chapter 7

electrodynamics fields and waves The electromagnetic field laws, derived thus far from the empirically determined Coulomb-Lorentz forces, are correct on the time scales of our own physical experiences. However, just as Newton's force law must be corrected for material speeds approaching that of light, the field laws must be corrected when fast time variations are on the order of the time it takes light to travel over the length of a system. Unlike the abstractness of relativistic mechanics, the complete electrodynamic equations describe a familiar phenomenon--propagation of electromagnetic waves. Throughout the rest of this text, we will examine when appropriate the lowfrequency limits to justify the past quasi-static assumptions.

7-1 MAXWELL'S EQUATIONS

7-1-1 Displacement Current Correction to Ampere's Law

In the historical development of electromagnetic field theory through the nineteenth century, charge and its electric field were studied separately from currents and their magnetic fields. Until Faraday showed that a time varying magnetic field generates an electric field, it was thought that the electric and magnetic fields were distinct and uncoupled. Faraday believed in the duality that a time varying electric field should also generate a magnetic field, but he was not able to prove this supposition.

It remained for James Clerk Maxwell to show that Faraday's hypothesis was correct and that without this correction Ampere's law and conservation of charge were inconsistent:

$$\nabla \times \mathbf{H} = \mathbf{J}_f \Rightarrow \nabla \cdot \mathbf{J}_f = 0 \tag{1}$$

$$\nabla \cdot \mathbf{J}_f + \frac{\partial \boldsymbol{\rho}_f}{\partial t} = 0 \tag{2}$$

for if we take the divergence of Ampere's law in (1), the current density must have zero divergence because the divergence of the curl of a vector is always zero. This result contradicts (2) if a time varying charge is present. Maxwell realized that adding the displacement current on the righthand side of Ampere's law would satisfy charge conservation, because of Gauss's law relating **D** to ρ_f ($\nabla \cdot \mathbf{D} = \rho_f$).

This simple correction has far-reaching consequences, because we will be able to show the existence of electromagnetic waves that travel at the speed of light *c*, thus proving that light is an electromagnetic wave. Because of the significance of Maxwell's correction, the complete set of coupled electromagnetic field laws are called Maxwell's equations:

Faraday's Law

$$\nabla \times \mathbf{E} = -\frac{\partial \mathbf{B}}{\partial t} \Rightarrow \oint_{L} \mathbf{E} \cdot \mathbf{d}\mathbf{l} = -\frac{d}{dt} \int_{S} \mathbf{B} \cdot \mathbf{d}\mathbf{S}$$
(3)

Ampere's law with Maxwell's displacement current correction

$$\nabla \times \mathbf{H} = \mathbf{J}_f + \frac{\partial \mathbf{D}}{\partial t} \Rightarrow \oint_L \mathbf{H} \cdot \mathbf{dI} = \int_S \mathbf{J}_f \cdot \mathbf{dS} + \frac{d}{dt} \int_S \mathbf{D} \cdot \mathbf{dS} \quad (4)$$

Gauss's laws

$$\nabla \cdot \mathbf{D} = \rho_f \Rightarrow \oint_S \mathbf{D} \cdot \mathbf{dS} = \int_V \rho_f \, dV \tag{5}$$

$$\nabla \cdot \mathbf{B} = 0 \Rightarrow \oint_{S} \mathbf{B} \cdot \mathbf{dS} = 0$$
(6)

Conservation of charge

$$\nabla \cdot \mathbf{J}_f + \frac{\partial \rho_f}{\partial t} = 0 \Rightarrow \oint_S \mathbf{J}_f \cdot \mathbf{dS} + \frac{d}{dt} \int_V \rho_f \, dV = 0 \tag{7}$$

As we have justified, (7) is derived from the divergence of (4) using (5).

Note that (6) is not independent of (3) for if we take the divergence of Faraday's law, $\nabla \cdot \mathbf{B}$ could at most be a time-independent function. Since we assume that at some point in time $\mathbf{B} = 0$, this function must be zero.

The symmetry in Maxwell's equations would be complete if a magnetic charge density appeared on the right-hand side of Gauss's law in (6) with an associated magnetic current due to the flow of magnetic charge appearing on the right-hand side of (3). Thus far, no one has found a magnetic charge or current, although many people are actively looking. Throughout this text we accept (3)-(7) keeping in mind that if magnetic charge is discovered, we must modify (3) and (6) and add an equation like (7) for conservation of magnetic charge.

7-1-2 Circuit Theory as a Quasi-static Approximation

Circuit theory assumes that the electric and magnetic fields are highly localized within the circuit elements. Although the displacement current is dominant within a capacitor, it is negligible outside so that Ampere's law can neglect time variations of **D** making the current divergence-free. Then we obtain Kirchoff's current law that the algebraic sum of all currents flowing into (or out of) a node is zero:

$$\nabla \cdot \mathbf{J} = 0 \Rightarrow \oint_{S} \mathbf{J} \cdot \mathbf{dS} = 0 \Rightarrow \Sigma i_{k} = 0$$
(8)

Similarly, time varying magnetic flux that is dominant within inductors and transformers is assumed negligible outside so that the electric field is curl free. We then have Kirchoff's voltage law that the algebraic sum of voltage drops (or rises) around any closed loop in a circuit is zero:

$$\nabla \times \mathbf{E} = 0 \Rightarrow \mathbf{E} = -\nabla V \Rightarrow \oint_{L} \mathbf{E} \cdot \mathbf{d}\mathbf{l} = 0 \Rightarrow \Sigma v_{k} = 0$$
(9)

7-2 CONSERVATION OF ENERGY

7-2-1 Poynting's Theorem

We expand the vector quantity

$$\nabla \cdot (\mathbf{E} \times \mathbf{H}) = \mathbf{H} \cdot (\nabla \times \mathbf{E}) - \mathbf{E} \cdot (\nabla \times \mathbf{H})$$
$$= -\mathbf{H} \cdot \frac{\partial \mathbf{B}}{\partial t} - \mathbf{E} \cdot \frac{\partial \mathbf{D}}{\partial t} - \mathbf{E} \cdot \mathbf{J}_{f}$$
(1)

where we change the curl terms using Faraday's and Ampere's laws.

For linear homogeneous media, including free space, the constitutive laws are

$$\mathbf{D} = \boldsymbol{\varepsilon} \mathbf{E}, \qquad \mathbf{B} = \boldsymbol{\mu} \mathbf{H} \tag{2}$$

so that (1) can be rewritten as

$$\nabla \cdot (\mathbf{E} \times \mathbf{H}) + \frac{\partial}{\partial t} (\frac{1}{2} \varepsilon E^2 + \frac{1}{2} \mu H^2) = -\mathbf{E} \cdot \mathbf{J}_f$$
(3)

which is known as Poynting's theorem. We integrate (3) over a closed volume, using the divergence theorem to convert the

first term to a surface integral:

$$\oint_{S} (\mathbf{E} \times \mathbf{H}) \cdot \mathbf{dS} + \frac{d}{dt} \int_{V} (\frac{1}{2} \varepsilon E^{2} + \frac{1}{2} \mu H^{2}) \, d\mathbf{V} = -\int_{V} \mathbf{E} \cdot \mathbf{J}_{f} \, d\mathbf{V} \quad (4)$$

We recognize the time derivative in (4) as operating on the electric and magnetic energy densities, which suggests the interpretation of (4) as

$$P_{\rm out} + \frac{dW}{dt} = -P_d \tag{5}$$

where P_{out} is the total electromagnetic power flowing out of the volume with density

$$\mathbf{S} = \mathbf{E} \times \mathbf{H} \text{ watts/m}^2 [kg-s^{-3}]$$
 (6)

where S is called the Poynting vector, W is the electromagnetic stored energy, and P_d is the power dissipated or generated:

$$P_{out} = \oint_{S} (\mathbf{E} \times \mathbf{H}) \cdot \mathbf{dS} = \oint_{S} S \cdot \mathbf{dS}$$
$$W = \int_{V} \left[\frac{1}{2} \varepsilon E^{2} + \frac{1}{2} \mu H^{2} \right] dV$$
(7)
$$P_{d} = \oint_{V} \mathbf{E} \cdot \mathbf{J}_{f} dV$$

If **E** and J_f are in the same direction as in an Ohmic conductor ($\mathbf{E} \cdot \mathbf{J}_f = \sigma E^2$), then P_d is positive, representing power dissipation since the right-hand side of (5) is negative. A source that supplies power to the volume has **E** and J_f in opposite directions so that P_d is negative.

7-2-2 A Lossy Capacitor

Poynting's theorem offers a different and to some a paradoxical explanation of power flow to circuit elements. Consider the cylindrical lossy capacitor excited by a time varying voltage source in Figure 7-1. The terminal current has both Ohmic and displacement current contributions:

$$i = \frac{\varepsilon A}{l} \frac{dv}{dt} + \frac{\sigma Av}{l} = C \frac{dv}{dt} + \frac{v}{R}, \qquad C = \frac{\varepsilon A}{l}, \qquad R = \frac{l}{\sigma A}$$
(8)

From a circuit theory point of view we would say that the power flows from the terminal wires, being dissipated in the

491



Figure 7-1 The power delivered to a lossy cylindrical capacitor vi is partly dissipated by the Ohmic conduction and partly stored in the electric field. This power can also be thought to flow-in radially from the surrounding electric and magnetic fields via the Poynting vector $S = E \times H$.

resistance and stored as electrical energy in the capacitor:

$$P = vi = \frac{v^2}{R} + \frac{d}{dt} (\frac{1}{2} C v^2)$$
(9)

We obtain the same results from a field's viewpoint using Poynting's theorem. Neglecting fringing, the electric field is simply

$$E_{\rm r} = v/l \tag{10}$$

while the magnetic field at the outside surface of the resistor is generated by the conduction and displacement currents:

$$\oint_{L} \mathbf{H} \cdot \mathbf{dl} = \int_{S} \left(J_{z} + \varepsilon \frac{\partial E_{z}}{\partial t} \right) dS \Rightarrow H_{\phi} 2\pi a = \frac{\sigma A v}{l} + \frac{\varepsilon}{l} A \frac{dv}{dt} = i \quad (11)$$

where we recognize the right-hand side as the terminal current in (8),

$$H_{\phi} = i/(2\pi a) \tag{12}$$

The power flow through the surface at r = a surrounding the resistor is then radially inward,

$$\oint_{S} (\mathbf{E} \times \mathbf{H}) \cdot \mathbf{dS} = -\int_{S} \frac{v}{l} \frac{i}{2\pi a} a \, d\phi \, dz = -vi \tag{13}$$

and equals the familiar circuit power formula. The minus sign arises because the left-hand side of (13) is the power out of the volume as the surface area element **dS** points radially outwards. From the field point of view, power flows into the lossy capacitor from the electric and magnetic fields outside the resistor via the Poynting vector. Whether the power is thought to flow along the terminal wires or from the surrounding fields is a matter of convenience as the results are identical. The presence of the electric and magnetic fields are directly due to the voltage and current. It is impossible to have the fields without the related circuit variables.

7-2-3 Power in Electric Circuits

We saw in (13) that the flux of S entering the surface surrounding a circuit element just equals vi. We can show this for the general network with N terminals in Figure 7-2 using the quasi-static field laws that describe networks outside the circuit elements:

$$\nabla \times \mathbf{E} = 0 \Rightarrow \mathbf{E} = -\nabla V$$

$$\nabla \times \mathbf{H} = \mathbf{L} \Rightarrow \nabla \cdot \mathbf{L} = 0$$
 (14)

We then can rewrite the electromagnetic power into a surface as

$$P_{in} = -\oint_{S} \mathbf{E} \times \mathbf{H} \cdot \mathbf{dS}$$
$$= -\int_{V} \nabla \cdot (\mathbf{E} \times \mathbf{H}) \, dV$$
$$= \int_{V} \nabla \cdot (\nabla V \times \mathbf{H}) \, dV \qquad (15)$$



Figure 7-2 The circuit power into an N terminal network $\sum_{k=1}^{N} V_k I_k$ equals the electromagnetic power flow into the surface surrounding the network, $-\oint_S \mathbf{E} \times \mathbf{H} \cdot \mathbf{dS}$.

where the minus is introduced because we want the power in and we use the divergence theorem to convert the surface integral to a volume integral. We expand the divergence term as

$$\nabla \cdot (\nabla V \times \mathbf{H}) = \mathbf{H} \cdot (\nabla \times \nabla V) - \nabla V \cdot (\nabla \times \mathbf{H})$$
$$= -\mathbf{J}_{f} \cdot \nabla V = -\nabla \cdot (\mathbf{J}_{f} V)$$
(16)

where we use (14).

Substituting (16) into (15) yields

$$P_{\rm in} = -\int_{\rm V} \nabla \cdot (\mathbf{J}_f V) \, d\mathbf{V}$$
$$= -\oint_{\rm S} \mathbf{J}_f V \cdot \mathbf{dS} \tag{17}$$

where we again use the divergence theorem. On the surface S, the potential just equals the voltages on each terminal wire allowing V to be brought outside the surface integral:

$$P_{in} = \sum_{k=1}^{N} - V_k \oint_S \mathbf{J}_f \cdot \mathbf{dS}$$
$$= \sum_{k=1}^{N} V_k I_k$$
(18)

where we recognize the remaining surface integral as just being the negative (remember **dS** points outward) of each terminal current flowing into the volume. This formula is usually given as a postulate along with Kirchoff's laws in most circuit theory courses. Their correctness follows from the quasi-static field laws that are only an approximation to more general phenomena which we continue to explore.

7-2-4 The Complex Poynting's Theorem

For many situations the electric and magnetic fields vary sinusoidally with time:

$$\mathbf{E}(\mathbf{r}, t) = \operatorname{Re} \left[\hat{\mathbf{E}}(\mathbf{r}) e^{j\omega t} \right]$$

$$\mathbf{H}(\mathbf{r}, t) = \operatorname{Re} \left[\hat{\mathbf{H}}(\mathbf{r}) e^{j\omega t} \right]$$
 (19)

where the caret is used to indicate a complex amplitude that can vary with position **r**. The instantaneous power density is obtained by taking the cross product of **E** and **H**. However, it is often useful to calculate the time-average power density $\langle S \rangle$, where we can avoid the lengthy algebraic and trigonometric manipulations in expanding the real parts in (19). A simple rule for the time average of products is obtained by realizing that the real part of a complex number is equal to one half the sum of the complex number and its conjugate (denoted by a superscript asterisk). The power density is then

$$S(\mathbf{r}, t) = \mathbf{E}(\mathbf{r}, t) \times \mathbf{H}(\mathbf{r}, t)$$

$$= \frac{1}{4} [\hat{\mathbf{E}}(\mathbf{r}) e^{j\omega t} + \hat{\mathbf{E}}^{*}(\mathbf{r}) e^{-j\omega t}] \times [\hat{\mathbf{H}}(\mathbf{r}) e^{j\omega t} + \hat{\mathbf{H}}^{*}(\mathbf{r}) e^{-j\omega t}]$$

$$= \frac{1}{4} [\hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}(\mathbf{r}) e^{2j\omega t} + \hat{\mathbf{E}}^{*}(\mathbf{r}) \times \hat{\mathbf{H}}(\mathbf{r}) + \hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r})$$

$$+ \hat{\mathbf{E}}^{*}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r}) e^{-2j\omega t}] \qquad (20)$$

The time average of (20) is then

$$< \mathbf{S} > = \frac{1}{4} [\hat{\mathbf{E}}^{*}(\mathbf{r}) \times \hat{\mathbf{H}}(\mathbf{r}) + \hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r})]$$
$$= \frac{1}{2} \operatorname{Re} \left[\hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r})\right]$$
$$= \frac{1}{2} \operatorname{Re} \left[\hat{\mathbf{E}}^{*}(\mathbf{r}) \times \hat{\mathbf{H}}(\mathbf{r})\right]$$
(21)

as the complex exponential terms $e^{\pm 2i\omega t}$ average to zero over a period $T = 2\pi/\omega$ and we again realized that the first bracketed term on the right-hand side of (21) was the sum of a complex function and its conjugate.

Motivated by (21) we define the complex Poynting vector as

$$\hat{\boldsymbol{S}} = \frac{1}{2} \hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^*(\mathbf{r})$$
(22)

whose real part is just the time-average power density.

We can now derive a complex form of Poynting's theorem by rewriting Maxwell's equations for sinusoidal time variations as

$$\nabla \times \hat{\mathbf{E}}(\mathbf{r}) = -j\omega\mu \,\hat{\mathbf{H}}(\mathbf{r})$$

$$\nabla \times \hat{\mathbf{H}}(\mathbf{r}) = \hat{\mathbf{J}}_f(\mathbf{r}) + j\omega\varepsilon \,\hat{\mathbf{E}}(\mathbf{r})$$

$$\nabla \cdot \hat{\mathbf{E}}(\mathbf{r}) = \hat{\rho}_f(\mathbf{r})/\varepsilon$$

$$\nabla \cdot \hat{\mathbf{B}}(\mathbf{r}) = 0$$
(23)

and expanding the product

$$\nabla \cdot \hat{\boldsymbol{S}} = \nabla \cdot \left[\frac{1}{2}\hat{\boldsymbol{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r})\right] = \frac{1}{2} \left[\hat{\mathbf{H}}^{*}(\mathbf{r}) \cdot \nabla \times \hat{\mathbf{E}}(\mathbf{r}) - \hat{\mathbf{E}}(\mathbf{r}) \cdot \nabla \times \hat{\mathbf{H}}^{*}(\mathbf{r})\right]$$
$$= \frac{1}{2} \left[-j\omega\mu \left|\hat{\mathbf{H}}(\mathbf{r})\right|^{2} + j\omega\varepsilon \left|\hat{\mathbf{E}}(\mathbf{r})\right|^{2}\right] - \frac{1}{2}\hat{\mathbf{E}}(\mathbf{r}) \cdot \hat{\mathbf{J}}_{f}^{*}(\mathbf{r}) \qquad (24)$$

which can be rewritten as

$$\nabla \cdot \hat{\boldsymbol{S}} + 2j\boldsymbol{\omega}[\langle w_m \rangle - \langle w_e \rangle] = -\hat{\boldsymbol{P}}_d \tag{25}$$

where

$$< w_{m} > = \frac{1}{4} \mu | \hat{\mathbf{H}}(\mathbf{r}) |^{2}$$

$$< w_{e} > = \frac{1}{4} \varepsilon | \hat{\mathbf{E}}(\mathbf{r}) |^{2}$$

$$\hat{P}_{d} = \frac{1}{2} \hat{\mathbf{E}}(\hat{\mathbf{r}}) \cdot \hat{\mathbf{J}}_{f}^{*}(\mathbf{r})$$
(26)

We note that $\langle w_m \rangle$ and $\langle w_s \rangle$ are the time-average magnetic and electric energy densities and that the complex Poynting's theorem depends on their difference rather than their sum.

7-3 TRANSVERSE ELECTROMAGNETIC WAVES

7-3-1 Plane Waves

Let us try to find solutions to Maxwell's equations that only depend on the z coordinate and time in linear media with permittivity ε and permeability μ . In regions where there are no sources so that $\rho_f = 0$, $\mathbf{J}_f = 0$, Maxwell's equations then reduce to

$$-\frac{\partial E_{y}}{\partial z}\mathbf{i}_{x} + \frac{\partial E_{x}}{\partial z}\mathbf{i}_{y} = -\mu\frac{\partial \mathbf{H}}{\partial t}$$
(1)

$$-\frac{\partial H_{y}}{\partial z}\mathbf{i}_{x} + \frac{\partial H_{x}}{\partial z}\mathbf{i}_{y} = \varepsilon \frac{\partial \mathbf{E}}{\partial t}$$
(2)

$$\varepsilon \frac{\partial E_z}{\partial z} = 0 \tag{3}$$

$$\mu \frac{\partial H_z}{\partial z} = 0 \tag{4}$$

These relations tell us that at best E_x and H_z are constant in time and space. Because they are uncoupled, in the absence of sources we take them to be zero. By separating vector components in (1) and (2) we see that E_x is coupled to H_y and E_y is coupled to H_x :

$$\frac{\partial E_{x}}{\partial z} = -\mu \frac{\partial H_{y}}{\partial t}, \qquad \frac{\partial E_{y}}{\partial z} = \mu \frac{\partial H_{x}}{\partial t}$$

$$\frac{\partial H_{y}}{\partial z} = -\varepsilon \frac{\partial E_{x}}{\partial t}, \qquad \frac{\partial H_{x}}{\partial z} = \varepsilon \frac{\partial E_{y}}{\partial t}$$
(5)

forming two sets of independent equations. Each solution has perpendicular electric and magnetic fields. The power flow $S = E \times H$ for each solution is z directed also being perpendicular to E and H. Since the fields and power flow are mutually perpendicular, such solutions are called transverse electromagnetic waves (TEM). They are waves because if we take $\partial/\partial z$ of the upper equations and $\partial/\partial t$ of the lower equations and solve for the electric fields, we obtain one-dimensional wave equations:

$$\frac{\partial^2 E_x}{\partial z^2} = \frac{1}{c^2} \frac{\partial^2 E_x}{\partial t^2}, \qquad \frac{\partial^2 E_y}{\partial z^2} = \frac{1}{c^2} \frac{\partial^2 E_y}{\partial t^2}$$
(6)

where c is the speed of the wave,

$$c = \frac{1}{\sqrt{\varepsilon_{\mu}}} = \frac{1}{\sqrt{\varepsilon_{0}\mu_{0}}\sqrt{\varepsilon_{r}\mu_{r}}} \approx \frac{3 \times 10^{8}}{\sqrt{\varepsilon_{r}\mu_{r}}} \,\mathrm{m/sec}$$
(7)

In free space, where $\varepsilon_r = 1$ and $\mu_r = 1$, this quantity equals the speed of light in vacuum which demonstrated that light is a transverse electromagnetic wave. If we similarly take $\partial/\partial t$ of the upper and $\partial/\partial z$ of the lower equations in (5), we obtain wave equations in the magnetic fields:

$$\frac{\partial^2 H_y}{\partial z^2} = \frac{1}{c^2} \frac{\partial^2 H_y}{\partial t^2}, \qquad \frac{\partial^2 H_x}{\partial z^2} = \frac{1}{c^2} \frac{\partial^2 H_x}{\partial t^2}$$
(8)

7-3-2 The Wave Equation

(a) Solutions

These equations arise in many physical systems, so their solutions are well known. Working with the E_x and H_y equations, the solutions are

$$E_{x}(z, t) = E_{+}(t - z/c) + E_{-}(t + z/c)$$

$$H_{y}(z, t) = H_{+}(t - z/c) + H_{-}(t + z/c)$$
(9)

where the functions E_+ , E_- , H_+ , and H_- depend on initial conditions in time and boundary conditions in space. These solutions can be easily verified by defining the arguments α and β with their resulting partial derivatives as

$$\alpha = t - \frac{z}{c} \Rightarrow \frac{\partial \alpha}{\partial t} = 1, \qquad \frac{\partial \alpha}{\partial z} = -\frac{1}{c}$$

$$\beta = t + \frac{z}{c} \Rightarrow \frac{\partial \beta}{\partial t} = 1, \qquad \frac{\partial \beta}{\partial z} = \frac{1}{c}$$
(10)

and realizing that the first partial derivatives of $E_x(z, t)$ are

$$\frac{\partial E_{x}}{\partial t} = \frac{dE_{+}}{d\alpha} \frac{\partial \alpha}{\partial t} + \frac{dE_{-}}{d\beta} \frac{\partial \beta}{\partial t}$$
$$= \frac{dE_{+}}{d\alpha} + \frac{dE_{-}}{d\beta}$$
$$\frac{\partial E_{x}}{\partial z} = \frac{dE_{+}}{d\alpha} \frac{\partial \alpha}{\partial z} + \frac{dE_{-}}{d\beta} \frac{\partial \beta}{\partial z}$$
$$= \frac{1}{c} \left(-\frac{dE_{+}}{d\alpha} + \frac{dE_{-}}{d\beta} \right)$$
(11)

The second derivatives are then

$$\frac{\partial^{2} E_{x}}{\partial t^{2}} = \frac{d^{2} E_{+}}{d\alpha^{2}} \frac{\partial \alpha}{\partial t} + \frac{d^{2} E_{-}}{d\beta^{2}} \frac{\partial \beta}{\partial t}$$

$$= \frac{d^{2} E_{+}}{d\alpha^{2}} + \frac{d^{2} E_{-}}{d\beta^{2}}$$

$$\frac{\partial^{2} E_{x}}{\partial z^{2}} = \frac{1}{c} \left(-\frac{d^{2} E_{+}}{d\alpha^{2}} \frac{\partial \alpha}{\partial z} + \frac{d^{2} E_{-}}{d\beta^{2}} \frac{\partial \beta}{\partial z} \right)$$

$$= \frac{1}{c^{2}} \left(\frac{d^{2} E_{+}}{d\alpha^{2}} + \frac{d^{2} E_{-}}{d\beta^{2}} \right) = \frac{1}{c^{2}} \frac{\partial^{2} E_{x}}{\partial t^{2}}$$
(12)

which satisfies the wave equation of (6). Similar operations apply for H_y , E_y , and H_x .

In (9), the pair H_+ and E_+ as well as the pair H_- and E_- are not independent, as can be seen by substituting the solutions of (9) back into (5) and using (11):

$$\frac{\partial E_x}{\partial z} = -\mu \frac{\partial H_y}{\partial t} \Rightarrow \frac{1}{c} \left(-\frac{dE_+}{d\alpha} + \frac{dE_-}{d\beta} \right) = -\mu \left(\frac{dH_+}{d\alpha} + \frac{dH_-}{d\beta} \right) \quad (13)$$

The functions of α and β must separately be equal,

$$\frac{d}{d\alpha}(E_{+}-\mu cH_{+})=0, \qquad \frac{d}{d\beta}(E_{-}+\mu cH_{-})=0 \qquad (14)$$

which requires that

$$E_{+} = \mu c H_{+} = \sqrt{\frac{\mu}{\varepsilon}} H_{+}, \qquad E_{-} = -\mu c H_{-} = -\sqrt{\frac{\mu}{\varepsilon}} H_{-} \quad (15)$$

where we use (7). Since $\sqrt{\mu/\varepsilon}$ has units of Ohms, this quantity is known as the wave impedance η ,

$$\eta = \sqrt{\frac{\mu}{\varepsilon}} \approx 120\pi \sqrt{\frac{\mu_r}{\varepsilon_r}}$$
(16)

and has value $120\pi \approx 377$ ohm in free space ($\mu_r = 1$, $\varepsilon_r = 1$). The power flux density in TEM waves is

$$S = E \times H = [E_{+}(t - z/c) + E_{-}(t + z/c)]i_{x}$$

$$\times [H_{+}(t - z/c) + H_{-}(t + z/c)]i_{y}$$

$$= (E_{+}H_{+} + E_{-}H_{-} + E_{-}H_{+} + E_{+}H_{-})i_{z} \qquad (17)$$

Using (15) and (16) this result can be written as

$$S_{z} = \frac{1}{\eta} (E_{+}^{2} - E_{-}^{2})$$
 (18)

where the last two cross terms in (17) cancel because of the minus sign relating E_{-} to H_{-} in (15). For TEM waves the total power flux density is due to the difference in power densities between the squares of the positively z-directed and negatively z-directed waves.

(b) Properties

The solutions of (9) are propagating waves at speed c. To see this, let us examine $E_{+}(t-z/c)$ and consider the case where at z = 0, $E_{+}(t)$ is the staircase pulse shown in Figure 7-3a. In Figure 7-3b we replace the argument t by t-z/c. As long as the function E_{+} is plotted versus its argument, no matter what its argument is, the plot remains unchanged. However, in Figure 7-3c the function $E_{+}(t-z/c)$ is plotted versus t resulting in the pulse being translated in time by an amount z/c. To help in plotting this translated function, we use the following logic:

- (i) The pulse jumps to amplitude E_0 when the argument is zero. When the argument is t-z/c, this occurs for t = z/c.
- (ii) The pulse jumps to amplitude $2E_0$ when the argument is T. When the argument is t-z/c, this occurs for t = T+z/c.
- (iii) The pulse returns to zero when the argument is 2T. For the argument t - z/c, we have t = 2T + z/c.



Figure 7-3 (a) $E_+(t)$ at z = 0 is a staircase pulse. (b) $E_+(\phi)$ always has the same shape as (a) when plotted versus ϕ , no matter what ϕ is. Here $\phi = t - z/c$. (c) When plotted versus t, the pulse is translated in time where z must be positive to keep t positive. (d) When plotted versus z, it is translated and inverted. The pulse propagates at speed c in the positive z direction.

Note that z can only be positive as causality imposes the condition that time can only be increasing. The response at any positive position z to an initial E_+ pulse imposed at z = 0 has the same shape in time but occurs at a time z/c later. The pulse travels the distance z at the speed c. This is why the function $E_+(t-z/c)$ is called a positively traveling wave.

In Figure 7-3d we plot the same function versus z. Its appearance is inverted as that part of the pulse generated first (step of amplitude E_0) will reach any positive position z first. The second step of amplitude $2E_0$ has not traveled as far since it was generated a time T later. To help in plotting, we use the same criterion on the argument as used in the plot versus time, only we solve for z. The important rule we use is that as long as the argument of a function remains constant, the value of the function is unchanged, no matter how the individual terms in the argument change.

Thus, as long as

$$t - z/c = \text{const} \tag{19}$$

 $E_+(t-z/c)$ is unchanged. As time increases, so must z to satisfy (19) at the rate

$$t - \frac{z}{c} = \text{const} \Rightarrow \frac{dz}{dt} = c \tag{20}$$

to keep the E_+ function constant.

For similar reasons $E_{-}(t+z/c)$ represents a traveling wave at the speed c in the negative z direction as an observer must move to keep the argument t+z/c constant at speed:

$$t + \frac{z}{c} = \text{const} \Rightarrow \frac{dz}{dt} = -c \tag{21}$$

as demonstrated for the same staircase pulse in Figure 7-4. Note in Figure 7-4d that the pulse is not inverted when plotted versus z as it was for the positively traveling wave, because that part of the pulse generated first (step of amplitude E_0) reaches the maximum distance but in the negative z direction. These differences between the positively and negatively traveling waves are functionally due to the difference in signs in the arguments (t - z/c) and (t + z/c).

7-3-3 Sources of Plane Waves

These solutions are called plane waves because at any constant z plane the fields are constant and do not vary with the x and y coordinates.

The idealized source of a plane wave is a time varying current sheet of infinite extent that we take to be x directed,



Figure 7-4 (a) $E_{-}(t)$ at z = 0 is a staircase pulse. (b) $E_{-}(\phi)$ always has the same form of (a) when plotted versus ϕ . Here $\phi = t + z/c$. (c) When plotted versus t, the pulse is translated in time where z must be negative to keep t positive. (d) When plotted versus z, it is translated but not inverted.

as shown in Figure 7-5. From the boundary condition on the discontinuity of tangential H, we find that the x-directed current sheet gives rise to a y-directed magnetic field:

$$H_{y}(z=0_{+}) - H_{y}(z=0_{-}) = -K_{x}(t)$$
(22)

In general, a uniform current sheet gives rise to a magnetic field perpendicular to the direction of current flow but in the plane of the sheet. Thus to generate an x-directed magnetic field, a y-directed surface current is required.

Since there are no other sources, the waves must travel away from the sheet so that the solutions on each side of the sheet are of the form

$$H_{y}(z, t) = \begin{cases} H_{+}(t-z/c) \\ H_{-}(t+z/c) \end{cases} \qquad E_{x}(z, t) = \begin{cases} \eta H_{+}(t-z/c), & z > 0 \\ -\eta H_{-}(t+z/c), & z < 0 \end{cases}$$
(23)

For z > 0, the waves propagate only in the positive z direction. In the absence of any other sources or boundaries, there can be no negatively traveling waves in this region. Similarly for z < 0, we only have waves propagating in the -z direction. In addition to the boundary condition of (22), the tangential component of **E** must be continuous across the sheet at z = 0

$$\frac{H_{+}(t) - H_{-}(t) = -K_{x}(t)}{\eta[H_{+}(t) + H_{-}(t)] = 0} \Rightarrow H_{+}(t) = -H_{-}(t) = \frac{-K_{x}(t)}{2} \quad (24)$$



Figure 7-5 (a) A linearly polarized plane wave is generated by an infinite current sheet. The electric field is in the direction opposite to the current on either side of the sheet. The magnetic field is perpendicular to the current but in the plane of the current sheet and in opposite directions as given by the right-hand rule on either side of the sheet. The power flow S is thus perpendicular to the current and to the sheet. (b) The field solutions for t > 2T if the current source is a staircase pulse in time.

so that the electric and magnetic fields have the same shape as the current. Because the time and space shape of the fields remains unchanged as the waves propagate, linear dielectric media are said to be nondispersive.

Note that the electric field at z = 0 is in the opposite direction as the current, so the power per unit area delivered by the current sheet.

$$-\mathbf{E}(z=0,t)\cdot\mathbf{K}_{x}(t)=\frac{\eta K_{x}^{2}(t)}{2}$$
(25)

is equally carried away by the Poynting vector on each side of the sheet:

$$\boldsymbol{S}(\boldsymbol{z}=\boldsymbol{0}) = \mathbf{E} \times \mathbf{H} = \begin{cases} \frac{\eta K_{x}^{2}(t)}{4} \mathbf{i}_{z}, & z > 0\\ \frac{-\eta K_{x}^{2}(t)}{4} \mathbf{i}_{z}, & z < 0 \end{cases}$$
(26)

7-3-4 A Brief Introduction to the Theory of Relativity

Maxwell's equations show that <u>electromagnetic</u> waves propagate at the speed $c_0 = 1/\sqrt{\varepsilon_0 \mu_0}$ in vacuum. Our natural intuition would tell us that if we moved at a speed v we would measure a wave speed of $c_0 - v$ when moving in the same direction as the wave, and a speed $c_0 + v$ when moving in the opposite direction. However, our intuition would be wrong, for nowhere in the free space, source-free Maxwell's equations does the speed of the observer appear. Maxwell's equations predict that the speed of electromagnetic waves is c_0 for all observers no matter their relative velocity. This assumption is a fundamental postulate of the theory of relativity and has been verified by all experiments. The most notable experiment was performed by A. A. Michelson and E. W. Morley in the late nineteenth century, where they showed that the speed of light reflected between mirrors is the same whether it propagated in the direction parallel or perpendicular to the velocity of the earth. This postulate required a revision of the usual notions of time and distance.

If the surface current sheet of Section 7-3-3 is first turned on at t = 0, the position of the wave front on either side of the sheet at time t later obeys the equality

$$z^2 - c_0^2 t^2 = 0 \tag{27}$$

Similarly, an observer in a coordinate system moving with constant velocity ui, which is aligned with the current sheet at t = 0 finds the wavefront position to obey the equality

$$z'^2 - c_0^2 t'^2 = 0 \tag{28}$$

The two coordinate systems must be related by a linear transformation of the form

$$z' = a_1 z + a_2 t, \qquad t' = b_1 z + b_2 t$$
 (29)

The position of the origin of the moving frame (z'=0) as measured in the stationary frame is z = vt, as shown in Figure 7-6, so that a_1 and a_2 are related as

$$0 = a_1 v t + a_2 t \Rightarrow a_1 v + a_2 = 0 \tag{30}$$

We can also equate the two equalities of (27) and (28),

$$z^{2} - c_{0}^{2}t^{2} = z'^{2} - c_{0}^{2}t'^{2} = (a_{1}z + a_{2}t)^{2} - c_{0}^{2}(b_{1}z + b_{2}t)^{2}$$
(31)

so that combining terms yields

$$z^{2}(1-a_{1}^{2}+c_{0}^{2}b_{1}^{2})-c_{0}^{2}t^{2}\left(1+\frac{a_{2}^{2}}{c_{0}^{2}}-b_{2}^{2}\right)-2(a_{1}a_{2}-c_{0}^{2}b_{1}b_{2})zt=0$$
(32)

Since (32) must be true for all z and t, each of the coefficients must be zero, which with (30) gives solutions

$$a_{1} = \frac{1}{\sqrt{1 - (v/c_{0})^{2}}}, \qquad b_{1} = \frac{-v/c_{0}^{2}}{\sqrt{1 - (v/c_{0})^{2}}}$$

$$a_{2} = \frac{-v}{\sqrt{1 - (v/c_{0})^{2}}}, \qquad b_{2} = \frac{1}{\sqrt{1 - (v/c_{0})^{2}}}$$
(33)



Figure 7-6 The primed coordinate system moves at constant velocity vi, with respect to a stationary coordinate system. The free space speed of an electromagnetic wave is c_0 as measured by observers in either coordinate system no matter the velocity v.

The transformations of (29) are then

$$z' = \frac{z - vt}{\sqrt{1 - (v/c_0)^2}}, \qquad t' = \frac{t - vz/c_0^2}{\sqrt{1 - (v/c_0)^2}}$$
(34)

and are known as the Lorentz transformations. Measured lengths and time intervals are different for observers moving at different speeds. If the velocity v is much less than the speed of light, (34) reduces to the Galilean transformations,

$$\lim_{v \neq c \ll 1} z' \approx z - vt, \qquad t' \approx t \tag{35}$$

which describe our usual experiences at nonrelativistic speeds.

The coordinates perpendicular to the motion are unaffected by the relative velocity between reference frames

$$\mathbf{x}' = \mathbf{x}, \qquad \mathbf{y}' = \mathbf{y} \tag{36}$$

Continued development of the theory of relativity is beyond the scope of this text and is worth a course unto itself. Applying the Lorentz transformation to Newton's law and Maxwell's equations yield new results that at first appearance seem contrary to our experiences because we live in a world where most material velocities are much less than c_0 . However, continued experiments on such disparate time and space scales as between atomic physics and astronomics verify the predictions of relativity theory, in part spawned by Maxwell's equations.

7-4 SINUSOIDAL TIME VARIATIONS

7-4-1 Frequency and Wavenumber

If the current sheet of Section 7-3-3 varies sinusoidally with time as Re $(K_0 e^{i\omega t})$, the wave solutions require the fields to vary as $e^{i\omega(t-x/c)}$ and $e^{i\omega(t+x/c)}$:

$$H_{y}(z, t) = \begin{cases} \operatorname{Re}\left(-\frac{K_{0}}{2}e^{j\omega(t-z/c)}\right), & z > 0 \\ \operatorname{Re}\left(+\frac{K_{0}}{2}e^{j\omega(t+z/c)}\right), & z < 0 \end{cases}$$

$$E_{x}(z, t) = \begin{cases} \operatorname{Re}\left(-\frac{\eta K_{0}}{2}e^{j\omega(t-z/c)}\right), & z > 0 \\ \operatorname{Re}\left(-\frac{\eta K_{0}}{2}e^{j\omega(t+z/c)}\right), & z < 0 \end{cases}$$

$$(1)$$

At a fixed time the fields then also vary sinusoidally with position so that it is convenient to define the wavenumber as

$$k = \frac{2\pi}{\lambda} = \frac{\omega}{c} = \omega \sqrt{\mu \varepsilon}$$
(2)

where λ is the fundamental spatial period of the wave. At a fixed position the waveform is also periodic in time with period T:

$$T = \frac{1}{f} = \frac{2\pi}{\omega} \tag{3}$$

where f is the frequency of the source. Using (3) with (2) gives us the familiar frequency-wavelength formula:

$$\boldsymbol{\omega} = \boldsymbol{k}\boldsymbol{c} \Rightarrow \boldsymbol{f}\boldsymbol{\lambda} = \boldsymbol{c} \tag{4}$$

Throughout the electromagnetic spectrum, summarized in Figure 7-7, time varying phenomena differ only in the scaling of time and size. No matter the frequency or wavelength, although easily encompassing 20 orders of magnitude, electromagnetic phenomena are all described by Maxwell's equations. Note that visible light only takes up a tiny fraction of the spectrum.



Figure 7-7 Time varying electromagnetic phenomena differ only in the scaling of time (frequency) and size (wavelength). In linear dielectric media the frequency and wavelength are related as $f\lambda = c$ ($\omega = kc$), where $c = 1/\sqrt{\epsilon\mu}$ is the speed of light in the medium.

For a single sinusoidally varying plane wave, the timeaverage electric and magnetic energy densities are equal because the electric and magnetic field amplitudes are related through the wave impedance η :

$$\langle w_{m} \rangle = \langle w_{e} \rangle = \frac{1}{4}\mu |\mathbf{H}|^{2} = \frac{1}{4}\varepsilon |\mathbf{E}|^{2} = \frac{1}{16}\mu K_{0}^{2}$$
 (5)

From the complex Poynting theorem derived in Section 7-2-4, we then see that in a lossless region with no sources for |z| > 0 that $\hat{P}_d = 0$ so that the complex Poynting vector has zero divergence. With only one-dimensional variations with z, this requires the time-average power density to be a constant throughout space on each side of the current sheet:

$$\langle \mathbf{S} \rangle = \frac{1}{2} \operatorname{Re} \left[\hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r}) \right]$$
$$= \begin{cases} \frac{1}{8} \eta K_{0}^{2} \mathbf{i}_{z}, & z > 0\\ -\frac{1}{8} \eta K_{0}^{2} \mathbf{i}_{z}, & z < 0 \end{cases}$$
(6)

The discontinuity in $\langle S \rangle$ at z = 0 is due to the power output of the source.

7-4-2 Doppler Frequency Shifts

If the sinusoidally varying current sheet Re $(K_0 e^{j\omega t})$ moves with constant velocity vi_z , as in Figure 7-8, the boundary conditions are no longer at z = 0 but at z = vt. The general form of field solutions are then:

$$H_{y}(z, t) = \begin{cases} \operatorname{Re} \left(\hat{H}_{+} e^{j\omega_{+}(t-z/c)} \right), & z > vt \\ \operatorname{Re} \left(\hat{H}_{-} e^{j\omega_{-}(t+z/c)} \right), & z < vt \end{cases}$$

$$E_{x}(z, t) = \begin{cases} \operatorname{Re} \left(\eta \hat{H}_{+} e^{j\omega_{+}(t-z/c)} \right), & z > vt \\ \operatorname{Re} \left(-\eta \hat{H}_{-} e^{j\omega_{-}(t+z/c)} \right), & z < vt \end{cases}$$
(7)

where the frequencies of the fields ω_+ and ω_- on each side of the sheet will be different from each other as well as differing from the frequency of the current source ω . We assume $v/c \ll 1$ so that we can neglect relativistic effects discussed in Section 7-3-4. The boundary conditions

$$E_{x_{+}}(z = vt) = E_{x_{-}}(z = vt) \Rightarrow \hat{H}_{+} e^{i\omega_{+}t(1-v/c)} = -\hat{H}_{-} e^{i\omega_{-}t(1+v/c)}$$

$$H_{y_{+}}(z = vt) - H_{y_{-}}(z = vt) = -K_{x} \qquad (8)$$

$$\Rightarrow \hat{H}_{+} e^{i\omega_{+}t(1-v/c)} - \hat{H}_{-} e^{i\omega_{-}t(1+v/c)} = -K_{0} e^{i\omega t}$$

must be satisfied for all values of t so that the exponential time factors in (8) must all be equal, which gives the shifted



Figure 7-8 When a source of electromagnetic waves moves towards an observer, the frequency is raised while it is lowered when it moves away from an observer.

frequencies on each side of the sheet as

$$\omega_{+} = \frac{\omega}{1 - v/c} \approx \omega \left(1 + \frac{v}{c} \right),$$

$$\omega_{-} = \frac{\omega}{1 + v/c} \approx \omega \left(1 - \frac{v}{c} \right) \Rightarrow \hat{H}_{+} = -\hat{H}_{-} = -\frac{K_{0}}{2}$$
(9)

where $v/c \ll 1$. When the source is moving towards an observer, the frequency is raised while it is lowered when it moves away. Such frequency changes due to the motion of a source or observer are called Doppler shifts and are used to measure the velocities of moving bodies in radar systems. For $v/c \ll 1$, the frequency shifts are a small percentage of the driving frequency, but in absolute terms can be large enough to be easily measured. At a velocity v = 300 m/sec with a driving frequency of $f = 10^{10}$ Hz, the frequency is raised and lowered on each side of the sheet by $\Delta f = \pm f(v/c) = \pm 10^4$ Hz.

7-4-3 Ohmic Losses

Thus far we have only considered lossless materials. If the medium also has an Ohmic conductivity σ , the electric field

will cause a current flow that must be included in Ampere's law:

$$\frac{\partial E_x}{\partial z} = -\mu \frac{\partial H_y}{\partial t}$$

$$\frac{\partial H_y}{\partial z} = -J_x - \varepsilon \frac{\partial E_x}{\partial t} = -\sigma E_x - \varepsilon \frac{\partial E_x}{\partial t}$$
(10)

where for conciseness we only consider the x-directed electric field solution as the same results hold for the E_y , H_x solution. Our wave solutions of Section 7-3-2 no longer hold with this additional term, but because Maxwell's equations are linear with constant coefficients, for sinusoidal time variations the solutions in space must also be exponential functions, which we write as

$$E_{\mathbf{x}}(z, t) = \operatorname{Re} \left(\hat{E}_0 e^{j(\omega t - \mathbf{k}z)} \right)$$

$$H_{\mathbf{y}}(z, t) = \operatorname{Re} \left(\hat{H}_0 e^{j(\omega t - \mathbf{k}z)} \right)$$
(11)

where \hat{E}_0 and \hat{H}_0 are complex amplitudes and the wavenumber k is no longer simply related to ω as in (4) but is found by substituting (11) back into (10):

$$-jk\hat{E}_{0} = -j\omega\mu\hat{H}_{0}$$

$$-jk\hat{H}_{0} = -j\omega\varepsilon(1+\sigma/j\omega\varepsilon)\hat{E}_{0}$$
 (12)

This last relation was written in a way that shows that the conductivity enters in the same way as the permittivity so that we can define a complex permittivity $\hat{\varepsilon}$ as

$$\hat{\varepsilon} = \varepsilon \left(1 + \sigma / j \omega \varepsilon \right) \tag{13}$$

Then the solutions to (12) are

$$\frac{\hat{E}_0}{\hat{H}_0} = \frac{\omega\mu}{k} = \frac{k}{\omega\hat{\varepsilon}} \Rightarrow k^2 = \omega^2 \mu \hat{\varepsilon} = \omega^2 \mu \varepsilon \left(1 + \frac{\sigma}{j\omega\varepsilon}\right) \qquad (14)$$

which is similar in form to (2) with a complex permittivity. There are two interesting limits of (14):

(a) Low Loss Limit

If the conductivity is small so that $\sigma/\omega\epsilon \ll 1$, then the solution of (14) reduces to

$$\lim_{\sigma/\omega\varepsilon\ll 1} k = \pm \omega \sqrt{\mu\varepsilon} \left(1 + \frac{\sigma}{2j\omega\varepsilon} \right) = \pm \left(\frac{\omega}{c} - \frac{j\sigma}{2} \sqrt{\frac{\mu}{\varepsilon}} \right)$$
(15)

where c is the speed of the light in the medium if there were no losses, $c = 1/\sqrt{\mu\epsilon}$. Because of the spatial exponential dependence in (11), the real part of k is the same as for the lossless case and represents the sinusoidal spatial distribution of the fields. The imaginary part of k represents the exponential decay of the fields due to the Ohmic losses with exponential decay length $\frac{1}{2}\sigma\eta$, where $\eta = \sqrt{\mu/\varepsilon}$ is the wave impedance. Note that for waves traveling in the positive z direction we take the upper positive sign in (15) using the lower negative sign for negatively traveling waves so that the solutions all decay and do not grow for distances far from the source. This solution is only valid for small σ so that the wave is only slightly damped as it propagates, as illustrated in Figure 7-9a.



Figure 7-9 (a) In a slightly lossy dielectric, the fields decay away from a source at a slow rate while the wavelength is essentially unchanged. (b) In the large loss limit the spatial decay rate is equal to the skin depth. The wavelength also equals the skin depth.

(b) Large Loss Limit

In the other extreme of a highly conducting material so that $\sigma/\omega\varepsilon \gg 1$, (14) reduces to

$$\lim_{\sigma/\omega\varepsilon \gg 1} k^2 \approx -j\omega\mu\sigma \Rightarrow k = \pm \frac{(1-j)}{\delta}, \qquad \delta = \sqrt{\frac{2}{\omega\mu\sigma}} \quad (16)$$

where δ is just the skin depth found in Section 6-4-3 for magneto-quasi-static fields within a conductor. The skindepth term also arises for electrodynamic fields because the large loss limit has negligible displacement current compared to the conduction currents.

Because the real and imaginary part of k have equal magnitudes, the spatial decay rate is large so that within a few oscillation intervals the fields are negligibly small, as illustrated in Figure 7-9b. For a metal like copper with $\mu = \mu_0 = 4\pi \times 10^{-7}$ henry/m and $\sigma \approx 6 \times 10^{7}$ siemens/m at a frequency of 1 MHz, the skin depth is $\delta \approx 6.5 \times 10^{-5}$ m.

7-4-4 High-Frequency Wave Propagation in Media

Ohm's law is only valid for frequencies much below the collision frequencies of the charge carriers, which is typically on the order of 10^{13} Hz. In this low-frequency regime the inertia of the particles is negligible. For frequencies much higher than the collision frequency the inertia dominates and the current constitutive law for a single species of charge carrier q with mass m and number density n is as found in Section 3-2-2d:

$$\partial \mathbf{J}_f / \partial t = \omega_p^2 \varepsilon \mathbf{E} \tag{17}$$

where $\omega_p = \sqrt{q^2 n/m\varepsilon}$ is the plasma frequency. This constitutive law is accurate for radio waves propagating in the ionosphere, for light waves propagating in many dielectrics, and is also valid for superconductors where the collision frequency is zero.

Using (17) rather than Ohm's law in (10) for sinusoidal time and space variations as given in (11), Maxwell's equations are

$$\frac{\partial E_{\mathbf{x}}}{\partial z} = -\mu \frac{\partial H_{\mathbf{y}}}{\partial t} \Rightarrow -jk\hat{E}_{0} = -j\omega\mu\hat{H}_{0}$$

$$\frac{\partial H_{\mathbf{y}}}{\partial z} = -J_{\mathbf{x}} - \varepsilon \frac{\partial E_{\mathbf{x}}}{\partial t} \Rightarrow -jk\hat{H}_{0} = -j\omega\varepsilon \left(1 - \frac{\omega_{p}^{2}}{\omega^{2}}\right)\hat{E}_{0}$$
(18)

The effective permittivity is now frequency dependent:

$$\hat{\varepsilon} = \varepsilon \left(1 - \omega_p^2 / \omega^2 \right) \tag{19}$$

The solutions to (18) are

$$\frac{\hat{E}_0}{\hat{H}_0} = \frac{\omega\mu}{k} = \frac{k}{\omega\hat{\varepsilon}} \Rightarrow k^2 = \omega^2 \mu\hat{\varepsilon} = \frac{\omega^2 - \omega_p^2}{c^2}$$
(20)

For $\omega > \omega_p$, k is real and we have pure propagation where the wavenumber depends on the frequency. For $\omega < \omega_p$, k is imaginary representing pure exponential decay.

Poynting's theorem for this medium is

$$\nabla \cdot \mathbf{S} + \frac{\partial}{\partial t} (\frac{1}{2} \varepsilon |\mathbf{E}|^2 + \frac{1}{2} \mu |\mathbf{H}|^2) = -\mathbf{E} \cdot \mathbf{J}_f = -\frac{1}{\omega_p^2 \varepsilon} \mathbf{J}_f \cdot \frac{\partial \mathbf{J}_f}{\partial t}$$
$$= -\frac{\partial}{\partial t} \left(\frac{1}{\omega_p^2 \varepsilon} \frac{|\mathbf{J}_f|^2}{2} \right)$$
(21)

Because this system is lossless, the right-hand side of (21) can be brought to the left-hand side and lumped with the energy densities:

$$\nabla \cdot \boldsymbol{S} + \frac{\partial}{\partial t} \left[\frac{1}{2} \varepsilon |\mathbf{E}|^2 + \frac{1}{2} \mu |\mathbf{H}|^2 + \frac{1}{2} \frac{1}{\omega_{\rho}^2 \varepsilon} |\mathbf{J}_f|^2 \right] = 0 \qquad (22)$$

This new energy term just represents the kinetic energy density of the charge carriers since their velocity is related to the current density as

$$\mathbf{J}_{f} = qn\mathbf{v} \Rightarrow \frac{1}{2} \frac{1}{\omega_{p}^{2}\varepsilon} |\mathbf{J}_{f}|^{2} = \frac{1}{2}mn|\mathbf{v}|^{2}$$
(23)

7-4-5 Dispersive Media

When the wavenumber is not proportional to the frequency of the wave, the medium is said to be dispersive. A nonsinusoidal time signal (such as a square wave) will change shape and become distorted as the wave propagates because each Fourier component of the signal travels at a different speed.

To be specific, consider a stationary current sheet source at z = 0 composed of two signals with slightly different frequencies:

$$K(t) = K_0[\cos(\omega_0 + \Delta\omega)t + \cos(\omega_0 - \Delta\omega)t]$$

= 2K_0 cos \Delta\u03c0 t cos \u03c0_0 t (24)

With $\Delta \omega \ll \omega$ the fast oscillations at frequency ω_0 are modulated by the slow envelope function at frequency $\Delta \omega$. In a linear dielectric medium this wave packet would propagate away from the current sheet at the speed of light, $c = 1/\sqrt{\epsilon \mu}$).

If the medium is dispersive, with the wavenumber $k(\omega)$ being a function of ω , each frequency component in (24) travels at a slightly different speed. Since each frequency is very close to ω_0 we expand $k(\omega)$ as

$$k(\omega_{0} + \Delta\omega) \approx k(\omega_{0}) + \frac{dk}{d\omega} \Big|_{\omega_{0}} \Delta\omega$$

$$k(\omega_{0} - \Delta\omega) \approx k(\omega_{0}) - \frac{dk}{d\omega} \Big|_{\omega_{0}} \Delta\omega$$
(25)

where for propagation $k(\omega_0)$ must be real.

The fields for waves propagating in the +z direction are then of the following form:

$$E_{\mathbf{x}}(z,t) = \operatorname{Re} \hat{E}_{0} \left(\exp \left\{ j \left[(\omega_{0} + \Delta \omega)t - \left(k(\omega_{0}) + \frac{dk}{d\omega} \Big|_{\omega_{0}} \Delta \omega \right) z \right] \right\} \right. \\ \left. + \exp \left\{ j \left[(\omega_{0} - \Delta \omega)t - \left(k(\omega_{0}) - \frac{dk}{d\omega} \Big|_{\omega_{0}} \Delta \omega \right) z \right] \right\} \right) \right. \\ \left. = \operatorname{Re} \left(\hat{E}_{0} \exp \left\{ j \left[\omega_{0}t - k(\omega_{0})z \right] \right\} \left\{ \exp \left[j \Delta \omega \left(t - \frac{dk}{d\omega} \Big|_{\omega_{0}} z \right) \right] \right. \right. \\ \left. + \exp \left[-j \Delta \omega \left(t - \frac{dk}{d\omega} \Big|_{\omega_{0}} z \right) \right] \right\} \right) \right.$$

where without loss of generality we assume in the last relation that $\hat{E}_0 = E_0$ is real. This result is plotted in Figure 7-10 as a function of z for fixed time. The fast waves with argument $\omega_0 t - k(\omega_0) z$ travel at the phase speed $v_p = \omega_0/k(\omega_0)$ through the modulating envelope with argument $\Delta \omega (t - dk/d\omega|_{\omega_0} z)$. This envelope itself travels at the slow speed

$$t - \frac{dk}{d\omega}\Big|_{\omega_0} z = \text{const} \Rightarrow \frac{dz}{dt} = v_g = \frac{d\omega}{dk}\Big|_{\omega_0}$$
(27)

known as the group velocity, for it is the velocity at which a packet of waves within a narrow frequency band around ω_0 will travel.

For linear media the group and phase velocities are equal:

$$\omega = kc \Rightarrow v_{p} = \frac{\omega}{k} = c$$

$$v_{g} = \frac{d\omega}{dk} = c$$
(28)



Figure 7-10 In a dispersive medium the shape of the waves becomes distorted so the velocity of a wave is not uniquely defined. For a group of signals within a narrow frequency band the modulating envelope travels at the group velocity v_g . The signal within the envelope propagates through at the phase velocity v_{ϕ} .

while from Section 7-4-4 in the high-frequency limit for conductors, we see that

$$\omega^{2} = k^{2}c^{2} + \omega_{p}^{2} \Rightarrow v_{p} = \frac{\omega}{k}$$

$$v_{g} = \frac{d\omega}{dk} = \frac{k}{\omega}c^{2}$$
(29)

where the velocities only make sense when k is real so that $\omega > \omega_p$. Note that in this limit

$$v_{g}v_{p} = c^{2} \tag{30}$$

Group velocity only has meaning in a dispersive medium when the signals of interest are clustered over a narrow frequency range so that the slope defined by (27) is approximately constant and real.

7-4-6 Polarization

The two independent sets of solutions of Section 7-3-1 both have their power flow $S = E \times H$ in the z direction. One solution is said to have its electric field polarized in the x direction while the second has its electric field polarized in the y direction. Each solution alone is said to be linearly polarized because the electric field always points in the same direction for all time. If both field solutions are present, the direction of net electric field varies with time. In particular, let us say that the x and y components of electric field at any value of z differ in phase by angle ϕ :

$$\mathbf{E} = \operatorname{Re}\left[E_{x_0}\mathbf{i}_x + E_{y_0} e^{i\phi}\mathbf{i}_y\right] e^{i\omega t} = E_{x_0}\cos\omega t \mathbf{i}_x + E_{y_0}\cos(\omega t + \phi)\mathbf{i}_y$$
(31)

We can eliminate time as a parameter, realizing from (31) that

$$\cos \omega t = E_z/E_{z_0}$$
(32)
$$\sin \omega t = \frac{\cos \omega t \cos \phi - E_y/E_{y_0}}{\sin \phi} = \frac{(E_z/E_{z_0}) \cos \phi - E_y/E_{y_0}}{\sin \phi}$$

and using the identity that

$$\sin^{2} \omega t + \cos^{2} \omega t$$

= 1 = $\left(\frac{E_{x}}{E_{x_{0}}}\right)^{2} + \frac{\left(\frac{E_{x}}{E_{x_{0}}}\right)^{2} \cos^{2} \phi + \left(\frac{E_{y}}{E_{y_{0}}}\right)^{2} - \left(\frac{2E_{x}E_{y}}{E_{x_{0}}}\right)\cos \phi}{\sin^{2} \phi}$
(33)

to give us the equation of an ellipse relating E_x to E_y :

$$\left(\frac{E_x}{E_{x_0}}\right)^2 + \left(\frac{E_y}{E_{y_0}}\right)^2 - \frac{2E_xE_y}{E_{x_0}E_{y_0}}\cos\phi = \sin^2\phi \tag{34}$$

as plotted in Figure 7-11*a*. As time increases the electric field vector traces out an ellipse each period so this general case of the superposition of two linear polarizations with arbitrary phase ϕ is known as elliptical polarization. There are two important special cases:

(a) Linear Polarization

If E_x and E_y are in phase so that $\phi = 0$, (34) reduces to

$$\left(\frac{E_x}{E_{x_0}} - \frac{E_y}{E_{y_0}}\right)^2 = 0 \Rightarrow \tan \theta = \frac{E_y}{E_x} = \frac{E_{y_0}}{E_{x_0}}$$
(35)

The electric field at all times is at a constant angle θ to the x axis. The electric field amplitude oscillates with time along this line, as in Figure 7-11b. Because its direction is always along the same line, the electric field is linearly polarized.

(b) Circular Polarization

If both components have equal amplitudes but are 90° out of phase,

$$E_{x_0} = E_{y_0} \equiv E_0, \qquad \phi = \pm \pi/2$$
 (36)



Figure 7-11 (a) Two perpendicular field components with phase difference ϕ have the tip of the net electric field vector tracing out an ellipse each period. (b) If both field components are in phase, the ellipse reduces to a straight line. (c) If the field components have the same magnitude but are 90° out of phase, the ellipse becomes a circle. The polarization is left circularly polarized to z-directed power flow if the electric field rotates clockwise and is (d) right circularly polarized if it rotates counterclockwise.

(34) reduces to the equation of a circle:

$$E_x^2 + E_y^2 = E_0^2 \tag{37}$$

The tip of the electric field vector traces out a circle as time evolves over a period, as in Figure 7-11c. For the upper (+) sign for ϕ in (36), the electric field rotates clockwise while the negative sign has the electric field rotating counterclockwise. These cases are, respectively, called left and right circular polarization for waves propagating in the +z direction as found by placing the thumb of either hand in the direction of power flow. The fingers on the left hand curl in the direction of the rotating field for left circular polarization, while the fingers of the right hand curl in the direction of the rotating field for right circular polarization. Left and right circular polarizations reverse for waves traveling in the -z direction.

7-4-7 Wave Propagation in Anisotropic Media

Many properties of plane waves have particular applications to optics. Because visible light has a wavelength on the order of 500 nm, even a pencil beam of light 1 mm wide is 2000 wavelengths wide and thus approximates a plane wave.





(a) Polarizers

Light is produced by oscillating molecules whether in a light bulb or by the sun. This natural light is usually unpolarized as each molecule oscillates in time and direction independent of its neighbors so that even though the power flow may be in a single direction the electric field phase changes randomly with time and the source is said to be incoherent. Lasers, an acronym for "light amplification by stimulated emission of radiation," emits coherent light by having all the oscillating molecules emit in time phase.

A polarizer will only pass those electric field components aligned with the polarizer's transmission axis so that the transmitted light is linearly polarized. Polarizers are made of such crystals as tourmaline, which exhibit dichroism—the selective absorption of the polarization along a crystal axis. The polarization perpendicular to this axis is transmitted.

Because tourmaline polarizers are expensive, fragile, and of small size, improved low cost and sturdy sheet polarizers were developed by embedding long needlelike crystals or chainlike molecules in a plastic sheet. The electric field component in the long direction of the molecules or crystals is strongly absorbed while the perpendicular component of the electric field is passed.

For an electric field of magnitude E_0 at angle ϕ to the transmission axis of a polarizer, the magnitude of the transmitted field is

$$E_t = E_0 \cos \phi \tag{38}$$

so that the time-average power flux density is

$$\langle S \rangle = \left| \frac{1}{2} \operatorname{Re} \left[\hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r}) \right] \right|$$
$$= \frac{1}{2} \frac{E_{0}^{2}}{\eta} \cos^{2} \phi$$
(39)

which is known as the law of Malus.

(b) Double Refraction (Birefringence)

If a second polarizer, now called the analyzer, is placed parallel to the first but with its transmission axis at right angles, as in Figure 7-12, no light is transmitted. The combination is called a polariscope. However, if an anisotropic crystal is inserted between the polarizer and analyzer, light is transmitted through the analyzer. In these doubly refracting crystals, light polarized along the optic axis travels at speed c_{\parallel} while light polarized perpendicular to the axis travels at a slightly different speed c_{\perp} . The crystal is said to be birefringent. If linearly polarized light is incident at 45° to the axis,

$$\mathbf{E}(z=0, t) = E_0(\mathbf{i}_x + \mathbf{i}_y) \operatorname{Re}\left(e^{j\omega t}\right)$$
(40)

the components of electric field along and perpendicular to the axis travel at different speeds:

$$E_{\mathbf{x}}(z, t) = E_0 \operatorname{Re}\left(e^{j(\omega t - k_{\parallel} z)}\right), \qquad k_{\parallel} = \omega/c_{\parallel}$$

$$E_{\mathbf{y}}(z, t) = E_0 \operatorname{Re}\left(e^{j(\omega t - k_{\perp} z)}\right), \qquad k_{\perp} = \omega/c_{\perp}$$
(41)

After exiting the crystal at z = l, the total electric field is

$$\mathbf{E}(z = l, t) = E_0 \operatorname{Re} \left[e^{j\omega t} \left(e^{-jk_{\parallel}l} \mathbf{i}_x + e^{-jk_{\perp}l} \mathbf{i}_y \right) \right]$$
$$= E_0 \operatorname{Re} \left[e^{j(\omega t - k_{\parallel}l)} (\mathbf{i}_x + e^{j(k_{\parallel} - k_{\perp})l} \mathbf{i}_y) \right]$$
(42)



Figure 7-12 When a linearly polarized wave passes through a doubly refracting (birefringent) medium at an angle to the crystal axes, the transmitted light is elliptically polarized.

which is of the form of (31) for an elliptically polarized wave where the phase difference is

$$\boldsymbol{\phi} = (\boldsymbol{k}_{\parallel} - \boldsymbol{k}_{\perp})\boldsymbol{l} = \omega \boldsymbol{l} \left(\frac{1}{c_{\parallel}} - \frac{1}{c_{\perp}}\right)$$
(43)

When ϕ is an integer multiple of 2π , the light exiting the crystal is the same as if the crystal were not there so that it is not transmitted through the analyzer. If ϕ is an odd integer multiple of π , the exiting light is also linearly polarized but perpendicularly to the incident light so that it is polarized in the same direction as the transmission axis of the analyzer, and thus is transmitted. Such elements are called half-wave plates at the frequency of operation. When ϕ is an odd integer multiple of $\pi/2$, the exiting light is circularly

polarized and the crystal serves as a quarter-wave plate. However, only that polarization of light along the transmission axis of the analyzer is transmitted.

Double refraction occurs naturally in many crystals due to their anisotropic molecular structure. Many plastics and glasses that are generally isotropic have induced birefringence when mechanically stressed. When placed within a polariscope the photoelastic stress patterns can be seen. Some liquids, notably nitrobenzene, also become birefringent when stressed by large electric fields. This phenomena is called the Kerr effect. Electro-optical measurements allow electric field mapping in the dielectric between high voltage stressed electrodes, useful in the study of high voltage conduction and breakdown phenomena. The Kerr effect is also used as a light switch in high-speed shutters. A parallel plate capacitor is placed within a polariscope so that in the absence of voltage no light is transmitted. When the voltage is increased the light is transmitted, being a maximum when $\phi = \pi$. (See problem 17.)

7-5 NORMAL INCIDENCE ONTO A PERFECT CONDUCTOR

A uniform plane wave with x-directed electric field is normally incident upon a perfectly conducting plane at z = 0, as shown in Figure 7-13. The presence of the boundary gives rise to a reflected wave that propagates in the -z direction. There are no fields within the perfect conductor. The known incident fields traveling in the +z direction can be written as

$$\mathbf{E}_{i}(z, t) = \operatorname{Re}\left(\hat{E}_{i} e^{j(\omega t - kz)} \mathbf{i}_{z}\right)$$

$$\mathbf{H}_{i}(z, t) = \operatorname{Re}\left(\frac{\hat{E}_{i}}{\eta_{0}} e^{j(\omega t - kz)} \mathbf{i}_{y}\right)$$
(1)

while the reflected fields propagating in the -z direction are similarly

$$\mathbf{E}_{r}(z, t) = \operatorname{Re}\left(\hat{E}_{r} e^{j(\omega t + kz)} \mathbf{i}_{x}\right)$$
$$\mathbf{H}_{r}(z, t) = \operatorname{Re}\left(\frac{-\hat{E}_{r}}{\eta_{0}} e^{j(\omega t + kz)} \mathbf{i}_{y}\right)$$
(2)

where in the lossless free space

$$\eta_0 = \sqrt{\mu_0/\varepsilon_0}, \qquad k = \omega \sqrt{\varepsilon_0 \mu_0}$$
 (3)

Note the minus sign difference in the spatial exponential phase factors of (1) and (2) as the waves are traveling in opposite directions. The amplitude of incident and reflected magnetic fields are given by the ratio of electric field amplitude to the wave impedance, as derived in Eq. (15) of Section



Figure 7-13 A uniform plane wave normally incident upon a perfect conductor has zero electric field at the conducting surface thus requiring a reflected wave. The source of this reflected wave is the surface current at z = 0, which equals the magnetic field there. The total electric and magnetic fields are 90° out of phase in time and space.

7-3-2. The negative sign in front of the reflected magnetic field for the wave in the -z direction arises because the power flow $S_r = E_r \times H_r$ in the reflected wave must also be in the -z direction.

The total electric and magnetic fields are just the sum of the incident and reflected fields. The only unknown parameter E_r can be evaluated from the boundary condition at z = 0 where the tangential component of **E** must be continuous and thus zero along the perfect conductor:

$$\hat{E}_i + \hat{E}_r = 0 \Rightarrow \hat{E}_r = -\hat{E}_i \tag{4}$$

The total fields are then the sum of the incident and reflected fields

$$\mathbf{E}_{\mathbf{x}}(z, t) = \mathbf{E}_{i}(z, t) + \mathbf{E}_{r}(z, t)$$

$$= \operatorname{Re}\left[\hat{E}_{i}(e^{-jkz} - e^{+jkz}) e^{j\omega t}\right]$$

$$= 2E_{i} \sin kz \sin \omega t$$

$$\mathbf{H}_{y}(z, t) = \mathbf{H}_{i}(z, t) + \mathbf{H}_{r}(z, t)$$

$$= \operatorname{Re}\left(\frac{\hat{E}_{i}}{\eta_{0}}(e^{-jkz} + e^{+jkz}) e^{j\omega t}\right)$$

$$= \frac{2E_{i}}{\eta_{0}} \cos kz \cos \omega t$$
(5)

where we take $\hat{E}_i = E_i$ to be real. The electric and magnetic fields are 90° out of phase with each other both in time and space. We note that the two oppositely traveling wave solutions combined for a standing wave solution. The total solution does not propagate but is a standing sinusoidal solution in space whose amplitude varies sinusoidally in time.

A surface current flows on the perfect conductor at z = 0due to the discontinuity in tangential component of **H**,

$$K_{x} = H_{y}(z=0) = \frac{2E_{i}}{\eta_{0}} \cos \omega t \tag{6}$$

giving rise to a force per unit area on the conductor,

$$\mathbf{F} = \frac{1}{2}\mathbf{K} \times \mu_0 \mathbf{H} = \frac{1}{2}\mu_0 H_y^2 (z=0)\mathbf{i}_z = 2\varepsilon_0 E_i^2 \cos^2 \omega t \mathbf{i}_z \qquad (7)$$

known as the radiation pressure. The factor of $\frac{1}{2}$ arises in (7) because the force on a surface current is proportional to the average value of magnetic field on each side of the interface, here being zero for $z = 0_+$.

7-6 NORMAL INCIDENCE ONTO A DIELECTRIC

7-6-1 Lossless Dielectric

We replace the perfect conductor with a lossless dielectric of permittivity ε_2 and permeability μ_2 , as in Figure 7-14, with a uniform plane wave normally incident from a medium with permittivity ε_1 and permeability μ_1 . In addition to the incident and reflected fields for z < 0, there are transmitted fields which propagate in the +z direction within the medium for z > 0:

$$\mathbf{E}_{i}(z, t) = \operatorname{Re}\left[\hat{E}_{i} e^{j(\omega t - k_{1}z)} \mathbf{i}_{x}\right], \qquad k_{1} = \omega \sqrt{\varepsilon_{1}\mu_{1}}$$

$$\mathbf{H}_{i}(z, t) = \operatorname{Re}\left[\frac{\hat{E}_{i}}{\eta_{1}} e^{j(\omega t - k_{1}z)} \mathbf{i}_{y}\right], \qquad \eta_{1} = \sqrt{\frac{\mu_{1}}{\varepsilon_{1}}}$$

$$\mathbf{E}_{r}(z, t) = \operatorname{Re}\left[\hat{E}_{r} e^{j(\omega t + k_{1}z)} \mathbf{i}_{x}\right] \qquad z < 0$$

$$\mathbf{H}_{r}(z,t) = \operatorname{Re}\left[-\frac{\hat{E}_{r}}{\eta_{1}}e^{j(\omega t + k_{1}z)}\mathbf{i}_{y}\right]$$
(1)

$$\mathbf{E}_{t}(z, t) = \operatorname{Re}\left[\hat{E}_{t} e^{j(\omega t - \mathbf{k}_{2}z)} \mathbf{i}_{z}\right], \qquad \mathbf{k}_{2} = \omega \sqrt{\varepsilon_{2}\mu_{2}} \\ \mathbf{H}_{t}(z, t) = \operatorname{Re}\left[\frac{\hat{E}_{t}}{\eta_{2}} e^{j(\omega t - \mathbf{k}_{2}z)} \mathbf{i}_{y}\right], \qquad \eta_{2} = \sqrt{\frac{\mu_{2}}{\varepsilon_{2}}}$$

It is necessary in (1) to use the appropriate wavenumber and impedance within each region. There is no wave traveling in the -z direction in the second region as we assume no boundaries or sources for z > 0.


Figure 7-14 A uniform plane wave normally incident upon a dielectric interface separating two different materials has part of its power reflected and part transmitted.

The unknown quantities \hat{E}_r and \hat{E}_i can be found from the boundary conditions of continuity of tangential **E** and **H** at z = 0,

$$\frac{\hat{E}_i + \hat{E}_r}{\eta_1} = \frac{\hat{E}_i}{\eta_2}$$
(2)

from which we find the reflection R and transmission T field coefficients as

 $R = \frac{\hat{E}_{r}}{\hat{E}_{i}} = \frac{\eta_{2} - \eta_{1}}{\eta_{2} + \eta_{1}}$ $T = \frac{\hat{E}_{i}}{\hat{E}_{i}} = \frac{2\eta_{2}}{\eta_{2} + \eta_{1}}$ (3)

where from (2)

$$1 + R = T \tag{4}$$

If both mediums have the same wave impedance, $\eta_1 = \eta_2$, there is no reflected wave.

7-6-2 Time-Average Power Flow

The time-average power flow in the region
$$z < 0$$
 is
 $=\frac{1}{2}\operatorname{Re}\left[\hat{E}_{z}(z)\hat{H}_{y}^{*}(z)\right]$
 $=\frac{1}{2\eta_{1}}\operatorname{Re}\left[\hat{E}_{i}e^{-jk_{1}z}+\hat{E}_{r}e^{+jk_{1}z}\right]\left[\hat{E}_{i}^{*}e^{+jk_{1}z}-\hat{E}_{r}^{*}e^{-jk_{1}z}\right]$
 $=\frac{1}{2\eta_{1}}\left[|\hat{E}_{i}|^{2}-|\hat{E}_{r}|^{2}\right]$
 $+\frac{1}{2\eta_{1}}\underbrace{\operatorname{Re}\left[\hat{E}_{r}\hat{E}_{i}^{*}e^{+2jk_{1}z}-\hat{E}_{r}^{*}\hat{E}_{i}e^{-2jk_{1}z}\right]}_{0}$
(5)

The last term on the right-hand side of (5) is zero as it is the difference between a number and its complex conjugate, which is pure imaginary and equals 2j times its imaginary part. Being pure imaginary, its real part is zero. Thus the time-average power flow just equals the difference in the power flows in the incident and reflected waves as found more generally in Section 7-3-2. The coupling terms between oppositely traveling waves have no time-average yielding the simple superposition of time-average powers:

$$< S_{xi} > = \frac{1}{2\eta_1} [|\hat{E}_i|^2 - |\hat{E}_r|^2] = \frac{|\hat{E}_i|^2}{2\eta_1} [1 - R^2]$$
(6)

This net time-average power flows into the dielectric medium, as it also equals the transmitted power;

$$\langle S_{tt} \rangle = \frac{1}{2\eta_2} |\hat{E}_t|^2 = \frac{|\hat{E}_i|^2 T^2}{2\eta_2} = \frac{|\hat{E}_i|^2}{2\eta_1} [1 - R^2]$$
(7)

7-6-3 Lossy Dielectric

If medium 2 is lossy with Ohmic conductivity σ , the solutions of (3) are still correct if we replace the permittivity ε_2 by the complex permittivity $\hat{\varepsilon}_2$,

$$\hat{\varepsilon}_2 = \varepsilon_2 \left(1 + \frac{\sigma}{j\omega\varepsilon_2} \right) \tag{8}$$

so that the wave impedance in region 2 is complex:

$$\eta_2 = \sqrt{\mu_2/\hat{\varepsilon}_2} \tag{9}$$

We can easily explore the effect of losses in the low and large loss limits.

(a) Low Losses

If the Ohmic conductivity is small, we can neglect it in all terms except in the wavenumber k_2 :

$$\lim_{\nu/\omega\varepsilon_2\ll 1} k_2 \approx \omega \sqrt{\varepsilon_2 \mu_2} - \frac{j}{2} \sigma \sqrt{\frac{\mu_2}{\varepsilon_2}}$$
(10)

The imaginary part of k_2 gives rise to a small rate of exponential decay in medium 2 as the wave propagates away from the z = 0 boundary.

(b) Large Losses

For large conductivities so that the displacement current is negligible in medium 2, the wavenumber and impedance in region 2 are complex:

$$\lim_{\sigma/\omega\varepsilon_{2}\gg1}\begin{cases} k_{2} = \frac{1-j}{\delta}, & \delta = \sqrt{\frac{2}{\omega\mu_{2}\sigma}}\\ \eta_{2} = \sqrt{\frac{j\omega\mu_{2}}{\sigma}} = \frac{1+j}{\sigma\delta} \end{cases}$$
(11)

The fields decay within a characteristic distance equal to the skin depth δ . This is why communications to submerged submarines are difficult. For seawater, $\mu_2 = \mu_0 = 4\pi \times 10^{-7}$ henry/m and $\sigma \approx 4$ siemens/m so that for 1 MHz signals, $\delta \approx 0.25$ m. However, at 100 Hz the skin depth increases to 25 meters. If a submarine is within this distance from the surface, it can receive the signals. However, it is difficult to transmit these low frequencies because of the large free space wavelength, $\lambda \approx 3 \times 10^{6}$ m. Note that as the conductivity approaches infinity,

$$\lim_{\sigma \to \infty} \begin{cases} k_2 = \infty \\ \eta_2 = 0 \end{cases} \Rightarrow \begin{cases} R = -1 \\ T = 0 \end{cases}$$
(12)

so that the field solution approaches that of normal incidence upon a perfect conductor found in Section 7-5.

EXAMPLE 7-1 DIELECTRIC COATING

A thin lossless dielectric with permittivity ε and permeability μ is coated onto the interface between two infinite halfspaces of lossless media with respective properties (ε_1 , μ_1) and (ε_2 , μ_2), as shown in Figure 7-15. What coating parameters ε and μ and thickness d will allow all the time-average power



measured within the coating

Figure 7-15 A suitable dielectric coating applied on the interface of discontinuity between differing media can eliminate reflections at a given frequency.

from region 1 to be transmitted through the coating to region 2? Such coatings are applied to optical components such as lenses to minimize unwanted reflections and to maximize the transmitted light intensity.

SOLUTION

For all the incident power to be transmitted into region 2, there can be no reflected field in region 1, although we do have oppositely traveling waves in the coating due to the reflection at the second interface. Region 2 only has positively z-directed power flow. The fields in each region are thus of the following form:

Region 1

$$\mathbf{E}_{1} = \operatorname{Re}\left[\hat{E}_{1} e^{j(\omega t - k_{1}z)} \mathbf{i}_{x}\right], \qquad k_{1} = \omega/c_{1} = \omega\sqrt{\varepsilon_{1}\mu_{1}}$$
$$\mathbf{H}_{1} = \operatorname{Re}\left[\frac{\hat{E}_{1}}{\eta_{1}} e^{j(\omega t - k_{1}z)} \mathbf{i}_{y}\right], \qquad \eta_{1} = \sqrt{\frac{\mu_{1}}{\varepsilon_{1}}}$$

Coating

$$E_{+} = \operatorname{Re} \left[\hat{E}_{+} e^{i(\omega t - kz)} \mathbf{i}_{x} \right], \qquad k = \omega/c = \omega \sqrt{\varepsilon \mu}$$

$$H_{+} = \operatorname{Re} \left[\frac{\hat{E}_{+}}{\eta} e^{i(\omega t - kz)} \mathbf{i}_{y} \right], \qquad \eta = \sqrt{\frac{\mu}{\varepsilon}}$$

$$E_{-} = \operatorname{Re} \left[\hat{E}_{-} e^{i(\omega t + kz)} \mathbf{i}_{x} \right]$$

$$H_{-} = \operatorname{Re} \left[-\frac{\hat{E}_{-}}{\eta} e^{i(\omega t + kz)} \mathbf{i}_{y} \right]$$

Region 2

$$\mathbf{E}_{2} = \operatorname{Re} \left[\hat{E}_{2} e^{j(\omega t - \mathbf{k}_{2} \mathbf{z})} \mathbf{i}_{x} \right], \qquad \mathbf{k}_{2} = \omega/c_{2} = \omega \sqrt{\varepsilon_{2} \mu_{2}}$$
$$\mathbf{H}_{2} = \operatorname{Re} \left[\frac{\hat{E}_{2}}{\eta_{2}} e^{j(\omega t - \mathbf{k}_{2} \mathbf{z})} \mathbf{i}_{y} \right], \qquad \eta_{2} = \sqrt{\frac{\mu_{2}}{\varepsilon_{2}}}$$

Continuity of tangential **E** and **H** at z = 0 and z = d requires

$$\hat{E}_{1} = \hat{E}_{+} + \hat{E}_{-}, \qquad \frac{\hat{E}_{1}}{\eta_{1}} = \frac{\hat{E}_{+} - \hat{E}_{-}}{\eta} \\
\hat{E}_{+} e^{-jkd} + \hat{E}_{-} e^{+jkd} = \hat{E}_{2} e^{-jk_{2}d} \\
\frac{\hat{E}_{+} e^{-jkd} - \hat{E}_{-} e^{+jkd}}{\eta} = \frac{\hat{E}_{2} e^{-jk_{2}d}}{\eta_{2}}$$

Each of these amplitudes in terms of \hat{E}_1 is then

$$\hat{E}_{+} = \frac{1}{2} \left(1 + \frac{\eta}{\eta_{1}} \right) \hat{E}_{1}$$

$$\hat{E}_{-} = \frac{1}{2} \left(1 - \frac{\eta}{\eta_{1}} \right) \hat{E}_{1}$$

$$\hat{E}_{2} = e^{jk_{2}d} [\hat{E}_{+} e^{-jkd} + \hat{E}_{-} e^{+jkd}]$$

$$= \frac{\eta_{2}}{\eta} e^{jk_{2}d} [\hat{E}_{+} e^{-jkd} - \hat{E}_{-} e^{+jkd}]$$

Solving this last relation self-consistently requires that

$$\hat{E}_{+} e^{-jkd} \left(1 - \frac{\eta_{2}}{\eta}\right) + \hat{E}_{-} e^{jkd} \left(1 + \frac{\eta_{2}}{\eta}\right) = 0$$

Writing \hat{E}_+ and \hat{E}_- in terms of \hat{E}_1 yields

$$\left(1+\frac{\eta}{\eta_1}\right)\left(1-\frac{\eta_2}{\eta}\right)+e^{2jkd}\left(1+\frac{\eta_2}{\eta}\right)\left(1-\frac{\eta}{\eta_1}\right)=0$$

Since this relation is complex, the real and imaginary parts must separately be satisfied. For the imaginary part to be zero requires that the coating thickness d be an integral number of

quarter wavelengths as measured within the coating,

$$2kd = n\pi \Rightarrow d = n\lambda/4, \qquad n = 1, 2, 3, \ldots$$

The real part then requires

$$\left(1+\frac{\eta}{\eta_1}\right)\left(1-\frac{\eta_2}{\eta}\right) \pm \left(1+\frac{\eta_2}{\eta}\right)\left(1-\frac{\eta}{\eta_1}\right) = 0 \begin{cases} n \text{ even} \\ n \text{ odd} \end{cases}$$

For the upper sign where d is a multiple of half-wavelengths the only solution is

$$\eta_2 = \eta_1$$
 $(d = n\lambda/4, n = 2, 4, 6, ...)$

which requires that media 1 and 2 be the same so that the coating serves no purpose. If regions 1 and 2 have differing wave impedances, we must use the lower sign where d is an odd integer number of quarter wavelengths so that

$$\eta^2 = \eta_1 \eta_2 \Rightarrow \eta = \sqrt{\eta_1 \eta_2} \quad (d = n\lambda/4, \quad n = 1, 3, 5, \ldots)$$

Thus, if the coating is a quarter wavelength thick as measured within the coating, or any odd integer multiple of this thickness with its wave impedance equal to the geometrical average of the impedances in each adjacent region, all the timeaverage power flow in region 1 passes through the coating into region 2:

$$= \frac{1}{2} \frac{|\hat{E}_{1}|^{2}}{\eta_{1}} = \frac{1}{2} \frac{|\hat{E}_{2}|^{2}}{\eta_{2}}$$
$$= \frac{1}{2} \operatorname{Re} \left[(\hat{E}_{+} e^{-jkz} + \hat{E}_{-} e^{+jkz}) \frac{(\hat{E}_{+}^{*} e^{+jkz} - \hat{E}_{-}^{*} e^{-jkz})}{\eta} \right]$$
$$= \frac{1}{2\eta} (|\hat{E}_{+}|^{2} - |\hat{E}_{-}|^{2})$$

Note that for a given coating thickness d, there is no reflection only at select frequencies corresponding to wavelengths $d = n\lambda/4$, $n = 1, 3, 5, \ldots$ For a narrow band of wavelengths about these select wavelengths, reflections are small. The magnetic permeability of coatings and of the glass used in optical components are usually that of free space while the permittivities differ. The permittivity of the coating ε is then picked so that

$$\varepsilon = \sqrt{\varepsilon_2 \varepsilon_0}$$

and with a thickness corresponding to the central range of the wavelengths of interest (often in the visible).

7-7 UNIFORM AND NONUNIFORM PLANE WAVES

Our analysis thus far has been limited to waves propagating in the z direction normally incident upon plane interfaces. Although our examples had the electric field polarized in the x direction, the solution procedure is the same for the ydirected electric field polarization as both polarizations are parallel to the interfaces of discontinuity.

7-7-1 Propagation at an Arbitrary Angle

We now consider a uniform plane wave with power flow at an angle θ to the z axis, as shown in Figure 7-16. The electric field is assumed to be y directed, but the magnetic field that is perpendicular to both **E** and **S** now has components in the x and z directions.

The direction of the power flow, which we can call z', is related to the Cartesian coordinates as

$$z' = x \sin \theta + z \cos \theta \tag{1}$$

so that the phase factor kz' can be written as

$$kz' = k_x x + k_z z, \qquad k_x = k \sin \theta$$

$$k_z = k \cos \theta \qquad (2)$$

where the wavenumber magnitude is

$$\boldsymbol{k} = \boldsymbol{\omega} \sqrt{\boldsymbol{\varepsilon} \boldsymbol{\mu}} \tag{3}$$



Figure 7-16 The spatial dependence of a uniform plane wave at an arbitrary angle θ can be expressed in terms of a vector wavenumber **k** as $e^{-i\mathbf{k}\cdot\mathbf{r}}$, where **k** is in the direction of power flow and has magnitude ω/c .

This allows us to write the fields as

$$\mathbf{E} = \operatorname{Re}\left[\hat{E} e^{j(\omega t - k_{x} x - k_{z} x)} \mathbf{i}_{y}\right]$$

$$\mathbf{H} = \operatorname{Re}\left[\frac{\hat{E}}{\eta}(-\cos\theta \mathbf{i}_{x} + \sin\theta \mathbf{i}_{z}) e^{j(\omega t - k_{x} x - k_{z} x)}\right]$$
(4)

We note that the spatial dependence of the fields can be written as $e^{-j\mathbf{k}\cdot\mathbf{r}}$, where the wavenumber is treated as a vector:

$$\mathbf{k} = k_x \mathbf{i}_x + k_y \mathbf{i}_y + k_z \mathbf{i}_z \tag{5}$$

with

$$\mathbf{r} = x\mathbf{i}_x + y\mathbf{i}_y + z\mathbf{i}_z \tag{6}$$

so that

$$\mathbf{k} \cdot \mathbf{r} = k_x \mathbf{x} + k_y \mathbf{y} + k_z z \tag{7}$$

The magnitude of \mathbf{k} is as given in (3) and its direction is the same as the power flow S:

$$\mathbf{S} = \mathbf{E} \times \mathbf{H} = \frac{|\hat{E}|^2}{\eta} (\cos \theta \mathbf{i}_z + \sin \theta \mathbf{i}_z) \cos^2 (\omega t - \mathbf{k} \cdot \mathbf{r})$$
$$= \frac{|\hat{E}|^2 \mathbf{k}}{\omega \mu} \cos^2 (\omega t - \mathbf{k} \cdot \mathbf{r})$$
(8)

where without loss of generality we picked the phase of \hat{E} to be zero so that it is real.

7-7-2 The Complex Propagation Constant

Let us generalize further by considering fields of the form

$$\mathbf{E} = \operatorname{Re} \left[\hat{\mathbf{E}} e^{j\omega t} e^{-\mathbf{\gamma} \cdot \mathbf{r}} \right] = \operatorname{Re} \left[\hat{\mathbf{E}} e^{j(\omega t - \mathbf{k} \cdot \mathbf{r})} e^{-\alpha \cdot \mathbf{r}} \right]$$

$$\mathbf{H} = \operatorname{Re} \left[\hat{\mathbf{H}} e^{j\omega t} e^{-\mathbf{\gamma} \cdot \mathbf{r}} \right] = \operatorname{Re} \left[\hat{\mathbf{H}} e^{j(\omega t - \mathbf{k} \cdot \mathbf{r})} e^{-\alpha \cdot \mathbf{r}} \right]$$
(9)

where γ is the complex propagation vector and **r** is the position vector of (6):

$$\boldsymbol{\gamma} = \boldsymbol{\alpha} + j\mathbf{k} = \gamma_x \mathbf{i}_x + \gamma_y \mathbf{i}_y + \gamma_z \mathbf{i}_z$$

$$\boldsymbol{\gamma} \cdot \mathbf{r} = \gamma_x x + \gamma_y \mathbf{y} + \gamma_z z$$
(10)

We have previously considered uniform plane waves in lossless media where the wavenumber **k** is pure real and z directed with $\alpha = 0$ so that γ is pure imaginary. The parameter α represents the decay rate of the fields even though the medium is lossless. If α is nonzero, the solutions are called nonuniform plane waves. We saw this decay in our quasi-static solutions of Laplace's equation where solutions had oscillations in one direction but decay in the perpendicular direction. We would expect this evanescence to remain at low frequencies. The value of the assumed form of solutions in (9) is that the del (∇) operator in Maxwell's equations can be replaced by the vector operator $-\gamma$:

$$\nabla = \frac{\partial}{\partial x} \mathbf{i}_{x} + \frac{\partial}{\partial y} \mathbf{i}_{y} + \frac{\partial}{\partial z} \mathbf{i}_{z}$$
$$= -\gamma_{x} \mathbf{i}_{x} - \gamma_{y} \mathbf{i}_{y} - \gamma_{z} \mathbf{i}_{z}$$
$$= -\gamma \qquad (11)$$

This is true because any spatial derivatives only operate on the exponential term in (9). Then the source free Maxwell's equations can be written in terms of the complex amplitudes as

$$-\gamma \times \hat{\mathbf{E}} = -j\omega\mu \hat{\mathbf{H}}$$
$$-\gamma \times \hat{\mathbf{H}} = j\omega\varepsilon \hat{\mathbf{E}}$$
$$-\gamma \cdot \varepsilon \hat{\mathbf{E}} = 0$$
$$-\gamma \cdot \mu \hat{\mathbf{H}} = 0$$
(12)

The last two relations tell us that γ is perpendicular to both **E** and **H**. If we take $\gamma \times$ the top equation and use the second equation, we have

$$-\mathbf{\gamma} \times (\mathbf{\gamma} \times \hat{\mathbf{E}}) = -j\omega\mu \left(\mathbf{\gamma} \times \hat{\mathbf{H}}\right) = -j\omega\mu \left(-j\omega\varepsilon\,\hat{\mathbf{E}}\right)$$
$$= -\omega^2\mu\varepsilon\,\hat{\mathbf{E}} \tag{13}$$

The double cross product can be expanded as

$$-\mathbf{\gamma} \times (\mathbf{\gamma} \times \hat{\mathbf{E}}) = -\mathbf{\gamma} (\mathbf{\gamma} \cdot \hat{\mathbf{E}}) + (\mathbf{\gamma} \cdot \mathbf{\gamma}) \hat{\mathbf{E}}$$
$$= (\mathbf{\gamma} \cdot \mathbf{\gamma}) \hat{\mathbf{E}} = -\omega^2 \mu \varepsilon \hat{\mathbf{E}}$$
(14)

The $\gamma \cdot \hat{E}$ term is zero from the third relation in (12). The dispersion relation is then

$$\boldsymbol{\gamma} \cdot \boldsymbol{\gamma} = (\boldsymbol{\alpha}^2 - \boldsymbol{k}^2 + 2\boldsymbol{j}\boldsymbol{\alpha} \cdot \boldsymbol{k}) = -\boldsymbol{\omega}^2 \boldsymbol{\mu}\boldsymbol{\varepsilon}$$
(15)

For solution, the real and imaginary parts of (15) must be separately equal:

$$\alpha^2 - k^2 = -\omega^2 \mu \varepsilon$$

$$\alpha \cdot \mathbf{k} = 0$$
 (16)

When $\alpha = 0$, (16) reduces to the familiar frequencywavenumber relation of Section 7-3.4.

The last relation now tells us that evanescence (decay) in space as represented by α is allowed by Maxwell's equations, but must be perpendicular to propagation represented by **k**.

We can compute the time-average power flow for fields of the form of (9) using (12) in terms of either $\hat{\mathbf{E}}$ or $\hat{\mathbf{H}}$ as follows:

$$~~= \frac{1}{2} \operatorname{Re} \left(\hat{\mathbf{E}} \times \hat{\mathbf{H}}^{*} \right),~~$$

$$= -\frac{1}{2} \operatorname{Re} \left(\hat{\mathbf{E}} \times \frac{(\boldsymbol{\gamma}^{*} \times \hat{\mathbf{E}}^{*})}{j\omega\mu} \right),$$

$$= -\frac{1}{2} \operatorname{Re} \left(\frac{\boldsymbol{\gamma}^{*} |\hat{\mathbf{E}}|^{2} - \hat{\mathbf{E}}^{*} (\boldsymbol{\gamma}^{*} \cdot \hat{\mathbf{E}})}{j\omega\mu} \right),$$

$$= \frac{1}{2} \operatorname{Re} \left(\frac{\boldsymbol{\gamma}^{*} |\hat{\mathbf{E}}|^{2} + \frac{1}{2} \operatorname{Re} \left(\frac{\hat{\mathbf{E}}^{*} (\boldsymbol{\gamma}^{*} \cdot \hat{\mathbf{E}})}{j\omega\mu} \right),$$

$$~~= \frac{1}{2} \operatorname{Re} \left(\hat{\mathbf{E}} \times \hat{\mathbf{H}}^{*} \right)~~$$

$$= -\frac{1}{2} \operatorname{Re} \left(\frac{(\boldsymbol{\gamma} \times \hat{\mathbf{H}})}{j\omega\varepsilon} \times \hat{\mathbf{H}}^{*} \right)$$

$$= \frac{1}{2} \operatorname{Re} \left(\frac{\boldsymbol{\gamma} |\hat{\mathbf{H}}|^{2} - \hat{\mathbf{H}} (\boldsymbol{\gamma} \cdot \hat{\mathbf{H}}^{*})}{j\omega\varepsilon} \right)$$

$$= \frac{1}{2} \frac{\mathbf{k}}{\omega\varepsilon} |\hat{\mathbf{H}}|^{2} - \frac{1}{2} \operatorname{Re} \left(\frac{\hat{\mathbf{H}} (\boldsymbol{\gamma} \cdot \hat{\mathbf{H}}^{*})}{j\omega\varepsilon} \right)$$

Although both final expressions in (17) are equivalent, it is convenient to write the power flow in terms of either $\hat{\mathbf{E}}$ or $\hat{\mathbf{H}}$. When $\hat{\mathbf{E}}$ is perpendicular to both the real vectors $\boldsymbol{\alpha}$ and $\boldsymbol{\beta}$, defined in (10) and (16), the dot product $\boldsymbol{\gamma}^* \cdot \hat{\mathbf{E}}$ is zero. Such a mode is called transverse electric (TE), and we see in (17) that the time-average power flow is still in the direction of the wavenumber \mathbf{k} . Similarly, when \mathbf{H} is perpendicular to $\boldsymbol{\alpha}$ and $\boldsymbol{\beta}$, the dot product $\boldsymbol{\gamma} \cdot \hat{\mathbf{H}}^*$ is zero and we have a transverse magnetic (TM) mode. Again, the time-average power flow in (17) is in the direction of \mathbf{k} . The magnitude of \mathbf{k} is related to $\boldsymbol{\omega}$ in (16).

Note that our discussion has been limited to lossless systems. We can include Ohmic losses if we replace ε by the complex permittivity $\hat{\varepsilon}$ of Section 7-4-3 in (15) and (17). Then, there is always decay ($\alpha \neq 0$) because of Ohmic dissipation (see Problem 22).

7-7-3 Nonuniform Plane Waves

We can examine nonuniform plane wave solutions with nonzero α by considering a current sheet in the z = 0 plane, which is a traveling wave in the x direction:

$$K_{x}(z=0) = K_{0}\cos(\omega t - k_{x}x) = \operatorname{Re}(K_{0}e^{j(\omega t - k_{x}x)})$$
(18)

The x-directed surface current gives rise to a y-directed magnetic field. Because the system does not depend on the y coordinate, solutions are thus of the following form:

$$H_{y} = \begin{cases} \operatorname{Re} \left(\hat{H}_{1} e^{j\omega t} e^{-\gamma_{1} \cdot \mathbf{r}} \right), & z > 0 \\ \operatorname{Re} \left(\hat{H}_{2} e^{j\omega t} e^{-\gamma_{2} \cdot \mathbf{r}} \right), & z < 0 \end{cases}$$

$$\mathbf{E} = \begin{cases} \operatorname{Re} \left[-\frac{\gamma_{1} \times \hat{H}_{1}}{j\omega \varepsilon} \mathbf{i}, e^{j\omega t} e^{-\gamma_{1} \cdot \mathbf{r}} \right], & z > 0 \\ \operatorname{Re} \left[-\frac{\gamma_{2} \times \hat{H}_{2}}{j\omega \varepsilon} \mathbf{i}, e^{j\omega t} e^{-\gamma_{2} \cdot \mathbf{r}} \right], & z < 0 \end{cases}$$

$$(19)$$

where γ_1 and γ_2 are the complex propagation vectors on each side of the current sheet:

$$\begin{aligned} \mathbf{\gamma}_1 &= \mathbf{\gamma}_{1x} \mathbf{i}_x + \mathbf{\gamma}_{1z} \mathbf{i}_z \\ \mathbf{\gamma}_2 &= \mathbf{\gamma}_{2x} \mathbf{i}_x + \mathbf{\gamma}_{2x} \mathbf{i}_z \end{aligned} \tag{20}$$

The boundary condition of the discontinuity of tangential H at z = 0 equaling the surface current yields

$$-\hat{H}_1 e^{-\gamma_{1x}x} + \hat{H}_2 e^{-\gamma_{2x}x} = K_0 e^{-jk_xx}$$
(21)

which tells us that the x components of the complex propagation vectors equal the trigonometric spatial dependence of the surface current:

$$\boldsymbol{\gamma}_{1x} = \boldsymbol{\gamma}_{2x} = j\boldsymbol{k}_x \tag{22}$$

The z components of γ_1 and γ_2 are then determined from (15) as

$$\gamma_x^2 + \gamma_z^2 = -\omega^2 \varepsilon \mu \Rightarrow \gamma_z = \pm (k_x^2 - \omega^2 \varepsilon \mu)^{1/2}$$
(23)

If $k_x^2 < \omega^2 \varepsilon \mu$, γ_z is pure imaginary representing propagation and we have uniform plane waves. If $k_x^2 > \omega^2 \varepsilon \mu$, then γ_z is pure real representing evanescence in the z direction so that we generate nonuniform plane waves. When $\omega = 0$, (23) corresponds to Laplacian solutions that oscillate in the x direction but decay in the z direction.

The z component of γ is of opposite sign in each region,

$$\gamma_{1z} = -\gamma_{2z} = +(k_x^2 - \omega^2 \varepsilon \mu)^{1/2}$$
(24)

as the waves propagate or decay away from the sheet. Continuity of the tangential component of E requires

$$\gamma_{1z}\hat{H}_1 = \gamma_{2z}\hat{H}_2 \Rightarrow \hat{H}_2 = -\hat{H}_1 = K_0/2$$
 (25)

If $k_x = 0$, we re-obtain the solution of Section 7-4-1. Increasing k_x generates propagating waves with power flow in the $k_x i_x \pm k_z i_z$ directions. At $k_x^2 = \omega^2 \epsilon \mu$, $k_z = 0$ so that the power flow is purely x directed with no spatial dependence on z. Further increasing k_x converts k_z to α_z as γ_z becomes real and the fields decay with z.

7-8 OBLIQUE INCIDENCE ONTO A PERFECT CONDUCTOR

7-8-1 E Field Parallel to the Interface

In Figure 7-17*a* we show a uniform plane wave incident upon a perfect conductor with power flow at an angle θ_i to the normal. The electric field is parallel to the surface with the magnetic field having both x and z components:

$$\mathbf{E}_{i} = \operatorname{Re}\left[\hat{E}_{i} e^{j(\omega t - k_{xi}x - k_{xi}z)}\mathbf{i}_{y}\right]$$

$$\mathbf{H}_{i} = \operatorname{Re}\left[\frac{\hat{E}_{i}}{\eta}(-\cos\theta_{i}\mathbf{i}_{x} + \sin\theta_{i}\mathbf{i}_{z}) e^{j(\omega t - k_{xi}x - k_{xi}z)}\right]$$
(1)

where

$$\begin{array}{l} k_{xi} = k \; \sin \theta_i \\ k_{zi} = k \; \cos \theta_i \end{array} \} \qquad k = \omega \sqrt{\varepsilon \mu} \; , \quad \eta \; = \; \sqrt{\frac{\mu}{\varepsilon}} \qquad (2)$$



Figure 7-17 A uniform plane wave obliquely incident upon a perfect conductor has its angle of incidence equal to the angle of reflection. (a) Electric field polarized parallel to the interface. (b) Magnetic field parallel to the interface.

There are no transmitted fields within the perfect conductor, but there is a reflected field with power flow at angle θ_r from the interface normal. The reflected electric field is also in the y direction so the magnetic field, which must be perpendicular to both **E** and $S=E\times H$, is in the direction shown in Figure 7-17*a*:

$$\mathbf{E}_{r} = \operatorname{Re}\left[\hat{E}_{r} e^{j(\omega t - \mathbf{k}_{w}x + \mathbf{k}_{x}z^{2})} \mathbf{i}_{y}\right]$$

$$\mathbf{H}_{r} = \operatorname{Re}\left[\frac{\hat{E}_{r}}{\eta}(\cos\theta_{r}\mathbf{i}_{x} + \sin\theta_{r}\mathbf{i}_{z}) e^{j(\omega t - \mathbf{k}_{w}x + \mathbf{k}_{x}z)}\right]$$
(3)

where the reflected wavenumbers are

$$k_{xr} = k \sin \theta_r$$

$$k_{xr} = k \cos \theta_r$$
(4)

At this point we do not know the angle of reflection θ_r or the reflected amplitude \hat{E}_r . They will be determined from the boundary conditions at z = 0 of continuity of tangential **E** and normal **B**. Because there are no fields within the perfect conductor these boundary conditions at z = 0 are

$$\hat{E}_i e^{-jk_{xi}x} + \hat{E}_r e^{-jk_{xr}x} = 0$$

$$\frac{\mu}{\eta} (\hat{E}_i \sin \theta_i e^{-jk_{xi}x} + \hat{E}_r \sin \theta_r e^{-jk_{xr}x}) = 0$$
(5)

These conditions must be true for every value of x along z = 0 so that the phase factors given in (2) and (4) must be equal,

$$k_{xi} = k_{xr} \Rightarrow \theta_i = \theta_r \equiv \theta \tag{6}$$

giving the well-known rule that the angle of incidence equals the angle of reflection. The reflected field amplitude is then

$$\hat{E}_r = -\hat{E}_i \tag{7}$$

with the boundary conditions in (5) being redundant as they both yield (7). The total fields are then:

$$E_{y} = \operatorname{Re} \left[\hat{E}_{i} (e^{-jk_{x}z} - e^{+jk_{x}z}) e^{j(\omega t - k_{x}x)} \right]$$

$$= 2E_{i} \sin k_{z} z \sin (\omega t - k_{x}x)$$

$$\mathbf{H} = \operatorname{Re} \left[\frac{\hat{E}_{i}}{\eta} \left[\cos \theta (-e^{-jk_{x}z} - e^{+jk_{x}z}) \mathbf{i}_{x} + \sin \theta (e^{-jk_{x}z} - e^{+jk_{x}z}) \mathbf{i}_{z} \right] e^{j(\omega t - k_{x}x)} \right]$$

$$= \frac{2E_{i}}{\eta} \left[-\cos \theta \cos k_{z} z \cos (\omega t - k_{x}x) \mathbf{i}_{x} + \sin \theta \sin k_{z} z \sin (\omega t - k_{x}x) \mathbf{i}_{z} \right]$$
(8)

where without loss of generality we take \hat{E}_i to be real.

We drop the i and r subscripts on the wavenumbers and angles because they are equal. The fields travel in the xdirection parallel to the interface, but are stationary in the zdirection. Note that another perfectly conducting plane can be placed at distances d to the left of the interface at

$$k_z d = n\pi \tag{9}$$

where the electric field is already zero without disturbing the solutions of (8). The boundary conditions at the second conductor are automatically satisfied. Such a structure is called a waveguide and is discussed in Section 8-6.

Because the tangential component of **H** is discontinuous at z = 0, a traveling wave surface current flows along the interface.

$$K_{y} = -H_{x}(z=0) = \frac{2E_{i}}{\eta} \cos \theta \cos (\omega t - k_{x}x)$$
(10)

From (8) we compute the time-average power flow as

$$< \mathbf{S} > = \frac{1}{2} \operatorname{Re} \left[\hat{\mathbf{E}}(\mathbf{x}, z) \times \hat{\mathbf{H}}^{*}(\mathbf{x}, z) \right]$$
$$= \frac{2E_{i}^{2}}{\eta} \sin \theta \sin^{2} \mathbf{k}_{z} \mathbf{i}_{x} \qquad (11)$$

.

We see that the only nonzero power flow is in the direction parallel to the interfacial boundary and it varies as a function of z.

7-8-2 H Field Parallel to the Interface

If the H field is parallel to the conducting boundary, as in Figure 7-17b, the incident and reflected fields are as follows:

$$\mathbf{E}_{i} = \operatorname{Re}\left[\hat{E}_{i}\left(\cos\theta_{i}\mathbf{i}_{x}-\sin\theta_{i}\mathbf{i}_{z}\right)e^{j(\omega t-k_{xi}x-k_{xi}z)}\right]$$

$$\mathbf{H}_{i} = \operatorname{Re}\left[\frac{\hat{E}_{i}}{\eta}e^{j(\omega t-k_{xi}x-k_{xi}z)}\mathbf{i}_{y}\right]$$

$$\mathbf{E}_{r} = \operatorname{Re}\left[\hat{E}_{r}\left(-\cos\theta_{r}\mathbf{i}_{x}-\sin\theta_{r}\mathbf{i}_{z}\right)e^{j(\omega t-k_{xr}x+k_{xr}z)}\right]$$

$$\mathbf{H}_{r} = \operatorname{Re}\left[\frac{\hat{E}_{r}}{\eta}e^{j(\omega t-k_{xr}x+k_{xr}z)}\mathbf{i}_{y}\right]$$
(12)

The tangential component of E is continuous and thus zero at z = 0:

$$\hat{E}_i \cos \theta_i \, e^{-jk_{xi}x} - \hat{E}_r \cos \theta_r \, e^{-jk_{xr}x} = 0 \tag{13}$$

There is no normal component of **B**. This boundary condition must be satisfied for all values of x so again the angle of incidence must equal the angle of reflection $(\theta_i = \theta_r)$ so that

$$\hat{E}_i = \hat{E}_r \tag{14}$$

The total **E** and **H** fields can be obtained from (12) by adding the incident and reflected fields and taking the real part;

$$\mathbf{E} = \operatorname{Re} \left\{ \hat{E}_{i} \left[\cos \theta \left(e^{-jk_{x}z} - e^{+jk_{z}z} \right) \mathbf{i}_{x} - \sin \theta \left(e^{-jk_{x}z} + e^{+jk_{x}z} \right) \mathbf{i}_{z} \right] e^{j(\omega t - k_{x}x)} \right\}$$

$$= 2E_{i} \left\{ \cos \theta \sin k_{z}z \sin (\omega t - k_{x}x) \mathbf{i}_{x} - \sin \theta \cos k_{z}z \cos (\omega t - k_{x}x) \mathbf{i}_{z} \right\}$$

$$\mathbf{H} = \operatorname{Re} \left[\frac{\hat{E}_{i}}{\eta} \left(e^{-jk_{x}z} + e^{+jk_{x}z} \right) e^{j(\omega t - k_{x}x)} \mathbf{i}_{y} \right]$$

$$= \frac{2E_{i}}{\eta} \cos k_{z}z \cos (\omega t - k_{x}x) \mathbf{i}_{y}$$
(15)

The surface current on the conducting surface at z = 0 is given by the tangential component of **H**

$$K_{x}(z=0) = H_{y}(z=0) = \frac{2E_{i}}{\eta} \cos(\omega t - k_{x}x)$$
(16)

while the surface charge at z = 0 is proportional to the normal component of electric field,

$$\sigma_f(z=0) = -\varepsilon E_z(z=0) = 2\varepsilon E_i \sin \theta \cos (\omega t - k_x x) \quad (17)$$

Note that (16) and (17) satisfy conservation of current on the conducting surface,

$$\nabla_{\Sigma} \cdot \mathbf{K} + \frac{\partial \sigma_f}{\partial t} = 0 \Rightarrow \frac{\partial K_x}{\partial x} + \frac{\partial \sigma_f}{\partial t} = 0$$
(18)

where

$$\nabla_{\Sigma} = \frac{\partial}{\partial x} \mathbf{i}_{x} + \frac{\partial}{\partial y} \mathbf{i},$$

is the surface divergence operator. The time-average power flow for this polarization is also x directed:

$$< \mathbf{S} > = \frac{1}{2} \operatorname{Re} \left(\hat{\mathbf{E}} \times \hat{\mathbf{H}}^* \right)$$
$$= \frac{2E_i^2}{\eta} \sin \theta \cos^2 k_z z \mathbf{i}_x \tag{19}$$

7-9 OBLIQUE INCIDENCE ONTO A DIELECTRIC

7-9-1 E Parallel to the Interface

A plane wave incident upon a dielectric interface, as in Figure 7-18*a*, now has transmitted fields as well as reflected fields. For the electric field polarized parallel to the interface, the fields in each region can be expressed as

$$\mathbf{E}_{i} = \operatorname{Re}\left[\hat{E}_{i} e^{j(\omega t - k_{xi}x - k_{zi}z)} \mathbf{i}_{y}\right]$$

$$\mathbf{H}_{i} = \operatorname{Re}\left[\frac{\hat{E}_{i}}{\eta_{1}}\left(-\cos \theta_{i} \mathbf{i}_{x} + \sin \theta_{i} \mathbf{i}_{z}\right) e^{j(\omega t - k_{xi}x - k_{xi}z)}\right]$$

$$\mathbf{E}_{r} = \operatorname{Re}\left[\hat{E}_{r} e^{j(\omega t - k_{xr}x + k_{xr}z)} \mathbf{i}_{y}\right]$$

$$\mathbf{H}_{r} = \operatorname{Re}\left[\frac{\hat{E}_{r}}{\eta_{1}}\left(\cos \theta_{r} \mathbf{i}_{x} + \sin \theta_{r} \mathbf{i}_{z}\right) e^{j(\omega t - k_{xr}x + k_{xr}z)}\right]$$

$$\mathbf{E}_{t} = \operatorname{Re}\left[\hat{E}_{t} e^{j(\omega t - k_{xr}x - k_{xr}z)} \mathbf{i}_{y}\right]$$

$$\mathbf{H}_{t} = \operatorname{Re}\left[\frac{\hat{E}_{t}}{\eta_{2}}\left(-\cos \theta_{t} \mathbf{i}_{x} + \sin \theta_{t} \mathbf{i}_{z}\right) e^{j(\omega t - k_{xr}x - k_{xr}z)}\right]$$

where θ_i , θ_r , and θ_t are the angles from the normal of the incident, reflected, and transmitted power flows. The wavenumbers in each region are

$$k_{xi} = k_1 \sin \theta_i, \qquad k_{xr} = k_1 \sin \theta_r, \qquad k_{xt} = k_2 \sin \theta_t$$

$$k_{zi} = k_1 \cos \theta_i, \qquad k_{zr} = k_1 \cos \theta_r, \qquad k_{zt} = k_2 \cos \theta_t$$
(2)

where the wavenumber magnitudes, wave speeds, and wave impedances are

$$k_1 = \frac{\omega}{c_1}, \qquad k_2 = \frac{\omega}{c_2}, \qquad c_1 = \frac{1}{\sqrt{\varepsilon_1 \mu_1}}$$

$$\eta_1 = \sqrt{\frac{\mu_1}{\varepsilon_1}}, \qquad \eta_2 = \sqrt{\frac{\mu_2}{\varepsilon_2}}, \qquad c_2 = \frac{1}{\sqrt{\varepsilon_2 \mu_2}}$$
(3)

The unknown angles and amplitudes in (1) are found from the boundary conditions of continuity of tangential **E** and **H** at the z = 0 interface.

$$\frac{\hat{E}_{i} e^{-jk_{xt}x} + \hat{E}_{r} e^{-jk_{xt}x} = \hat{E}_{t} e^{-jk_{xt}x}}{\frac{-\hat{E}_{i} \cos \theta_{i} e^{-jk_{xt}x} + \hat{E}_{r} \cos \theta_{r} e^{-jk_{xr}x}}{\eta_{1}} = -\frac{\hat{E}_{t} \cos \theta_{t} e^{-jk_{xt}x}}{\eta_{2}}$$
(4)

These boundary conditions must be satisfied point by point for all x. This requires that the exponential factors also be



Figure 7-18 A uniform plane wave obliquely incident upon a dielectric interface also has its angle of incidence equal to the angle of reflection while the transmitted angle is given by Snell's law. (a) Electric field polarized parallel to the interface. (b) Magnetic field parallel to the interface.

equal so that the x components of all wavenumbers must be equal,

$$k_{xi} = k_{xr} = k_{xt} \Rightarrow k_1 \sin \theta_i = k_1 \sin \theta_r = k_2 \sin \theta_t$$
 (5)

which relates the angles as

$$\boldsymbol{\theta}_r = \boldsymbol{\theta}_i \tag{6}$$

$$\sin \theta_t = (c_2/c_1) \sin \theta_i \tag{7}$$

As before, the angle of incidence equals the angle of reflection. The transmission angle obeys a more complicated relation called Snell's law relating the sines of the angles. The angle from the normal is largest in that region which has the faster speed of electromagnetic waves.

In optics, the ratio of the speed of light in vacuum, $c_0 = 1/\sqrt{\varepsilon_0\mu_0}$, to the speed of light in the medium is defined as the index of refraction,

$$n_1 = c_0/c_1, \qquad n_2 = c_0/c_2$$
 (8)

which is never less than unity. Then Snell's law is written as

$$\sin \theta_i = (n_1/n_2) \sin \theta_i \tag{9}$$

With the angles related as in (6), the reflected and transmitted field amplitudes can be expressed in the same way as for normal incidence (see Section 7-6-1) if we replace the wave impedances by $\eta \rightarrow \eta/\cos \theta$ to yield

$$R = \frac{\hat{E}_{i}}{\hat{E}_{i}} = \frac{\frac{\eta_{2}}{\cos\theta_{i}} - \frac{\eta_{1}}{\cos\theta_{i}}}{\frac{\eta_{2}}{\cos\theta_{i}} + \frac{\eta_{1}}{\cos\theta_{i}}} = \frac{\eta_{2}\cos\theta_{i} - \eta_{1}\cos\theta_{i}}{\eta_{2}\cos\theta_{i} + \eta_{1}\cos\theta_{i}}$$

$$T = \frac{\hat{E}_{i}}{\hat{E}_{i}} = \frac{2\eta_{2}}{\cos\theta_{i}\left(\frac{\eta_{2}}{\cos\theta_{i}} + \frac{\eta_{1}}{\cos\theta_{i}}\right)} = \frac{2\eta_{2}\cos\theta_{i}}{\eta_{2}\cos\theta_{i} + \eta_{1}\cos\theta_{i}}$$
(10)

In (4) we did not consider the boundary condition of continuity of normal **B** at z = 0. This boundary condition is redundant as it is the same condition as the upper equation in (4):

$$\frac{\mu_1}{\eta_1}(\hat{E}_i + \hat{E}_r) \sin \theta_i = \frac{\mu_2}{\eta_2} \hat{E}_t \sin \theta_t \Rightarrow (\hat{E}_i + \hat{E}_r) = \hat{E}_t \qquad (11)$$

where we use the relation between angles in (6). Since

$$\frac{\mu_1}{\eta_1} = \sqrt{\mu_1 \varepsilon_1} = \frac{1}{c_1}, \qquad \frac{\mu_2}{\eta_2} = \sqrt{\mu_2 \varepsilon_2} = \frac{1}{c_2}$$
(12)

the trigonometric terms in (11) cancel due to Snell's law. There is no normal component of **D** so it is automatically continuous across the interface.

7-9-2 Brewster's Angle of No Reflection

We see from (10) that at a certain angle of incidence, there is no reflected field as R = 0. This angle is called Brewster's angle:

$$R = 0 \Rightarrow \eta_2 \cos \theta_i = \eta_1 \cos \theta_i \tag{13}$$

By squaring (13), replacing the cosine terms with sine terms $(\cos^2 \theta = 1 - \sin^2 \theta)$, and using Snell's law of (6), the Brewster angle θ_B is found as

$$\sin^2 \theta_B = \frac{1 - \varepsilon_2 \mu_1 / (\varepsilon_1 \mu_2)}{1 - (\mu_1 / \mu_2)^2}$$
(14)

There is not always a real solution to (14) as it depends on the material constants. The common dielectric case, where $\mu_1 = \mu_2 \equiv \mu$ but $\varepsilon_1 \neq \varepsilon_2$, does not have a solution as the right-hand side of (14) becomes infinite. Real solutions to (14) require the right-hand side to be between zero and one. A Brewster's angle does exist for the uncommon situation where $\varepsilon_1 = \varepsilon_2$ and $\mu_1 \neq \mu_2$:

$$\sin^2 \theta_B = \frac{1}{1 + \mu_1/\mu_2} \Rightarrow \tan \theta_B = \sqrt{\frac{\mu_2}{\mu_1}}$$
(15)

At this Brewster's angle, the reflected and transmitted power flows are at right angles ($\theta_B + \theta_t = \pi/2$) as can be seen by using (6), (13), and (14):

$$\cos \left(\theta_{B} + \theta_{t}\right) = \cos \theta_{B} \cos \theta_{t} - \sin \theta_{B} \sin \theta_{t}$$

$$= \cos^{2} \theta_{B} \sqrt{\frac{\mu_{2}}{\mu_{1}}} - \sin^{2} \theta_{B} \sqrt{\frac{\mu_{1}}{\mu_{2}}}$$

$$= \sqrt{\frac{\mu_{2}}{\mu_{1}}} - \sin^{2} \theta_{B} \left(\sqrt{\frac{\mu_{1}}{\mu_{2}}} + \sqrt{\frac{\mu_{2}}{\mu_{1}}}\right) = 0 \quad (16)$$

7-9-3 Critical Angle of Transmission

Snell's law in (6) shows us that if $c_2 > c_1$, large angles of incident angle θ_i could result in $\sin \theta_t$ being greater than unity. There is no real angle θ_t that satisfies this condition. The critical incident angle θ_c is defined as that value of θ_i that makes $\theta_t = \pi/2$,

$$\sin \theta_c = c_1/c_2 \tag{17}$$

which has a real solution only if $c_1 < c_2$. At the critical angle, the wavenumber k_{xt} is zero. Lesser incident angles have real values of k_{xt} . For larger incident angles there is no real angle θ_t that satisfies (6). Snell's law must always be obeyed in order to satisfy the boundary conditions at z = 0 for all x. What happens is that θ_t becomes a complex number that satisfies (6). Although sin θ_t is still real, $\cos \theta_t$ is imaginary when sin θ_t exceeds unity:

$$\cos\theta_t = \sqrt{1 - \sin^2\theta_t} \tag{18}$$

This then makes k_{zt} imaginary, which we can write as

$$\boldsymbol{k}_{zt} = \boldsymbol{k}_2 \cos \theta_t = -j\boldsymbol{\alpha} \tag{19}$$

The negative sign of the square root is taken so that waves now decay with z:

$$\mathbf{E}_{t} = \operatorname{Re}\left[\hat{E}_{t} e^{j(\omega t - k_{xt}x)} e^{-\alpha x} \mathbf{i}_{y}\right]$$

$$\mathbf{H}_{t} = \operatorname{Re}\left[\frac{\hat{E}_{t}}{\eta_{2}}(-\cos \theta_{t} \mathbf{i}_{x} + \sin \theta_{t} \mathbf{i}_{z}) e^{j(\omega t - k_{xt}x)} e^{-\alpha x}\right]$$
(20)

The solutions are now nonuniform plane waves, as discussed in Section 7-7.

Complex angles of transmission are a valid mathematical concept. What has happened is that in (1) we wrote our assumed solutions for the transmitted fields in terms of pure propagating waves. Maxwell's equations for an incident angle greater than the critical angle require spatially decaying waves with z in region 2 so that the mathematics forced k_{zt} to be imaginary.

There is no power dissipation since the z-directed timeaverage power flow is zero,

$$< S_{z} > = -\frac{1}{2} \operatorname{Re} \left[E_{y} H_{x}^{*} \right]$$
$$= -\frac{1}{2} \operatorname{Re} \left[\frac{\hat{E}_{t} \hat{E}_{t}^{*}}{\eta_{2}} (-\cos \theta_{t})^{*} e^{-2\alpha x} \right] = 0 \qquad (21)$$

because $\cos \theta_t$ is pure imaginary so that the bracketed term in (21) is pure imaginary. The incident z-directed time-average power is totally reflected. Even though the time-averaged z-directed transmitted power is zero, there are nonzero but exponentially decaying fields in region 2.

7-9-4 H Field Parallel to the Boundary

For this polarization, illustrated in Figure 7-18b, the fields are

$$\mathbf{E}_{i} = \operatorname{Re}\left[\hat{E}_{i}\left(\cos\theta_{i}\mathbf{i}_{x}-\sin\theta_{i}\mathbf{i}_{z}\right)e^{j\left(\omega t-k_{ui}x-k_{ui}z\right)}\right]$$

$$\mathbf{H}_{i} = \operatorname{Re}\left[\frac{\hat{E}_{i}}{\eta_{1}}e^{j\left(\omega t-k_{ui}x-k_{ui}z\right)}\mathbf{i}_{y}\right]$$

$$\mathbf{E}_{r} = \operatorname{Re}\left[\hat{E}_{r}\left(-\cos\theta_{r}\mathbf{i}_{x}-\sin\theta_{r}\mathbf{i}_{z}\right)e^{j\left(\omega t-k_{ur}x+k_{ur}z\right)}\right]$$

$$\mathbf{H}_{r} = \operatorname{Re}\left[\frac{\hat{E}_{r}}{\eta_{1}}e^{j\left(\omega t-k_{ur}x+k_{ur}z\right)}\mathbf{i}_{y}\right]$$

$$\mathbf{E}_{t} = \operatorname{Re}\left[\hat{E}_{i}\left(\cos\theta_{t}\mathbf{i}_{x}-\sin\theta_{t}\mathbf{i}_{z}\right)e^{j\left(\omega t-k_{ur}x-k_{ur}z\right)}\right]$$

$$\mathbf{H}_{t} = \operatorname{Re}\left[\frac{\hat{E}_{t}}{\eta_{2}}e^{j\left(\omega t-k_{ur}x-k_{ur}z\right)}\mathbf{i}_{y}\right]$$

$$(22)$$

where the wavenumbers and impedances are the same as in (2) and (3).

Continuity of tangential **E** and **H** at z = 0 requires

$$\frac{\hat{E}_{i}\cos\theta_{i}e^{-jk_{xt}x} - \hat{E}_{r}\cos\theta_{r}e^{-jk_{xr}x}}{\hat{E}_{i}e^{-jk_{xr}x} + \hat{E}_{r}e^{-jk_{xr}x}} = \frac{\hat{E}_{t}\cos\theta_{t}e^{-jk_{xt}x}}{\eta_{2}}$$
(23)

Again the phase factors must be equal so that (5) and (6) are again true. Snell's law and the angle of incidence equalling the angle of reflection are independent of polarization.

We solve (23) for the field reflection and transmission coefficients as

$$R = \frac{\hat{E}_r}{\hat{E}_i} = \frac{\eta_1 \cos \theta_i - \eta_2 \cos \theta_i}{\eta_2 \cos \theta_i + \eta_1 \cos \theta_i}$$
(24)

$$T = \frac{\hat{E}_i}{\hat{E}_i} = \frac{2\eta_2 \cos \theta_i}{\eta_2 \cos \theta_i + \eta_1 \cos \theta_i}$$
(25)

Now we note that the boundary condition of continuity of normal **D** at z = 0 is redundant to the lower relation in (23),

$$\varepsilon_1 \hat{E}_1 \sin \theta_i + \varepsilon_1 \hat{E}_r \sin \theta_r = \varepsilon_2 \hat{E}_t \sin \theta_t$$
 (26)

using Snell's law to relate the angles.

For this polarization the condition for no reflected waves is

$$R = 0 \Rightarrow \eta_2 \cos \theta_i = \eta_1 \cos \theta_i \tag{27}$$

which from Snell's law gives the Brewster angle:

$$\sin^2 \theta_B = \frac{1 - \varepsilon_1 \mu_2 / (\varepsilon_2 \mu_1)}{1 - (\varepsilon_1 / \varepsilon_2)^2}$$
(28)

There is now a solution for the usual case where $\mu_1 = \mu_2$ but $\varepsilon_1 \neq \varepsilon_2$:

$$\sin^2 \theta_B = \frac{1}{1 + \varepsilon_1 / \varepsilon_2} \Rightarrow \tan \theta_B = \sqrt{\frac{\varepsilon_2}{\varepsilon_1}}$$
(29)

At this Brewster's angle the reflected and transmitted power flows are at right angles $(\theta_B + \theta_i) = \pi/2$ as can be seen by using (6), (27), and (29)

$$\cos \left(\theta_{B} + \theta_{t}\right) = \cos \theta_{B} \cos \theta_{t} - \sin \theta_{B} \sin \theta_{t}$$
$$= \cos^{2} \theta_{B} \sqrt{\frac{\varepsilon_{2}}{\varepsilon_{1}}} - \sin^{2} \theta_{B} \sqrt{\frac{\varepsilon_{1}}{\varepsilon_{2}}}$$
$$= \sqrt{\frac{\varepsilon_{2}}{\varepsilon_{1}}} - \sin^{2} \theta_{B} \left(\sqrt{\frac{\varepsilon_{1}}{\varepsilon_{2}}} + \sqrt{\frac{\varepsilon_{2}}{\varepsilon_{1}}}\right) = 0 \qquad (30)$$

Because Snell's law is independent of polarization, the critical angle of (17) is the same for both polarizations. Note that the Brewster's angle for either polarization, if it exists, is always less than the critical angle of (17), as can be particularly seen when $\mu_1 = \mu_2$ for the magnetic field polarized parallel to the interface or when $\varepsilon_1 = \varepsilon_2$ for the electric field polarized parallel to the interface, as then

$$\frac{1}{\sin^2 \theta_B} = \frac{1}{\sin^2 \theta_c} + 1 \tag{31}$$

7-10 APPLICATIONS TO OPTICS

Reflection and refraction of electromagnetic waves obliquely incident upon the interface between dissimilar linear lossless media are governed by the two rules illustrated in Figure 7-19:

- (i) The angle of incidence equals the angle of reflection.
- (ii) Waves incident from a medium of high light velocity (low index of refraction) to one of low velocity (high index of refraction) are bent towards the normal. If the wave is incident from a low velocity (high index) to high velocity (low index) medium, the light is bent away from the normal. The incident and refracted angles are related by Snell's law.



Figure 7-19 A summary of reflection and refraction phenomena across the interface separating two linear media. When $\theta_i = \theta_B$ (Brewster's angle), there is no reflected ray. When $\theta_i > \theta_c$ (critical angle), the transmitted fields decay with z.

Most optical materials, like glass, have a permeability of free space μ_0 . Therefore, a Brewster's angle of no reflection only exists if the **H** field is parallel to the boundary.

At the critical angle, which can only exist if light travels from a high index of refraction material (low light velocity) to one of low index (high light velocity), there is a transmitted field that decays with distance as a nonuniform plane wave. However, there is no time-average power carried by this evanescent wave so that all the time-average power is reflected. This section briefly describes various applications of these special angles and the rules governing reflection and refraction.

7-10-1 Reflections from a Mirror

A person has their eyes at height h above their feet and a height Δh below the top of their head, as in Figure 7-20. A mirror in front extends a distance Δy above the eyes and a distance y below. How large must y and Δy be so that the person sees their entire image? The light reflected off the person into the mirror must be reflected again into the person's eyes. Since the angle of incidence equals the angle of reflection, Figure 7-20 shows that $\Delta y = \Delta h/2$ and y = h/2.

7-10-2 Lateral Displacement of a Light Ray

A light ray is incident from free space upon a transparent medium with index of refraction n at angle θ_i , as shown in Figure 7-21. The angle of the transmitted light is given by Snell's law:

$$\sin \theta_i = (1/n) \sin \theta_i \tag{1}$$



Figure 7-20 Because the angle of incidence equals the angle of reflection, a person can see their entire image if the mirror extends half the distance of extent above and below the eyes.



Figure 7-21 A light ray incident upon a glass plate exits the plate into the original medium parallel to its original trajectory but laterally displaced.

When this light hits the second interface, the angle θ_t is now the incident angle so that the transmitted angle θ_2 is again given by Snell's law:

$$\sin \theta_2 = n \sin \theta_t = \sin \theta_i \tag{2}$$

so that the light exits at the original incident angle θ_i . However, it is now shifted by the amount:

$$s = \frac{d \sin \left(\theta_i - \theta_t\right)}{\cos \theta_t} \tag{3}$$

If the plate is glass with refractive index n = 1.5 and thickness d = 1 mm with incident angle $\theta_i = 30^\circ$, the angle θ_i in the glass is

$$\sin \theta_t = 0.33 \Rightarrow \theta_t = 19.5^{\circ} \tag{4}$$

so that the lateral displacement is s = 0.19 mm.

7-10-3 Polarization By Reflection

Unpolarized light is incident upon the piece of glass in Section 7-10-2 with index of refraction n = 1.5. Unpolarized light has both **E** and **H** parallel to the interface. We assume that the permeability of the glass equals that of free space and that the light is incident at the Brewster's angle θ_B for light polarized with **H** parallel to the interface. The incident and transmitted angles are then

$$\tan \theta_{B} = \sqrt{\varepsilon/\varepsilon_{0}} = n \Rightarrow \theta_{B} = 56.3^{\circ}$$
$$\tan \theta_{t} = \sqrt{\varepsilon_{0}/\varepsilon} = 1/n \Rightarrow \theta_{t} = 33.7^{\circ}$$
(5)

The Brewster's angle is also called the polarizing angle because it can be used to separate the two orthogonal polarizations. The polarization, whose **H** field is parallel to the interface, is entirely transmitted at the first interface with no reflection. The other polarization with electric field parallel to the interface is partially transmitted and reflected. At the second (glass-free space) interface the light is incident at angle θ_t . From (5) we see that this angle is the Brewster's angle with **H** parallel to the interface for light incident from the glass side onto the glass-free space interface. Then again, the **H** parallel to the interface polarization is entirely transmitted while the **E** parallel to the interface polarization is partially reflected and partially transmitted. Thus, the reflected wave is entirely polarized with electric field parallel to the interface. The transmitted waves, although composed of both polarizations, have the larger amplitude with H



Figure 7-22 Unpolarized light incident upon glass with $\mu = \mu_0$ can be polarized by reflection if it is incident at the Brewster's angle for the polarization with **H** parallel to the interface. The transmitted light becomes more polarized with **H** parallel to the interface by adding more parallel glass plates.

parallel to the interface because it was entirely transmitted with no reflection at both interfaces.

By passing the transmitted light through another parallel piece of glass, the polarization with electric field parallel to the interface becomes further diminished because it is partially reflected, while the other polarization is completely transmitted. With more glass elements, as in Figure 7-22, the transmitted light can be made essentially completely polarized with **H** field parallel to the interface.

7-10-4 Light Propagation In Water

(a) Submerged Source

A light source is a distance d below the surface of water with refractive index n = 1.33, as in Figure 7-23. The rays emanate from the source as a cone. Those rays at an angle from the normal greater than the critical angle,

$$\sin \theta_c = 1/n \Rightarrow \theta_c = 48.8^{\circ} \tag{6}$$

are not transmitted into the air but undergo total internal reflection. A circle of light with diameter

$$D = 2d \tan \theta_c \approx 2.28d \tag{7}$$

then forms on the water's surface due to the exiting light.

(b) Fish Below a Boat

A fish swims below a circular boat of diameter D, as in Figure 7-24. As we try to view the fish from the air above, the incident light ray is bent towards the normal. The region below the boat that we view from above is demarcated by the light rays at grazing incidence to the surface ($\theta_i = \pi/2$) just entering the water (n = 1.33) at the sides of the boat. The transmitted angle of these light rays is given from Snell's law as

$$\sin \theta_t = \frac{\sin \theta_i}{n} = \frac{1}{n} \Rightarrow \theta_t = 48.8^{\circ}$$
(8)



Figure 7-23 Light rays emanating from a source within a high index of refraction medium are totally internally reflected from the surface for angles greater than the critical angle. Lesser angles of incidence are transmitted.



Figure 7-24 A fish cannot be seen from above if it swims below a circular boat within the cone bounded by light rays at grazing incidence entering the water at the side of the boat.

These rays from all sides of the boat intersect at the point a distance y below the boat, where

$$\tan \theta_t = \frac{D}{2y} \Rightarrow y = \frac{D}{2 \tan \theta_t} \approx 0.44D \tag{9}$$

If the fish swims within the cone, with vertex at the point y below the boat, it cannot be viewed from above.

7-10-5 Totally Reflecting Prisms

The glass isoceles right triangle in Figure 7-25 has an index of refraction of n = 1.5 so that the critical angle for total



Figure 7-25 A totally reflecting prism. The index of refraction n must exceed $\sqrt{2}$ so that the light incident on the hypotenuse at 45° exceeds the critical angle.

internal reflection is

$$\sin \theta_c = \frac{1}{n} = \frac{1}{1.5} \Rightarrow \theta_c = 41.8^{\circ} \tag{10}$$

The light is normally incident on the vertical face of the prism. The transmission coefficient is then given in Section 7-6-1 as

$$T_1 = \frac{\hat{E}_i}{\hat{E}_i} = \frac{2\eta}{\eta + \eta_0} = \frac{2/n}{1 + 1/n} = \frac{2}{n+1} = 0.8$$
(11)

where because the permeability of the prism equals that of free space $n = \sqrt{\varepsilon/\varepsilon_0}$ while $\eta/\eta_0 = \sqrt{\varepsilon_0/\varepsilon} = 1/n$. The transmitted light is then incident upon the hypotenuse of the prism at an angle of 45°, which exceeds the critical angle so that no power is transmitted and the light is totally reflected being turned through a right angle. The light is then normally incident upon the horizontal face with transmission coefficient:

$$T_2 = \frac{\hat{E}_2}{0.8\hat{E}_i} = \frac{2\eta_0}{\eta + \eta_0} = \frac{2}{1/n + 1} = \frac{2n}{n + 1} = 1.2$$
(12)

The resulting electric field amplitude is then

$$\hat{E}_2 = T_1 T_2 \hat{E}_i = 0.96 \hat{E}_i \tag{13}$$

The ratio of transmitted to incident power density is

$$\frac{\langle S \rangle}{\langle S_i \rangle} = \frac{\frac{1}{2} |\hat{E}_2|^2 / \eta_0}{\frac{1}{2} |\hat{E}_i|^2 / \eta_0} = \frac{|\hat{E}_2|^2}{|\hat{E}_i|^2} = \left(\frac{24}{25}\right)^2 \approx 0.92$$
(14)

This ratio can be increased to unity by applying a quarterwavelength-thick dielectric coating with index of refraction $n_{\text{coating}} = \sqrt{n}$, as developed in Example 7-1. This is not usually done because the ratio in (14) is already large without the expense of a coating.

7-10-6 Fiber Optics

(a) Straight Light Pipe

Long thin fibers of transparent material can guide light along a straight path if the light within the pipe is incident upon the wall at an angle greater than the critical angle $(\sin \theta_{c} = 1/n)$:

$$\sin \theta_2 = \cos \theta_t \ge \sin \theta_c \tag{15}$$

The light rays are then totally internally reflected being confined to the pipe until they exit, as in Figure 7-26. The



Figure 7-26 The index of refraction of a straight light pipe must be greater than $\sqrt{2}$ for total internal reflections of incident light at any angle.

incident angle is related to the transmitted angle from Snell's law,

$$\sin \theta_t = (1/n) \sin \theta_i \tag{16}$$

so that (15) becomes

$$\cos \theta_t = \sqrt{1 - \sin^2 \theta_t} = \sqrt{1 - (1/n^2) \sin^2 \theta_i} \ge 1/n \qquad (17)$$

which when solved for n yields

$$n^2 \ge 1 + \sin^2 \theta_i \tag{18}$$

If this condition is met for grazing incidence ($\theta_i = \pi/2$), all incident light will be passed by the pipe, which requires that

$$n^2 \ge 2 \Rightarrow n \ge \sqrt{2} \tag{19}$$

Most types of glass have $n \approx 1.5$ so that this condition is easily met.

(b) Bent Fibers

Light can also be guided along a tortuous path if the fiber is bent, as in the semi-circular pipe shown in Figure 7-27. The minimum angle to the radial normal for the incident light shown is at the point A. This angle in terms of the radius of the bend and the light pipe width must exceed the critical angle

$$\sin \theta_A = \frac{R}{R+d} \ge \sin \theta_c \tag{20}$$



Figure 7-27 Light can be guided along a circularly bent fiber if R/d > 1/(n-1) as then there is always total internal reflection each time the light is incident on the walls.

so that

$$\frac{R/d}{R/d+1} \ge \frac{1}{n} \tag{21}$$

which when solved for R/d requires

$$\frac{R}{d} \ge \frac{1}{n-1} \tag{22}$$

PROBLEMS

Section 7-1

1. For the following electric fields in a linear media of permittivity ε and permeability μ find the charge density, magnetic field, and current density.

(a) $\mathbf{E} = E_0(\mathbf{x}\mathbf{i}_x + \mathbf{y}\mathbf{i}_y) \sin \omega t$

(b) $\mathbf{E} = E_0(\mathbf{y}\mathbf{i}_x - \mathbf{x}\mathbf{i}_y) \cos \omega t$ (c) $\mathbf{E} = \operatorname{Re} [E_0 e^{i(\omega t - k_x x - k_x x)}\mathbf{i}_y]$. How must k_x , k_z , and ω be related so that J = 0?

2. An Ohmic conductor of arbitrary shape has an initial charge distribution $\rho_0(\mathbf{r})$ at t = 0.

(a) What is the charge distribution for all time?

(b) The initial charge distribution is uniform and is confined between parallel plate electrodes of spacing d. What are the electric and magnetic fields when the electrodes are opened or short circuited?

(c) Repeat (b) for coaxial cylindrical electrodes of inner radius a and outer radius b.

(d) When does a time varying electric field not generate a magnetic field?

3. (a) For linear media of permittivity ε and permeability μ , use the magnetic vector potential A to rewrite Faraday's law as the curl of a function.

(b) Can a scalar potential function V be defined? What is the electric field in terms of V and A? The choice of V is not unique so pick V so that under static conditions $\mathbf{E} = -\nabla V$.

(c) Use the results of (a) and (b) in Ampere's law with Maxwell's displacement current correction to obtain a single equation in A and V. (Hint: $\nabla \times (\nabla \times A) = \nabla (\nabla \cdot A) - \nabla^2 A$.)

(d) Since we are free to specify $\nabla \cdot \mathbf{A}$, what value should we pick to make (c) an equation just in A? This is called setting the gauge.

(e) Use the results of (a)-(d) in Gauss's law for **D** to obtain a single equation in V.

(f) Consider a sinusoidally varying point charge at r=0, $\hat{Q}e^{j\omega t}$. Solve (e) for r>0.

Hint:

$$\frac{1}{r}\frac{\partial}{\partial r}\left(r^2\frac{\partial V}{\partial r}\right) = \frac{\partial^2}{\partial r^2}(rV)$$

Define a new variable (rV). By symmetry, V only depends on r and waves can only propagate away from the charge and not towards it. As $r \rightarrow 0$, the potential approaches the quasi-static Coulomb potential.

Section 7-2

4. Poynting's theorem must be modified if we have a hysteretic material with a nonlinear and double-valued relationship between the polarization **P** and electric field **E** and the magnetization **M** and magnetic field **H**.



(a) For these nonlinear constitutive laws put Poynting's theorem in the form

$$\nabla \cdot \boldsymbol{S} + \frac{\partial w}{\partial t} = -P_d - P_P - P_M$$

where P_P and P_M are the power densities necessary to polarize and magnetize the material.

(b) Sinusoidal electric and magnetic fields $\mathbf{E} = \mathbf{E}_s \cos \omega t$ and $\mathbf{H} = \mathbf{H}_s \cos \omega t$ are applied. How much energy density is dissipated per cycle?

5. An electromagnetic field is present within a superconductor with constituent relation

$$\frac{\partial \mathbf{J}_f}{\partial t} = \boldsymbol{\omega}_p^2 \boldsymbol{\varepsilon} \mathbf{E}$$

(a) Show that Poynting's theorem can be written in the form

$$\nabla \cdot \boldsymbol{S} + \frac{\partial w}{\partial t} = 0$$

What is w?

(b) What is the velocity of the charge carriers each with charge q in terms of the current density J_f ? The number density of charge carriers is n.

(c) What kind of energy does the superconductor add?

(d) Rewrite Maxwell's equations with this constitutive law for fields that vary sinusoidally with time.

(e) Derive the complex Poynting theorem in the form

 $\nabla \cdot \left[\frac{1}{2} \hat{\mathbf{E}}(\mathbf{r}) \times \hat{\mathbf{H}}^{*}(\mathbf{r})\right] + 2j\omega < w > = 0$

What is $\langle w \rangle$?

6. A paradoxical case of Poynting's theorem occurs when a static electric field is applied perpendicularly to a static magnetic field, as in the case of a pair of electrodes placed within a magnetic circuit.



- (a) What are **E**, **H**, and **S**?
- (b) What is the energy density stored in the system?
- (c) Verify Poynting's theorem.

7. The complex electric field amplitude has real and imaginary parts

$$\hat{\mathbf{E}}(\mathbf{r}) = \mathbf{E}_r + j\mathbf{E}_i$$

Under what conditions are the following scalar and vector products zero:

- (a) Ê·Ê≟0
- (b) $\hat{\mathbf{E}} \cdot \hat{\mathbf{E}}^* \stackrel{?}{=} 0$
- (c) $\hat{\mathbf{E}} \times \hat{\mathbf{E}} \stackrel{?}{=} 0$
- (d) $\hat{\mathbf{E}} \times \hat{\mathbf{E}}^* \stackrel{?}{=} 0$

Section 7.3

8. Consider a lossy medium of permittivity ε , permeability μ , and Ohmic conductivity σ .

(a) Write down the field equations for an x-directed electric field.

- (b) Obtain a single equation in E_{x} .
- (c) If the fields vary sinusoidally with time,

$$E_{\mathbf{x}} = \operatorname{Re}\left[\hat{E}_{\mathbf{x}}(z) \ e^{j\omega t}\right]$$

what are the spatial dependences of the fields?

(d) Specialize (c) to the (i) low loss limit ($\sigma/\omega \epsilon \ll 1$) and (ii) large loss limit ($\sigma/\omega \epsilon \gg 1$).

(e) Repeat (a)-(c) if the medium is a plasma with constitutive law

$$\frac{\partial \mathbf{J}}{\partial t} = \omega_p^2 \varepsilon \mathbf{E}$$

(f) A current sheet $K_0 \cos \omega t \mathbf{i}_x$ is placed at z = 0. Find the electric and magnetic fields if the sheet is placed within an Ohmic conductor or within a plasma.

9. A uniformly distributed volume current of thickness 2d, $J_0 \cos \omega t \mathbf{i}_x$, is a source of plane waves.



(a) From Maxwell's equations obtain a single differential equation relating E_x to J_x .

(b) Find the electric and magnetic fields within and outside the current distribution.

(c) How much time-average power per unit area is delivered by the current?

(d) How does this generated power compare to the electromagnetic time-average power per unit area leaving the volume current at $z = \pm d$?

10. A TEM wave (E_x, H_y) propagates in a medium whose permittivity and permeability are functions of z, $\varepsilon(z)$, and $\mu(z)$.

(a) Write down Maxwell's equations and obtain single partial differential equations in E_x and H_y .

(b) Consider the idealized case where $\varepsilon(z) = \varepsilon e^{\alpha |z|}$ and $\mu(z) = \mu e^{-\alpha |z|}$. A current sheet $K_0 e^{j\omega t} \mathbf{i}_x$ is at z = 0. What are

the resulting electric and magnetic fields on each side of the sheet?

(c) For what values of α are the solutions spatially evanescent or oscillatory?

11. We wish to compare various measurements between two observers, the second moving at a constant velocity $v i_x$ with respect to the first.

(a) The first observer measures simultaneous events at two positions z_1 and z_2 so that $t_1 = t_2$. What is the time interval between the two events $t'_1 - t'_2$ as measured by the second observer?

(b) The first observer measures a time interval $\Delta t = t_1 - t_2$ between two events at the same position z. What is the time interval as measured by the second observer?

(c) The first observer measures the length of a stick as $L = z_2 - z_1$. What is the length of the stick as measured by the second observer?

12. A stationary observer measures the velocity of a particle as $\mathbf{u} = u_x \mathbf{i}_x + u_y \mathbf{i}_y + u_z \mathbf{i}_z$.

(a) What velocity, $\mathbf{u}' = u'_x \mathbf{i}_x + u'_y \mathbf{i}_y + u'_z \mathbf{i}_z$, does another observer moving at constant speed $v \mathbf{i}_z$ measure?

(b) Find \mathbf{u}' for the following values of \mathbf{u} where c_0 is the free space speed of light:

(i)
$$\mathbf{u} = c_0 \mathbf{i}_x$$

(ii) $\mathbf{u} = c_0 \mathbf{i}_y$
(iii) $\mathbf{u} = c_0 \mathbf{i}_z$
(iv) $\mathbf{u} = (c_0/\sqrt{3})[\mathbf{i}_x + \mathbf{i}_y + \mathbf{i}_z]$

(c) Do the results of (a) and (b) agree with the postulate that the speed of light for all observers is c_0 ?

Section 7.4

13. An electric field is of the form

$$\mathbf{E} = 100 \ e^{i(2\pi \times 10^6 t - 2\pi \times 10^{-2}z)} \mathbf{i}_r \ \text{volts/m}$$

(a) What is the frequency, wavelength, and speed of light in the medium?

(b) If the medium has permeability $\mu_0 = 4\pi \times 10^{-7}$ henry/m, what is the permittivity ε , wave impedance η , and the magnetic field?

(c) How much time-average power per unit area is carried by the wave?

14. The electric field of an elliptically polarized plane wave in a medium with wave impedance η is

 $\mathbf{E} = \operatorname{Re} \left(E_{x0} \mathbf{i}_{x} + E_{v0} e^{j\phi} \mathbf{i}_{v} \right) e^{j(\omega t - kx)}$

where E_{x0} and E_{y0} are real.

(a) What is the magnetic field?

(b) What is the instantaneous and time-average power flux densities?

15. In Section 3-1-4 we found that the force on one of the charges Q of a spherical atomic electric dipole of radius R_0 is

$$\mathbf{F} = Q \left[\mathbf{E} - \frac{Q \mathbf{d}}{4\pi\varepsilon_0 R_0^3} \right]$$

where **d** is the dipole spacing.

(a) Write Newton's law for this moveable charge with mass M assuming that the electric field varies sinusoidally with time as $E_0 \cos \omega t$ and solve for **d**. (Hint: Let $\omega_0^2 = Q^2/(M4\pi\epsilon_0 R_0^3)$.)

(b) What is the polarization **P** as a function of **E** if there are N dipoles per unit volume? What is the frequency dependent permittivity function $\varepsilon(\omega)$, where

$$\mathbf{D}(\mathbf{r}) = \varepsilon(\boldsymbol{\omega})\mathbf{E}(\mathbf{r})$$

This model is often appropriate for light propagating in dielectric media.

(c) Use the results of (b) in Maxwell's equations to find the relation between the wavenumber k and frequency ω .

(d) For what frequency ranges do we have propagation or evanescence?

(e) What are the phase and group velocities of the waves?

(f) Derive the complex Poynting's theorem for this dispersive dielectric.

16. High-frequency wave propagation in the ionosphere is partially described by the development in Section 7-4-4 except that we must include the earth's dc magnetic field, which we take to be $H_0 i_z$.

(a) The charge carriers have charge q and mass m. Write the three components of Newton's force law neglecting collisions but including inertia and the Coulomb-Lorentz force law. Neglect the magnetic field amplitudes of the propagating waves compared to H_0 in the Lorentz force law.

(b) Solve for each component of the current density \mathbf{J} in terms of the charge velocity components assuming that the propagating waves vary sinusoidally with time as $e^{j\omega t}$. **Hint:** Define

$$\omega_p^2 = \frac{q^2 n}{m\epsilon}, \qquad \omega_0 = \frac{q\mu_0 H_0}{m}$$

(c) Use the results of (b) in Maxwell's equations for fields of the form $e^{i(\omega t - kz)}$ to solve for the wavenumber k in terms of ω .

(d) At what frequencies is the wavenumber zero or infinite? Over what frequency range do we have evanescence or propagation? (e) For each of the two modes found in (c), what is the polarization of the electric field?

(f) What is the phase velocity of each wave? Since each mode travels at a different speed, the atmosphere acts like an anisotropic birefringent crystal. A linearly polarized wave $E_0 e^{i(\omega t - k_0 x)} \mathbf{i}_x$ is incident upon such a medium. Write this field as the sum of right and left circularly polarized waves. **Hint:**

$$E_0 \mathbf{i}_x = \frac{E_0}{2} (\mathbf{i}_x + j\mathbf{i}_y) + \frac{E_0}{2} (\mathbf{i}_x - j\mathbf{i}_y)$$

(g) If the transmitted field at z = 0 just inside the medium has amplitude $E_t e^{j\omega t} \mathbf{i}_x$, what are the electric and magnetic fields throughout the medium?

17. Nitrobenzene with $\mu = \mu_0$ and $\varepsilon = 35\varepsilon_0$ is placed between parallel plate electrodes of spacing s and length l stressed by a dc voltage V_0 . Measurements have shown that light polarized parallel to the dc electric field travels at the speed c_{\parallel} , while light polarized perpendicular to the dc electric field travels slightly faster at the speed c_{\perp} , being related to the dc electric field E_0 and free space light wavelength as

$$\frac{1}{c_{\parallel}} - \frac{1}{c_{\perp}} = \lambda B E_0^2$$

where B is called the Kerr constant which for nitrobenzene is $B \approx 4.3 \times 10^{-12} \text{ sec/V}^2$ at $\lambda = 500 \text{ nm}$.

(a) Linearly polarized light with free space wavelength $\lambda = 500$ nm is incident at 45° to the dc electric field. After exiting the Kerr cell, what is the phase difference between the field components of the light parallel and perpendicular to the dc electric field?

(b) What are all the values of electric field strengths that allow the Kerr cell to act as a quarter- or half-wave plate?

(c) The Kerr cell is placed between crossed polarizers (polariscope). What values of electric field allow maximum light transmission? No light transmission?

Section 7.5

18. A uniform plane wave with y-directed electric field is normally incident upon a plasma medium at z = 0 with constitutive law $\partial \mathbf{J}_f / \partial t = \omega_p^2 \varepsilon \mathbf{E}$. The fields vary sinusoidally in time as $e^{j\omega t}$.

(a) What is the general form of the incident, reflected, and transmitted fields?

(b) Applying the boundary conditions, find the field amplitudes.

(c) What is the time-average electromagnetic power density in each region for $\omega > \omega_p$ and for $\omega < \omega_p$?


wires

19. A polarizing filter to microwaves is essentially formed by many highly conducting parallel wires whose spacing is much smaller than a wavelength. That polarization whose electric field is transverse to the wires passes through. The incident electric field is

$$\mathbf{E} = E_{\mathbf{x}} \cos \left(\omega t - kz\right) \mathbf{i}_{\mathbf{x}} + E_{\mathbf{y}} \sin \left(\omega t - kz\right) \mathbf{i}_{\mathbf{y}}$$

(a) What is the incident magnetic field and incident power density?

(b) What are the transmitted fields and power density?

(c) Another set of polarizing wires are placed parallel but a distance d and orientated at an angle ϕ to the first. What are the transmitted fields?

20. A uniform plane wave with y-directed electric field $E_y = E_0 \cos \omega (t - z/c)$ is normally incident upon a perfectly conducting plane that is moving with constant velocity $v \mathbf{i}_z$, where $v \ll c$.

(a) What are the total electric and magnetic fields in each region?

(b) What is the frequency of the reflected wave?

(c) What is the power flow density? Why can't we use the complex Poynting vector to find the time-average power?

559



Section 7.6

21. A dielectric (ε_2, μ_2) of thickness *d* coats a perfect conductor. A uniform plane wave is normally incident onto the coating from the surrounding medium with properties (ε_1, μ_1) .



57, 13 g → ∞

(a) What is the general form of the fields in the two dielectric media? (**Hint:** Why can the transmitted electric field be written as $\mathbf{E}_t = \operatorname{Re}\left[\hat{E}_t \sin k_2(z-d) e^{j\omega t} \mathbf{i}_x\right]$?)

(b) Applying the boundary conditions, what are the field amplitudes?

(c) What is the time-average power flow in each region?

(d) What is the time-average radiation pressure on the conductor?

Section 7.7

22. An electric field of the form Re $(\hat{E} e^{j\omega t} e^{-\gamma \cdot r})$ propagates in a lossy conductor with permittivity ε , permeability μ , and conductivity σ . If $\gamma = \alpha + j\mathbf{k}$, what equalities must α and \mathbf{k} obey?

23. A sheet of surface charge with charge density $\sigma_0 \sin(\omega t - k_x x)$ is placed at z = 0 within a linear medium with properties (ε, μ) .



- (a) What are the electric and magnetic fields?
- (b) What surface current flows on the sheet?

24. A current sheet of the form Re $(K_0 e^{j(\omega t - k_x x)} \mathbf{i}_x)$ is located in free space at z = 0. A dielectric medium (ε, μ) of semi-infinite extent is placed at z = d.



(a) For what range of frequency can we have a nonuniform plane wave in free space and a uniform plane wave in the dielectric? Nonuniform plane wave in each region? Uniform plane wave in each region?

(b) What are the electric and magnetic fields everywhere?

(c) What is the time-average z-directed power flow density in each region if we have a nonuniform plane wave in free space but a uniform plane wave in the dielectric?

Section 7.8

25. A uniform plane wave Re $(E_0 e^{j(\omega t - k_x x - k_z x)} \mathbf{i}_y)$ is obliquely incident upon a right-angled perfectly conducting corner. The wave is incident at angle θ_i to the z = 0 wall.



(a) Try a solution composed of the incident and reflected waves off each surface of the conductor. What is the general form of solution? (**Hint:** There are four different waves.)

(b) Applying the boundary conditions, what are the electric and magnetic fields?

(c) What are the surface charge and current distributions on the conducting walls?

- (d) What is the force per unit area on each wall?
- (e) What is the power flow density?

Section 7.9

26. Fermat's principle of least time states that light, when reflected or refracted off an interface, will pick the path of least time to propagate between two points.



(a) A beam of light from point A is incident upon a dielectric interface at angle θ_i from the normal and is reflected through the point B at angle θ_r . In terms of θ_i , θ_r , h_1 and h_2 , and the speed of light c_1 , how long does it take light to travel from A to B along this path? What other relation is there between θ_i , θ_r , L_{AB} , h_1 and h_2 ?

(b) Find the angle θ_i that satisfies Fermat's principle. What is θ_r ?

(c) In terms of θ_i , θ_i , h_1 , h_3 , and the light speeds c_1 and c_2 in each medium, how long does it take light to travel from A to C?

(d) Find the relationship between θ_i and θ_t that satisfies Fermat's principle.

27. In many cases the permeability of dielectric media equals that of free space. In this limit show that the reflection and transmission coefficients for waves obliquely incident upon dielectric media are: **E** parallel to the interface

$$R = -\frac{\sin (\theta_i - \theta_t)}{\sin (\theta_i + \theta_t)}, \qquad T = \frac{2 \cos \theta_i \sin \theta_t}{\sin (\theta_i + \theta_t)}$$

H parallel to the interface

$$R = \frac{\tan (\theta_i - \theta_t)}{\tan (\theta_i + \theta_t)}, \qquad T = \frac{2 \cos \theta_i \sin \theta_t}{\sin (\theta_i + \theta_t) \cos (\theta_i - \theta_t)}$$

28. White light is composed of the entire visible spectrum. The index of refraction n for most materials is a weak function of wavelength λ , often described by Cauchy's equation



$$n = A + B/\lambda^2$$

A beam of white light is incident at 30° to a piece of glass with A = 1.5 and $B = 5 \times 10^{-15}$ m². What are the transmitted angles for the colors violet (400 nm), blue (450 nm), green (550 nm), yellow (600 nm), orange (650 nm), and red (700 nm)? This separation of colors is called dispersion.

29. A dielectric slab of thickness d with speed of light c_2 is placed within another dielectric medium of infinite extent with speed of light c_1 , where $c_1 < c_2$. An electromagnetic wave with **H** parallel to the interface is incident onto the slab at angle θ_i .

(a) Find the electric and magnetic fields in each region. (Hint: Use Cramer's rule to find the four unknown field amplitudes in terms of $E_{i.}$)



(b) For what range of incident angle do we have uniform or nonuniform plane waves through the middle region?

(c) What is the transmitted time-average power density with uniform or nonuniform plane waves through the middle region. How can we have power flow through the middle region with nonuniform plane waves?

Section 7.10

30. Consider the various prisms shown.



(a) What is the minimum index of refraction n_1 necessary for no time-average power to be transmitted across the hypotenuse when the prisms are in free space, $n_2 = 1$, or water, $n_2 = 1.33$?

(b) At these values of refractive index, what are the exiting angles θ_{e} ?

31. A fish below the surface of water with index of refraction n = 1.33 sees a star that he measures to be at 30° from the normal. What is the star's actual angle from the normal?



32. A straight light pipe with refractive index n_1 has a dielectric coating with index n_2 added for protection. The light pipe is usually within free space so that n_3 is typically unity.



(a) Light within the pipe is incident upon the first interface at angle θ_1 . What are the angles θ_2 and θ_3 ?

(b) What value of θ_1 will make θ_3 just equal the critical angle for total internal reflection at the second interface?

(c) How does this value differ from the critical angle if the coating was not present so that n_1 was directly in contact with n_3 ?

(d) If we require that total reflection occur at the first interface, what is the allowed range of incident angle θ_1 . Must the coating have a larger or smaller index of refraction than the light pipe?

33. A spherical piece of glass of radius R has refractive index n.

(a) A vertical light ray is incident at the distance x (x < R) from the vertical diameter. At what distance y from the top of the sphere will the light ray intersect the vertical diameter? For what range of n and x will the refracted light intersect the vertical diameter within the sphere?



(b) A vertical light beam of radius αR ($\alpha < 1$) is incident upon a hemisphere of this glass that rests on a table top. What is the radius R' of the light on the table?

chapter 8

guided electromagnetic waves The uniform plane wave solutions developed in Chapter 7 cannot in actuality exist throughout all space, as an infinite amount of energy would be required from the sources. However, TEM waves can also propagate in the region of finite volume between electrodes. Such electrode structures, known as transmission lines, are used for electromagnetic energy flow from power (60 Hz) to microwave frequencies, as delay lines due to the finite speed c of electromagnetic waves, and in pulse forming networks due to reflections at the end of the line. Because of the electrode boundaries, more general wave solutions are also permitted where the electric and magnetic fields are no longer perpendicular. These new solutions also allow electromagnetic power flow in closed single conductor structures known as waveguides.

8-1 THE TRANSMISSION LINE EQUATIONS

8-1-1 The Parallel Plate Transmission Line

The general properties of transmission lines are illustrated in Figure 8-1 by the parallel plate electrodes a small distance dapart enclosing linear media with permittivity ε and permeability μ . Because this spacing d is much less than the width w or length l, we neglect fringing field effects and assume that the fields only depend on the z coordinate.

The perfectly conducting electrodes impose the boundary conditions:

- (i) The tangential component of **E** is zero.
- (ii) The normal component of **B** (and thus **H** in the linear media) is zero.

With these constraints and the neglect of fringing near the electrode edges, the fields cannot depend on x or y and thus are of the following form:

$$\mathbf{E} = E_{\mathbf{x}}(z, t)\mathbf{i}_{\mathbf{x}}$$

$$\mathbf{H} = H_{\mathbf{y}}(z, t)\mathbf{i}_{\mathbf{y}}$$
(1)

which when substituted into Maxwell's equations yield



Figure 8-1 The simplest transmission line consists of two parallel perfectly conducting plates a small distance d apart.

$$\nabla \times \mathbf{E} = -\mu \frac{\partial \mathbf{H}}{\partial t} \Rightarrow \frac{\partial E_x}{\partial z} = -\mu \frac{\partial H_y}{\partial t}$$

$$\nabla \times \mathbf{H} = \varepsilon \frac{\partial \mathbf{E}}{\partial t} \Rightarrow \frac{\partial H_y}{\partial z} = -\varepsilon \frac{\partial E_x}{\partial t}$$
(2)

We recognize these equations as the same ones developed for plane waves in Section 7-3-1. The wave solutions found there are also valid here. However, now it is more convenient to introduce the circuit variables of voltage and current along the transmission line, which will depend on z and t.

Kirchoff's voltage and current laws will not hold along the transmission line as the electric field in (2) has nonzero curl and the current along the electrodes will have a divergence due to the time varying surface charge distribution, $\sigma_f = \pm \varepsilon E_x(z, t)$. Because **E** has a curl, the voltage difference measured between any two points is not unique, as illustrated in Figure 8-2, where we see time varying magnetic flux passing through the contour L_1 . However, no magnetic flux passes through the path L_2 , where the potential difference is measured between the two electrodes at the same value of z, as the magnetic flux is parallel to the surface. Thus, the voltage can be uniquely defined between the two electrodes at the same value of z:

$$v(z, t) = \int_{\substack{1\\z=\text{const}}}^{2} \mathbf{E} \cdot \mathbf{dl} = E_{x}(z, t)d \qquad (3)$$



Figure 8-2 The potential difference measured between any two arbitrary points at different positions z_1 and z_2 on the transmission line is not unique—the line integral L_1 of the electric field is nonzero since the contour has magnetic flux passing through it. If the contour L_2 lies within a plane of constant z such as at z_3 , no magnetic flux passes through it so that the voltage difference between the two electrodes at the same value of z is unique.

Similarly, the tangential component of **H** is discontinuous at each plate by a surface current $\pm \mathbf{K}$. Thus, the total current i(z, t) flowing in the z direction on the lower plate is

$$i(z, t) = K_z w = H_y w \tag{4}$$

Substituting (3) and (4) back into (2) results in the transmission line equations:

$$\frac{\partial v}{\partial z} = -L\frac{\partial i}{\partial t}$$

$$\frac{\partial i}{\partial z} = -C\frac{\partial v}{\partial t}$$
(5)

where L and C are the inductance and capacitance per unit length of the parallel plate structure:

$$L = \frac{\mu d}{w}$$
 henry/m, $C = \frac{\varepsilon w}{d}$ farad/m (6)

If both quantities are multiplied by the length of the line l, we obtain the inductance of a single turn plane loop if the line were short circuited, and the capacitance of a parallel plate capacitor if the line were open circuited.

It is no accident that the LC product

$$LC = \varepsilon \mu = 1/c^2 \tag{7}$$

is related to the speed of light in the medium.

8-1-2 General Transmission Line Structures

The transmission line equations of (5) are valid for any two-conductor structure of arbitrary shape in the transverse xy plane but whose cross-sectional area does not change along its axis in the z direction. L and C are the inductance and capacitance per unit length as would be calculated in the quasi-static limits. Various simple types of transmission lines are shown in Figure 8-3. Note that, in general, the field equations of (2) must be extended to allow for x and y components but still no z components:

$$\mathbf{E} = \mathbf{E}_T(\mathbf{x}, \mathbf{y}, \mathbf{z}, t) = E_{\mathbf{x}}\mathbf{i}_{\mathbf{x}} + E_{\mathbf{y}}\mathbf{i}_{\mathbf{y}}, \qquad E_{\mathbf{z}} = 0$$

$$\mathbf{H} = \mathbf{H}_T(\mathbf{x}, \mathbf{y}, \mathbf{z}, t) = H_{\mathbf{x}}\mathbf{i}_{\mathbf{x}} + H_{\mathbf{y}}\mathbf{i}_{\mathbf{y}}, \qquad H_{\mathbf{z}} = 0$$
(8)

We use the subscript T in (8) to remind ourselves that the fields lie purely in the transverse xy plane. We can then also distinguish between spatial derivatives along the z axis $(\partial/\partial z)$ from those in the transverse plane $(\partial/\partial x, \partial/\partial y)$:

$$\nabla \underbrace{=}_{i_{x}\frac{\partial}{\partial x}+i_{y}\frac{\partial}{\partial y}} + i_{z}\frac{\partial}{\partial z}$$

$$\tag{9}$$

We may then write Maxwell's equations as

$$\nabla_{T} \times \mathbf{E}_{T} + \frac{\partial}{\partial z} (\mathbf{i}_{z} \times \mathbf{E}_{T}) = -\mu \frac{\partial \mathbf{H}_{T}}{\partial t}$$

$$\nabla_{T} \times \mathbf{H}_{T} + \frac{\partial}{\partial z} (\mathbf{i}_{z} \times \mathbf{H}_{T}) = \varepsilon \frac{\partial \mathbf{E}_{T}}{\partial t}$$

$$\nabla_{T} \cdot \mathbf{E}_{T} = 0$$

$$\nabla_{T} \cdot \mathbf{H}_{T} = 0$$
(10)

The following vector properties for the terms in (10) apply:

- (i) $\nabla_T \times \mathbf{H}_T$ and $\nabla_T \times \mathbf{E}_T$ lie purely in the z direction.
- (ii) $\mathbf{i}_z \times \mathbf{E}_T$ and $\mathbf{i}_z \times \mathbf{H}_T$ lie purely in the xy plane.



Figure 8-3 Various types of simple transmission lines.

Thus, the equations in (10) may be separated by equating vector components:

$$\nabla_T \times \mathbf{E}_T = 0, \qquad \nabla_T \times \mathbf{H}_T = 0 \tag{11}$$

$$\nabla_T \cdot \mathbf{E}_T = 0, \qquad \nabla_T \cdot \mathbf{H}_T = 0 \tag{11}$$

$$\frac{\partial}{\partial z}(\mathbf{i}_{z} \times \mathbf{E}_{T}) = -\mu \frac{\partial \mathbf{H}_{T}}{\partial t} \Rightarrow \frac{\partial \mathbf{E}_{T}}{\partial z} = \mu \frac{\partial}{\partial t}(\mathbf{i}_{z} \times \mathbf{H}_{T})$$

$$\frac{\partial}{\partial z}(\mathbf{i}_{z} \times \mathbf{H}_{T}) = \varepsilon \frac{\partial \mathbf{E}_{T}}{\partial t}$$
(12)

where the Faraday's law equalities are obtained by crossing with i_z and expanding the double cross product

$$\mathbf{i}_{z} \times (\mathbf{i}_{z} \times \mathbf{E}_{T}) = \mathbf{i}_{z} (\mathbf{i}_{z} / \mathbf{E}_{T}) - \mathbf{E}_{T} (\mathbf{i}_{z} \cdot \mathbf{i}_{z}) = -\mathbf{E}_{T}$$
(13)

and remembering that $\mathbf{i}_z \cdot \mathbf{E}_T = 0$.

The set of equations in (11) tell us that the field dependences on the transverse coordinates are the same as if the system were static and source free. Thus, all the tools developed for solving static field solutions, including the twodimensional Laplace's equations and the method of images, can be used to solve for \mathbf{E}_T and \mathbf{H}_T in the transverse xy plane.

We need to relate the fields to the voltage and current defined as a function of z and t for the transmission line of arbitrary shape shown in Figure 8-4 as

$$v(z, t) = \int_{z=\text{const}}^{2} \mathbf{E}_{T} \cdot \mathbf{d}\mathbf{l}$$

$$i(z, t) = \oint_{\substack{\text{contour } L \\ \text{at constant } z \\ \text{enclosing the} \\ \text{inner conductor}}} \mathbf{H}_{T} \cdot \mathbf{d}\mathbf{s}$$
(14)

The related quantities of charge per unit length q and flux per unit length λ along the transmission line are

$$q(z, t) = \varepsilon \oint_{\substack{L \\ z = \text{const}}} \mathbf{E}_T \cdot \mathbf{n} \, ds$$

$$\lambda(z, t) = \mu \int_{\substack{1 \\ z = \text{const}}}^2 \mathbf{H}_T \cdot (\mathbf{i}_z \times \mathbf{d}\mathbf{l})$$
(15)

The capacitance and inductance per unit length are then defined as the ratios:

$$C = \frac{q(z, t)}{v(z, t)} = \frac{\varepsilon \oint_L \mathbf{E}_T \cdot \mathbf{ds}}{\int_1^2 \mathbf{E}_T \cdot \mathbf{dl}} \bigg|_{z=\text{const}}$$

$$L = \frac{\lambda(z, t)}{i(z, t)} = \frac{\mu \int_1^2 \mathbf{H}_T \cdot (\mathbf{i}_z \times \mathbf{dl})}{\oint_L \mathbf{H}_T \cdot \mathbf{ds}} \bigg|_{z=\text{const}}$$
(16)



Figure 8-4 A general transmission line has two perfect conductors whose crosssectional area does not change in the direction along its z axis, but whose shape in the transverse xy plane is arbitrary. The electric and magnetic fields are perpendicular, lie in the transverse xy plane, and have the same dependence on x and y as if the fields were static.

which are constants as the geometry of the transmission line does not vary with z. Even though the fields change with z, the ratios in (16) do not depend on the field amplitudes.

To obtain the general transmission line equations, we dot the upper equation in (12) with **dl**, which can be brought inside the derivatives since **dl** only varies with x and y and not z or t. We then integrate the resulting equation over a line at constant z joining the two electrodes:

$$\frac{\partial}{\partial z} \left(\int_{1}^{2} \mathbf{E}_{T} \cdot \mathbf{d} \mathbf{l} \right) = \frac{\partial}{\partial t} \left(\mu \int_{1}^{2} \left(\mathbf{i}_{z} \times \mathbf{H}_{T} \right) \cdot \mathbf{d} \mathbf{l} \right)$$
$$= -\frac{\partial}{\partial t} \left(\mu \int_{1}^{2} \mathbf{H}_{T} \cdot \left(\mathbf{i}_{z} \times \mathbf{d} \mathbf{l} \right) \right)$$
(17)

where the last equality is obtained using the scalar triple product allowing the interchange of the dot and the cross:

$$(\mathbf{i}_{z} \times \mathbf{H}_{T}) \cdot \mathbf{d}\mathbf{l} = -(\mathbf{H}_{T} \times \mathbf{i}_{z}) \cdot \mathbf{d}\mathbf{l} = -\mathbf{H}_{T} \cdot (\mathbf{i}_{z} \times \mathbf{d}\mathbf{l})$$
(18)

We recognize the left-hand side of (17) as the z derivative of the voltage defined in (14), while the right-hand side is the negative time derivative of the flux per unit length defined in (15):

$$\frac{\partial v}{\partial z} = -\frac{\partial \lambda}{\partial t} = -L\frac{\partial i}{\partial t}$$
(19)

We could also have derived this last relation by dotting the upper equation in (12) with the normal **n** to the inner

conductor and then integrating over the contour L surrounding the inner conductor:

$$\frac{\partial}{\partial z} \left(\oint_{L} \mathbf{n} \cdot \mathbf{E}_{T} \, ds \right) = \frac{\partial}{\partial t} \left(\mu \oint_{L} \mathbf{n} \cdot (\mathbf{i}_{z} \times \mathbf{H}_{T}) \, ds \right) = -\frac{\partial}{\partial t} \left(\mu \oint_{L} \mathbf{H}_{T} \cdot \mathbf{ds} \right)$$
(20)

where the last equality was again obtained by interchanging the dot and the cross in the scalar triple product identity:

$$\mathbf{n} \cdot (\mathbf{i}_z \times \mathbf{H}_T) = (\mathbf{n} \times \mathbf{i}_z) \cdot \mathbf{H}_T = -\mathbf{H}_T \cdot \mathbf{ds}$$
(21)

The left-hand side of (20) is proportional to the charge per unit length defined in (15), while the right-hand side is proportional to the current defined in (14):

$$\frac{1}{\varepsilon}\frac{\partial q}{\partial z} = -\mu \frac{\partial i}{\partial t} \Rightarrow C \frac{\partial v}{\partial z} = -\varepsilon \mu \frac{\partial i}{\partial t}$$
(22)

Since (19) and (22) must be identical, we obtain the general result previously obtained in Section 6-5-6 that the inductance and capacitance per unit length of any arbitrarily shaped transmission line are related as

$$LC = \varepsilon \mu \tag{23}$$

We obtain the second transmission line equation by dotting the lower equation in (12) with **dl** and integrating between electrodes:

$$\frac{\partial}{\partial t} \left(\varepsilon \int_{1}^{2} \mathbf{E}_{T} \cdot \mathbf{d} \mathbf{l} \right) = \frac{\partial}{\partial z} \left(\int_{1}^{2} \left(\mathbf{i}_{z} \times \mathbf{H}_{T} \right) \cdot \mathbf{d} \mathbf{l} \right) = -\frac{\partial}{\partial z} \left(\int_{1}^{2} \mathbf{H}_{T} \cdot \left(\mathbf{i}_{z} \times \mathbf{d} \mathbf{l} \right) \right)$$
(24)

to yield from (14)-(16) and (23)

$$\varepsilon \frac{\partial v}{\partial t} = -\frac{1}{\mu} \frac{\partial \lambda}{\partial z} = -\frac{L}{\mu} \frac{\partial i}{\partial z} \Rightarrow \frac{\partial i}{\partial z} = -C \frac{\partial v}{\partial t}$$
(25)

EXAMPLE 8-1 THE COAXIAL TRANSMISSION LINE

Consider the coaxial transmission line shown in Figure 8-3 composed of two perfectly conducting concentric cylinders of radii a and b enclosing a linear medium with permittivity ε and permeability μ . We solve for the transverse dependence of the fields as if the problem were static, independent of time. If the voltage difference between cylinders is v with the inner cylinder carrying a total current i the static fields are

$$E_{\rm r} = \frac{v}{{\rm r}\ln{(b/a)}}, \qquad H_{\phi} = \frac{i}{2\pi {\rm r}}$$

The surface charge per unit length q and magnetic flux per unit length λ are

$$q = \varepsilon E_{\mathbf{r}}(\mathbf{r} = a)2\pi a = \frac{2\pi\varepsilon v}{\ln(b/a)}$$
$$\lambda = \int_{a}^{b} \mu H_{\phi} d\mathbf{r} = \frac{\mu i}{2\pi} \ln \frac{b}{a}$$

so that the capacitance and inductance per unit length of this structure are

$$C = \frac{q}{v} = \frac{2\pi\varepsilon}{\ln(b/a)}, \qquad L = \frac{\lambda}{i} = \frac{\mu}{2\pi} \ln \frac{b}{a}$$

where we note that as required

$$LC = \varepsilon \mu$$

Substituting E_r and H_{ϕ} into (12) yields the following transmission line equations:

$$\frac{\partial E_r}{\partial z} = -\mu \frac{\partial H_{\phi}}{\partial t} \Rightarrow \frac{\partial v}{\partial z} = -L \frac{\partial i}{\partial t}$$
$$\frac{\partial H_{\phi}}{\partial z} = -\varepsilon \frac{\partial E_r}{\partial t} \Rightarrow \frac{\partial i}{\partial z} = -C \frac{\partial v}{\partial t}$$

8-1-3 Distributed Circuit Representation

Thus far we have emphasized the field theory point of view from which we have derived relations for the voltage and current. However, we can also easily derive the transmission line equations using a distributed equivalent circuit derived from the following criteria:

- (i) The flow of current through a lossless medium between two conductors is entirely by displacement current, in exactly the same way as a capacitor.
- (ii) The flow of current along lossless electrodes generates a magnetic field as in an inductor.

Thus, we may discretize the transmission line into many small incremental sections of length Δz with series inductance $L \Delta z$ and shunt capacitance $C \Delta z$, where L and C are the inductance and capacitance per unit lengths. We can also take into account the small series resistance of the electrodes $R \Delta z$, where R is the resistance per unit length (ohms per meter) and the shunt conductance loss in the dielectric $G \Delta z$, where G is the conductance per unit length (siemens per meter). If the transmission line and dielectric are lossless, R = 0, G = 0. The resulting equivalent circuit for a lossy transmission line shown in Figure 8-5 shows that the current at $z + \Delta z$ and z differ by the amount flowing through the shunt capacitance and conductance:

$$i(z, t) - i(z + \Delta z, t) = C \Delta z \frac{\partial v(z, t)}{\partial t} + G \Delta z v(z, t)$$
(26)

Similarly, the voltage difference at $z + \Delta z$ from z is due to the drop across the series inductor and resistor:

$$v(z, t) - v(z + \Delta z, t) = L \Delta z \frac{\partial i(z + \Delta z, t)}{\partial t} + i(z + \Delta z, t) R \Delta z \qquad (27)$$

By dividing (26) and (27) through by Δz and taking the limit as $\Delta z \rightarrow 0$, we obtain the lossy transmission line equations:

$$\lim_{\Delta z \to 0} \frac{i(z + \Delta z, t) - i(z, t)}{\Delta z} = \frac{\partial i}{\partial z} = -C\frac{\partial v}{\partial t} - Gv$$

$$\lim_{\Delta z \to 0} \frac{v(z + \Delta z, t) - v(z, t)}{\Delta z} = \frac{\partial v}{\partial z} = -L\frac{\partial i}{\partial t} - iR$$
(28)

which reduce to (19) and (25) when R and G are zero.

8-1-4 Power Flow

Multiplying the upper equation in (28) by v and the lower by i and then adding yields the circuit equivalent form of Poynting's theorem:

$$\frac{\partial}{\partial z}(vi) = -\frac{\partial}{\partial t}(\frac{1}{2}Cv^2 + \frac{1}{2}Li^2) - Gv^2 - i^2R$$
(29)



Figure 8-5 Distributed circuit model of a transmission line including small series and shunt resistive losses.

The power flow vi is converted into energy storage $(\frac{1}{2}Cv^2 + \frac{1}{2}Li^2)$ or is dissipated in the resistance and conductance per unit lengths.

From the fields point of view the total electromagnetic power flowing down the transmission line at any position z is

$$P(z, t) = \int_{S} (\mathbf{E}_{T} \times \mathbf{H}_{T}) \cdot \mathbf{i}_{z} dS = \int_{S} \mathbf{E}_{T} \cdot (\mathbf{H}_{T} \times \mathbf{i}_{z}) dS \quad (30)$$

where S is the region between electrodes in Figure 8-4. Because the transverse electric field is curl free, we can define the scalar potential

$$\nabla \times \mathbf{E}_T = \mathbf{0} \Rightarrow \mathbf{E}_T = -\nabla_T V \tag{31}$$

so that (30) can be rewritten as

$$P(z, t) = \int_{S} (\mathbf{i}_{z} \times \mathbf{H}_{T}) \cdot \nabla_{T} V dS$$
(32)

It is useful to examine the vector expansion

$$\nabla_{T} \cdot [V(\mathbf{i}_{z} \times \mathbf{H}_{T})] = (\mathbf{i}_{z} \times \mathbf{H}_{T}) \cdot \nabla_{T} V + V \nabla_{T} \cdot (\mathbf{i}_{z} \times \overset{\rightarrow}{\mathbf{H}}_{T})$$
(33)

where the last term is zero because i_z is a constant vector and H_T is also curl free:

$$\nabla_T \cdot (\mathbf{i}_z \times \mathbf{H}_T) = \mathbf{H}_T \cdot (\nabla_T \times \mathbf{i}_z) - \mathbf{i}_z \cdot (\nabla_T \times \mathbf{H}_T) = 0 \quad (34)$$

Then (32) can be converted to a line integral using the twodimensional form of the divergence theorem:

$$P(z, t) = \int_{S} \nabla_{T} \cdot [V(\mathbf{i}_{z} \times \mathbf{H}_{T})] dS$$

$$= -\int_{S} V(\mathbf{i}_{z} \times \mathbf{H}_{T}) \cdot \mathbf{n} ds$$
contours on
the surfaces of
both electrodes
$$(35)$$

where the line integral is evaluated at constant z along the surface of both electrodes. The minus sign arises in (35) because **n** is defined inwards in Figure 8-4 rather than outwards as is usual in the divergence theorem. Since we are free to pick our zero potential reference anywhere, we take the outer conductor to be at zero voltage. Then the line integral in (35) is only nonzero over the inner conductor,

where V = v:

$$P(z, t) = -v \oint (\mathbf{i}_{z} \times \mathbf{H}_{T}) \cdot \mathbf{n} \, ds$$

inner
inner
conductor

$$= v \oint (\mathbf{H}_{T} \times \mathbf{i}_{z}) \cdot \mathbf{n} \, ds$$

inner
conductor

$$= v \oint \mathbf{H}_{T} \cdot (\mathbf{i}_{z} \times \mathbf{n}) \, ds$$

inner
inner
conductor

$$= v \oint \mathbf{H}_{T} \cdot \mathbf{ds}$$

inner
inner
conductor

$$= v i \qquad (36)$$

where we realized that $(i_z \times n) ds = ds$, defined in Figure 8-4 if L lies along the surface of the inner conductor. The electromagnetic power flowing down a transmission line just equals the circuit power.

8-1-5 The Wave Equation

Restricting ourselves now to lossless transmission lines so that R = G = 0 in (28), the two coupled equations in voltage and current can be reduced to two single wave equations in v and i:

$$\frac{\partial^2 v}{\partial t^2} = c^2 \frac{\partial^2 v}{\partial z^2}$$

$$\frac{\partial^2 i}{\partial t^2} = c^2 \frac{\partial^2 i}{\partial z^2}$$
(37)

where the speed of the waves is

$$c = \frac{1}{\sqrt{LC}} = \frac{1}{\sqrt{\varepsilon\mu}} \,\mathrm{m/sec} \tag{38}$$

As we found in Section 7-3-2 the solutions to (37) are propagating waves in the $\pm z$ directions at the speed c:

$$v(z, t) = V_{+}(t - z/c) + V_{-}(t + z/c)$$

$$i(z, t) = I_{+}(t - z/c) + I_{-}(t + z/c)$$
(39)

where the functions V_+ , V_- , I_+ , and I_- are determined by boundary conditions imposed by sources and transmission

line terminations. By substituting these solutions back into (28) with R = G = 0, we find the voltage and current functions related as

$$V_{+} = I_{+}Z_{0}$$

$$V_{-} = -I_{-}Z_{0}$$
(40)

where

$$Z_0 = \sqrt{L/C} \quad \text{ohm} \tag{41}$$

is known as the characteristic impedance of the transmission line, analogous to the wave impedance η in Chapter 7. Its inverse $Y_0 = 1/Z_0$ is also used and is termed the characteristic admittance. In practice, it is difficult to measure L and C of a transmission line directly. It is easier to measure the wave speed c and characteristic impedance Z_0 and then calculate L and C from (38) and (41).

The most useful form of the transmission line solutions of (39) that we will use is

$$v(z, t) = V_{+}(t - z/c) + V_{-}(t + z/c)$$

$$i(z, t) = Y_{0}[V_{+}(t - z/c) - V_{-}(t + z/c)]$$
(42)

Note the complete duality between these voltage-current solutions and the plane wave solutions in Section 7-3-2 for the electric and magnetic fields.

8-2 TRANSMISSION LINE TRANSIENT WAVES

The easiest way to solve for transient waves on transmission lines is through use of physical reasoning as opposed to mathematical rigor. Since the waves travel at a speed c, once generated they cannot reach any position z until a time z/clater. Waves traveling in the positive z direction are described by the function $V_+(t-z/c)$ and waves traveling in the -zdirection by $V_-(t+z/c)$. However, at any time t and position z, the voltage is equal to the sum of both solutions while the current is proportional to their difference.

8-2-1 Transients on Infinitely Long Transmission Lines

The transmission line shown in Figure 8-6*a* extends to infinity in the positive *z* direction. A time varying voltage source V(t) that is turned on at t = 0 is applied at z = 0 to the line which is initially unexcited. A positively traveling wave $V_+(t-z/c)$ propagates away from the source. There is no negatively traveling wave, $V_-(t+z/c) = 0$. These physical





(c)



Figure 8-6 (a) A semi-infinite transmission line excited by a voltage source at z = 0. (b) To the source, the transmission line looks like a resistor Z_0 equal to the characteristic impedance. (c) The spatial distribution of the voltage v(z, t) at various times for a staircase pulse of V(t). (d) If the voltage source is applied to the transmission line through a series resistance R_n the voltage across the line at z = 0 is given by the voltage divider relation.

arguments are verified mathematically by realizing that at t=0 the voltage and current are zero for z > 0,

$$v(z, t = 0) = V_{+}(-z/c) + V_{-}(z/c) = 0$$

$$i(z, t = 0) = Y_{0}[V_{+}(-z/c) - V_{-}(z/c)] = 0$$
(1)

which only allows the trivial solutions

$$V_{+}(-z/c) = 0, \quad V_{-}(z/c) = 0$$
 (2)

Since z can only be positive, whenever the argument of V_+ is negative and of V_- positive, the functions are zero. Since t can only be positive, the argument of $V_-(t+z/c)$ is always positive

so that the function is always zero. The argument of $V_+(t-z/c)$ can be positive, allowing a nonzero solution if t>z/c agreeing with our conclusions reached by physical arguments.

With $V_{-}(t + z/c) = 0$, the voltage and current are related as

$$v(z, t) = V_{+}(t - z/c)$$

$$i(z, t) = Y_{0}V_{+}(t - z/c)$$
(3)

The line voltage and current have the same shape as the source, delayed in time for any z by z/c with the current scaled in amplitude by Y_0 . Thus as far as the source is concerned, the transmission line looks like a resistor of value Z_0 yielding the equivalent circuit at z = 0 shown in Figure 8-6b. At z = 0, the voltage equals that of the source

$$v(0, t) = V(t) = V_{+}(t)$$
 (4)

If V(t) is the staircase pulse of total duration T shown in Figure 8-6c, the pulse extends in space over the spatial interval:

$$0 \le z \le ct, \qquad 0 \le t \le T$$

$$c(t-T) \le z \le ct, \qquad t > T$$
(5)

The analysis is the same even if the voltage source is in series with a source resistance R_s , as in Figure 8-6d. At z = 0 the transmission line still looks like a resistor of value Z_0 so that the transmission line voltage divides in the ratio given by the equivalent circuit shown:

$$v(z = 0, t) = \frac{Z_0}{R_s + Z_0} V(t) = V_+(t)$$

$$i(z = 0, t) = Y_0 V_+(t) = \frac{V(t)}{R_s + Z_0}$$
(6)

The total solution is then identical to that of (3) and (4) with the voltage and current amplitudes reduced by the voltage divider ratio $Z_0/(R_s + Z_0)$.

8-2-2 Reflections from Resistive Terminations

(a) Reflection Coefficient

All transmission lines must have an end. In Figure 8-7 we see a positively traveling wave incident upon a load resistor R_L at z = l. The reflected wave will travel back towards the source at z = 0 as a V_- wave. At the z = l end the following circuit



Figure 8-7 A V₊ wave incident upon the end of a transmission line with a load resistor R_L is reflected as a V₋ wave.

relations hold:

$$v(l, t) = V_{+}(t - l/c) + V_{-}(t + l/c)$$

= $i(l, t)R_{L}$
= $Y_{0}R_{L}[V_{+}(t - l/c) - V_{-}(t + l/c)]$ (7)

We then find the amplitude of the negatively traveling wave in terms of the incident positively traveling wave as

$$\Gamma_L = \frac{V_{-}(t+l/c)}{V_{+}(t-l/c)} = \frac{R_L - Z_0}{R_L + Z_0}$$
(8)

where Γ_L is known as the reflection coefficient that is of the same form as the reflection coefficient R in Section 7-6-1 for normally incident uniform plane waves on a dielectric.

The reflection coefficient gives us the relative amplitude of the returning V_{-} wave compared to the incident V_{+} wave. There are several important limits of (8):

- (i) If $R_L = Z_0$, the reflection coefficient is zero ($\Gamma_L = 0$) so that there is no reflected wave and the line is said to be matched.
- (ii) If the line is short circuited $(R_L = 0)$, then $\Gamma_L = -1$. The reflected wave is equal in amplitude but opposite in sign to the incident wave. In general, if $R_L < Z_0$, the reflected voltage wave has its polarity reversed.
- (iii) If the line is open circuited $(R_L = \infty)$, then $\Gamma_L = +1$. The reflected wave is identical to the incident wave. In general, if $R_L > Z_0$, the reflected voltage wave is of the same polarity as the incident wave.

(b) Step Voltage

A dc battery of voltage V_0 with series resistance R_s is switched onto the transmission line at t=0, as shown in Figure 8-8a. At z=0, the source has no knowledge of the





Figure 8-8 (a) A dc voltage V_0 is switched onto a resistively loaded transmission line through a source resistance R_s . (b) The equivalent circuits at z = 0 and z = l allow us to calculate the reflected voltage wave amplitudes in terms of the incident waves.

line's length or load termination, so as for an infinitely long line the transmission line looks like a resistor of value Z_0 to the source. There is no V₋ wave initially. The V₊ wave is determined by the voltage divider ratio of the series source resistance and transmission line characteristic impedance as given by (6).

This V₊ wave travels down the line at speed c where it is reflected at z = l for t > T, where T = l/c is the transit time for a wave propagating between the two ends. The new V₋ wave generated is related to the incident V₊ wave by the reflection coefficient Γ_L . As the V₊ wave continues to propagate in the positive z direction, the V₋ wave propagates back towards the source. The total voltage at any point on the line is equal to the sum of V₊ and V₋ while the current is proportional to their difference.

When the V₋ wave reaches the end of the transmission line at z=0 at time 2*T*, in general a new V₊ wave is generated, which can be found by solving the equivalent circuit shown in Figure 8-8*b*:

$$v(0, t) + i(0, t)R_{s} = V_{0} \Rightarrow V_{+}(0, t) + V_{-}(0, t) + Y_{0}R_{s}[V_{+}(0, t) - V_{-}(0, t)] = V_{0}$$
(9)

to yield

$$V_{+}(0, t) = \Gamma_{s} V_{-}(0, t) + \frac{Z_{0} V_{0}}{Z_{0} + R_{s}}, \qquad \Gamma_{s} = \frac{R_{s} - Z_{0}}{R_{s} + Z_{0}} \qquad (10)$$

where Γ_s is just the reflection coefficient at the source end. This new V₊ wave propagates towards the load again generating a new V₋ wave as the reflections continue.

If the source resistance is matched to the line, $R_s = Z_0$ so that $\Gamma_s = 0$, then V₊ is constant for all time and the steady state is reached for t > 2T. If the load was matched, the steady state is reached for t > T no matter the value of R_s . There are no further reflections from the end of a matched line. In Figure 8-9 we plot representative voltage and current spatial distributions for various times assuming the source is matched to the line for the load being matched, open, or short circuited.

(i) Matched Line

When $R_L = Z_0$ the load reflection coefficient is zero so that $V_+ = V_0/2$ for all time. The wavefront propagates down the line with the voltage and current being identical in shape. The system is in the dc steady state for $t \ge T$.



Figure 8-9 (a) A dc voltage is switched onto a transmission line with load resistance R_L through a source resistance R_i matched to the line. (b) Regardless of the load resistance, half the source voltage propagates down the line towards the load. If the load is also matched to the line $(R_L = Z_0)$, there are no reflections and the steady state of $v(z, t \ge T) = V_0/2$, $i(z, t \ge T) = Y_0V_0/2$ is reached for $t \ge T$. (c) If the line is short circuited $(R_L = 0)$, then $\Gamma_L = -1$ so that the V₊ and V₋ waves cancel for the voltage but add for the current wherever they overlap in space. Since the source end is matched, no further reflections arise at z = 0 so that $\Gamma_L = +1$, the V₊ and V₋ waves add for the voltage but cancel for the current.



Short circuited line, $R_L = 0$, $(v(z, t \ge 2T) = 0, i(z, t \ge 2T) = Y_0 V_0)$

(c)



Figure 8-9

(ii) Open Circuited Line

When $R_L = \infty$ the reflection coefficient is unity so that $V_+ = V_-$. When the incident and reflected waves overlap in space the voltages add to a stairstep pulse shape while the current is zero. For $t \ge 2T$, the voltage is V_0 everywhere on the line while the current is zero.

(iii) Short Circuited Line

When $R_L = 0$ the load reflection coefficient is -1 so that $V_+ = -V_-$. When the incident and reflected waves overlap in space, the total voltage is zero while the current is now a stairstep pulse shape. For $t \ge 2T$ the voltage is zero everywhere on the line while the current is V_0/Z_0 .

8-2-3 Approach to the dc Steady State

If the load end is matched, the steady state is reached after one transit time T = l/c for the wave to propagate from the source to the load. If the source end is matched, after one round trip 2T = 2l/c no further reflections occur. If neither end is matched, reflections continue on forever. However, for nonzero and noninfinite source and load resistances, the reflection coefficient is always less than unity in magnitude so that each successive reflection is reduced in amplitude. After a few round-trips, the changes in V₊ and V₋ become smaller and eventually negligible. If the source resistance is zero and the load resistance is either zero or infinite, the transient pulses continue to propagate back and forth forever in the lossless line, as the magnitude of the reflection coefficients are unity.

Consider again the dc voltage source in Figure 8-8a switched through a source resistance R_z at t=0 onto a transmission line loaded at its z = l end with a load resistor R_L . We showed in (10) that the V₊ wave generated at the z=0 end is related to the source and an incoming V₋ wave as

$$V_{+} = \Gamma_0 V_0 + \Gamma_s V_{-}, \qquad \Gamma_0 = \frac{Z_0}{R_s + Z_0}, \qquad \Gamma_s = \frac{R_s - Z_0}{R_s + Z_0}$$
(11)

Similarly, at z = l, an incident V₊ wave is converted into a V₋ wave through the load reflection coefficient:

$$V_{-} = \Gamma_L V_{+}, \qquad \Gamma_L = \frac{R_L - Z_0}{R_L + Z_0}$$
 (12)

We can now tabulate the voltage at z = l using the following reasoning:

- (i) For the time interval t < T the voltage at z = l is zero as no wave has yet reached the end.
- (ii) At z=0 for $0 \le t \le 2T$, $V_{-}=0$ resulting in a V_{+} wave emanating from z=0 with amplitude $V_{+}=\Gamma_{0}V_{0}$.
- (iii) When this V_+ wave reaches z = l, a V_- wave is generated with amplitude $V_- = \Gamma_L V_+$. The incident V_+ wave at z = l remains unchanged until another interval of 2*T*, whereupon the just generated V_- wave after being reflected from z = 0 as a new V_+ wave given by (11) again returns to z = l.
- (iv) Thus, the voltage at z = l only changes at times (2n 1)T, n = 1, 2, ..., while the voltage at z = 0 changes at times 2(n-1)T. The resulting voltage waveforms at the ends are stairstep patterns with steps at these times.

The *n*th traveling V_+ wave is then related to the source and the (n-1)th V_- wave at z = 0 as

$$\mathbf{V}_{+n} = \Gamma_0 \mathbf{V}_0 + \Gamma_s \mathbf{V}_{-(n-1)} \tag{13}$$

while the (n-1)th V₋ wave is related to the incident (n-1)th V₊ wave at z = l as

$$V_{-(n-1)} = \Gamma_L V_{+(n-1)}$$
(14)

Using (14) in (13) yields a single linear constant coefficient difference equation in V_{+n} :

$$\mathbf{V}_{+n} - \Gamma_s \Gamma_L \mathbf{V}_{+(n-1)} = \Gamma_0 V_0 \tag{15}$$

For a particular solution we see that V_{+n} being a constant satisfies (15):

$$V_{+n} = C \Rightarrow C(1 - \Gamma_s \Gamma_L) = \Gamma_0 V_0 \Rightarrow C = \frac{\Gamma_0}{1 - \Gamma_s \Gamma_L} V_0 \quad (16)$$

To this solution we can add any homogeneous solution assuming the right-hand side of (15) is zero:

$$V_{+n} - \Gamma_s \Gamma_L V_{+(n-1)} = 0 \tag{17}$$

We try a solution of the form

$$\mathbf{V}_{+n} = A\lambda^n \tag{18}$$

which when substituted into (17) requires

$$A\lambda^{n-1}(\lambda - \Gamma_s \Gamma_L) = 0 \Rightarrow \lambda = \Gamma_s \Gamma_L \tag{19}$$

The total solution is then a sum of the particular and homogeneous solutions:

$$V_{+n} = \frac{\Gamma_0}{1 - \Gamma_s \Gamma_L} V_0 + A \left(\Gamma_s \Gamma_L\right)^n \tag{20}$$

The constant A is found by realizing that the first transient wave is

$$\mathbf{V}_{+1} = \Gamma_0 V_0 = \frac{\Gamma_0}{1 - \Gamma_s \Gamma_L} V_0 + A(\Gamma_s \Gamma_L)$$
(21)

which requires A to be

$$A = -\frac{\Gamma_0 V_0}{1 - \Gamma_s \Gamma_L}$$
(22)

so that (20) becomes

$$V_{+n} = \frac{\Gamma_0 V_0}{1 - \Gamma_s \Gamma_L} [1 - (\Gamma_s \Gamma_L)^n]$$
(23)

Raising the index of (14) by one then gives the *n*th V_- wave as

$$\mathbf{V}_{-n} = \Gamma_L \mathbf{V}_{+n} \tag{24}$$

so that the total voltage at z = l after *n* reflections at times (2n-1)T, n = 1, 2, ..., is

$$V_{n} = V_{+n} + V_{-n} = \frac{V_{0}\Gamma_{0}(1+\Gamma_{L})}{1-\Gamma_{s}\Gamma_{L}} [1-(\Gamma_{s}\Gamma_{L})^{n}]$$
(25)

or in terms of the source and load resistances

$$V_n = \frac{R_L}{R_L + R_s} V_0 [1 - (\Gamma_s \Gamma_L)^n]$$
(26)

The steady-state results as $n \rightarrow \infty$. If either R_s or R_L are nonzero or noninfinite, the product of $\Gamma_s \Gamma_L$ must be less than unity. Under these conditions

$$\lim_{\substack{n \to \infty \\ ||\Gamma_i \Gamma_L| < 1\rangle}} (\Gamma_s \Gamma_L)^n = 0$$
(27)

so that in the steady state

$$\lim_{n \to \infty} \mathbf{V}_n = \frac{R_L}{R_s + R_L} \mathbf{V}_0 \tag{28}$$

which is just the voltage divider ratio as if the transmission line was just a pair of zero-resistance connecting wires. Note also that if either end is matched so that either Γ_s or Γ_L is zero, the voltage at the load end is immediately in the steady state after the time T.

In Figure 8-10 the load is plotted versus time with $R_s = 0$ and $R_L = 3Z_0$ so that $\Gamma_s \Gamma_L = -\frac{1}{2}$ and with $R_L = \frac{1}{3}Z_0$ so that



Figure 8-10 The load voltage as a function of time when $R_s = 0$ and $R_L = 3Z_0$ so that $\Gamma_s \Gamma_L = -\frac{1}{2}$ (solid) and with $R_L = \frac{1}{3}Z_0$ so that $\Gamma_s \Gamma_L = \frac{1}{2}$ (dashed). The dc steady state is the same as if the transmission line were considered a pair of perfectly conducting wires in a circuit.

 $\Gamma_s \Gamma_L = +\frac{1}{2}$. Then (26) becomes

$$V_{n} = \begin{cases} V_{0} [1 - (-\frac{1}{2})^{n}], & R_{L} = 3Z_{0} \\ V_{0} [1 - (\frac{1}{2})^{n}], & R_{L} = \frac{1}{5}Z_{0} \end{cases}$$
(29)

The step changes in load voltage oscillate about the steadystate value $V_{\infty} = V_0$. The steps rapidly become smaller having less than one-percent variation for n > 7.

If the source resistance is zero and the load resistance is either zero or infinite (short or open circuits), a lossless transmission line never reaches a dc steady state as the limit of (27) does not hold with $\Gamma_s\Gamma_L = \pm 1$. Continuous reflections with no decrease in amplitude results in pulse waveforms for all time. However, in a real transmission line, small losses in the conductors and dielectric allow a steady state to be eventually reached.

Consider the case when $R_s = 0$ and $R_L = \infty$ so that $\Gamma_s \Gamma_L = -1$. Then from (26) we have

$$\mathbf{V}_{n} = \begin{cases} 0, & n \text{ even} \\ 2 V_{0}, & n \text{ odd} \end{cases}$$
(30)

which is sketched in Figure 8-11a.

For any source and load resistances the current through the load resistor at z = l is

$$I_{n} = \frac{V_{n}}{R_{L}} = \frac{V_{0}\Gamma_{0}(1+\Gamma_{L})}{R_{L}(1-\Gamma_{s}\Gamma_{L})}[1-(\Gamma_{s}\Gamma_{L})^{n}]$$
$$= \frac{2V_{0}\Gamma_{0}}{R_{L}+Z_{0}}\frac{[1-(\Gamma_{s}\Gamma_{L})^{n}]}{(1-\Gamma_{s}\Gamma_{L})}$$
(31)

If both R_s and R_L are zero so that $\Gamma_s\Gamma_L = 1$, the short circuit current in (31) is in the indeterminate form 0/0, which can be evaluated using l'Hôpital's rule:

$$\lim_{\Gamma_{*}\Gamma_{L} \to 1} I_{n} = \frac{2V_{0}\Gamma_{0}}{R_{L} + Z_{0}} \frac{[-n(\Gamma_{*}\Gamma_{L})^{n-1}]}{(-1)}$$
$$= \frac{2V_{0}n}{Z_{0}}$$
(32)

As shown by the solid line in Figure 8-11b, the current continually increases in a stepwise fashion. As n increases to infinity, the current also becomes infinite, which is expected for a battery connected across a short circuit.

8-2-4 Inductors and Capacitors as Quasi-static Approximations to Transmission Lines

If the transmission line was one meter long with a free space dielectric medium, the round trip transit time 2T = 2l/c



Figure 8-11 The (a) open circuit voltage and (b) short circuit current at the z = l end of the transmission line for $R_r = 0$. No dc steady state is reached because the system is lossless. If the short circuited transmission line is modeled as an inductor in the quasi-static limit, a step voltage input results in a linearly increasing current (shown dashed). The exact transmission line response is the solid staircase waveform.

is approximately 6 nsec. For many circuit applications this time is so fast that it may be considered instantaneous. In this limit the quasi-static circuit element approximation is valid.

For example, consider again the short circuited transmission line $(R_L = 0)$ of length l with zero source resistance. In the magnetic quasi-static limit we would call the structure an inductor with inductance Ll (remember, L is the inductance per unit length) so that the terminal voltage and current are related as

$$v = (Ll)\frac{di}{dt} \tag{33}$$

If a constant voltage V_0 is applied at t=0, the current is obtained by integration of (33) as

$$i = \frac{V_0}{Ll}t \tag{34}$$

where we use the initial condition of zero current at t = 0. The linear time dependence of the current, plotted as the dashed line in Figure 8-11b, approximates the rising staircase waveform obtained from the exact transmission line analysis of (32).

Similarly, if the transmission line were open circuited with $R_L = \infty$, it would be a capacitor of value Cl in the electric quasi-static limit so that the voltage on the line charges up through the source resistance R_s with time constant $\tau = R_s Cl$ as

$$v(t) = V_0(1 - e^{-t/\tau}) \tag{35}$$

The exact transmission line voltage at the z = l end is given by (26) with $R_L = \infty$ so that $\Gamma_L = 1$:

$$V_n = V_0(1 - \Gamma_s^n) \tag{36}$$

where the source reflection coefficient can be written as

$$\Gamma_{s} = \frac{R_{s} - Z_{0}}{R_{s} + Z_{0}}$$
$$= \frac{R_{s} - \sqrt{L/C}}{R_{s} + \sqrt{L/C}}$$
(37)

If we multiply the numerator and denominator of (37) through by Cl, we have

$$\Gamma_{s} = \frac{R_{s}Cl - l\sqrt{LC}}{R_{s}Cl + l\sqrt{LC}}$$
$$= \frac{\tau - T}{\tau + T} = \frac{1 - T/\tau}{1 + T/\tau}$$
(38)

where

$$T = l\sqrt{LC} = l/c \tag{39}$$

For the quasi-static limit to be valid, the wave transit time T must be much faster than any other time scale of interest so that $T/\tau \ll 1$. In Figure 8-12 we plot (35) and (36) for two values of T/τ and see that the quasi-static and transmission line results approach each other as T/τ . becomes small.

When the roundtrip wave transit time is so small compared to the time scale of interest so as to appear to be instantaneous, the circuit treatment is an excellent approximation.



Figure 8-12 The open circuit voltage at z = l for a step voltage applied at t = 0 through a source resistance R, for various values of T/τ , which is the ratio of propagation time T = l/c to quasi-static charging time $\tau = R_s Cl$. The dashed curve shows the exponential rise obtained by a circuit analysis assuming the open circuited transmission line is a capacitor.

If this propagation time is significant, then the transmission line equations must be used.

8-2-5 Reflections from Arbitrary Terminations

For resistive terminations we have been able to relate reflected wave amplitudes in terms of an incident wave amplitude through the use of a reflection coefficient because the voltage and current in the resistor are algebraically related. For an arbitrary termination, which may include any component such as capacitors, inductors, diodes, transistors, or even another transmission line with perhaps a different characteristic impedance, it is necessary to solve a circuit problem at the end of the line. For the arbitrary element with voltage V_L and current I_L at z = l, shown in Figure 8-13*a*, the voltage and current at the end of line are related as

$$v(z = l, t) = V_L(t) = V_+(t - l/c) + V_-(t + l/c)$$
(40)

$$i(z = l, t) = I_L(t) = Y_0[V_+(t - l/c) - V_-(t + l/c)]$$
(41)

We assume that we know the incident V_+ wave and wish to find the reflected V_- wave. We then eliminate the unknown V_- in (40) and (41) to obtain

$$2V_{+}(t - l/c) = V_{L}(t) + I_{L}(t)Z_{0}$$
(42)

which suggests the equivalent circuit in Figure 8-13b.

For a particular lumped termination we solve the equivalent circuit for $V_L(t)$ or $I_L(t)$. Since $V_+(t-l/c)$ is already known as it is incident upon the termination, once $V_L(t)$ or



Figure 8-13 A transmission line with an (a) arbitrary load at the z = l end can be analyzed from the equivalent circuit in (b). Since V_+ is known, calculation of the load current or voltage yields the reflected wave V_- .

 $I_L(t)$ is calculated from the equivalent circuit, $V_{-}(t+l/c)$ can be calculated as $V_{-} = V_L - V_{+}$.

For instance, consider the lossless transmission lines of length l shown in Figure 8-14*a* terminated at the end with either a lumped capacitor C_L or an inductor L_L . A step voltage at t=0 is applied at z=0 through a source resistor matched to the line.

The source at z = 0 is unaware of the termination at z = luntil a time 2*T*. Until this time it launches a V₊ wave of amplitude V₀/2. At z = l, the equivalent circuit for the capacitive termination is shown in Figure 8-14*b*. Whereas resistive terminations just altered wave amplitudes upon reflection, inductive and capacitive terminations introduce differential equations.

From (42), the voltage across the capacitor v_c obeys the differential equation

$$Z_0 C_L \frac{dv_c}{dt} + v_c = 2V_+ = V_0, \qquad t > T$$
(43)

with solution

$$v_c(t) = V_0[1 - e^{-(t-T)/Z_0 C_L}], \quad t > T$$
(44)

Note that the voltage waveform plotted in Figure 8-14b begins at time T = l/c.

Thus, the returning V_{-} wave is given as

$$V_{-} = v_{c} - V_{+} = V_{0}/2 + V_{0} e^{-(t-T)/Z_{0}C_{L}}$$
(45)

This reflected wave travels back to z = 0, where no further reflections occur since the source end is matched. The current at z = l is then

$$i_{c} = C_{L} \frac{dv_{c}}{dt} \approx \frac{V_{0}}{Z_{0}} e^{-(t-T)/Z_{0}C_{L}}, \qquad t > T$$
(46)

and is also plotted in Figure 8-14b.













(b)

Figure 8-14 (a) A step voltage is applied to transmission lines loaded at z = l with a capacitor C_L or inductor L_L . The load voltage and current are calculated from the (b) resistive-capacitive or (c) resistive-inductive equivalent circuits at z = l to yield exponential waveforms with respective time constants $\tau = Z_0 C_L$ and $\tau = L_L/Z_0$ as the solutions approach the dc steady state. The waveforms begin after the initial V₊ wave arrives at z = l after a time T = l/c. There are no further reflections as the source end is matched.

*59*4

 V_0
If the end at z=0 were not matched, a new V₊ would be generated. When it reached z=l, we would again solve the *RC* circuit with the capacitor now initially charged. The reflections would continue, eventually becoming negligible if R_s is nonzero.

Similarly, the governing differential equation for the inductive load obtained from the equivalent circuit in Figure 8-14c is

$$L_L \frac{di_L}{dt} + i_L Z_0 = 2V_+ = V_0, \qquad t > T$$
(47)

with solution

$$i_L = \frac{V_0}{Z_0} (1 - e^{-(t-T)Z_0/L_L}), \qquad t > T$$
(48)

The voltage across the inductor is

$$v_L = L_L \frac{di_L}{dt} = V_0 \, e^{-(t-T)Z_0/L_L}, \qquad t > T \tag{49}$$

Again since the end at z=0 is matched, the returning Vwave from z = l is not reflected at z = 0. Thus the total voltage and current for all time at z = l is given by (48) and (49) and is sketched in Figure 8-14c.

8-3 SINUSOIDAL TIME VARIATIONS

8-3-1 Solutions to the Transmission Line Equations

Often transmission lines are excited by sinusoidally varying sources so that the line voltage and current also vary sinusoidally with time:

$$v(z, t) = \operatorname{Re} \left[\hat{v}(z) \ e^{j\omega t} \right]$$

$$i(z, t) = \operatorname{Re} \left[\hat{i}(z) \ e^{j\omega t} \right]$$
 (1)

Then as we found for TEM waves in Section 7-4, the voltage and current are found from the wave equation solutions of Section 8-1-5 as linear combinations of exponential functions with arguments t-z/c and t+z/c:

$$v(z, t) = \operatorname{Re} \left[\hat{V}_{+} e^{j\omega(t-z/c)} + \hat{V}_{-} e^{j\omega(t+z/c)} \right]$$

$$i(z, t) = Y_{0} \operatorname{Re} \left[\hat{V}_{+} e^{j\omega(t-z/c)} - \hat{V}_{-} e^{j\omega(t+z/c)} \right]$$

(2)

Now the phasor amplitudes \hat{V}_+ and \hat{V}_- are complex numbers and do not depend on z or t.

By factoring out the sinusoidal time dependence in (2), the spatial dependences of the voltage and current are

$$\hat{v}(z) = \hat{V}_{+} e^{-jkz} + \hat{V}_{-} e^{+jkz}$$

$$\hat{i}(z) = Y_{0}(\hat{V}_{+} e^{-jkz} - \hat{V}_{-} e^{+jkz})$$
(3)

where the wavenumber is again defined as

$$k = \omega/c \tag{4}$$

8-3-2 Lossless Terminations

(a) Short Circuited Line

The transmission line shown in Figure 8-15*a* is excited by a sinusoidal voltage source at z = -l imposing the boundary condition

$$v(z = -l, t) = V_0 \cos \omega t$$

= Re $(V_0 e^{j\omega t}) \Rightarrow \hat{v}(z = -l) = V_0 = \hat{V}_+ e^{jkl} + \hat{V}_- e^{-jkl}$
(5)

Note that to use (3) we must write all sinusoids in complex notation. Then since all time variations are of the form $e^{j\omega t}$, we may suppress writing it each time and work only with the spatial variations of (3).

Because the transmission line is short circuited, we have the additional boundary condition

$$v(z=0, t) = 0 \Rightarrow \hat{v}(z=0) = 0 = \hat{V}_{+} + \hat{V}_{-}$$
 (6)

which when simultaneously solved with (5) yields

$$\hat{V}_{+} = -\hat{V}_{-} = \frac{V_{0}}{2j \sin kl}$$
(7)

The spatial dependences of the voltage and current are then

$$\hat{v}(z) = \frac{V_0(e^{-jkz} - e^{jkz})}{2j\sin kl} = -\frac{V_0\sin kz}{\sin kl}$$

$$\hat{v}(z) = \frac{V_0Y_0(e^{-jkz} + e^{+jkz})}{2j\sin kl} = -j\frac{V_0Y_0\cos kz}{\sin kl}$$
(8)

The instantaneous voltage and current as functions of space and time are then

$$v(z, t) = \operatorname{Re}\left[\hat{v}(z) \ e^{j\omega t}\right] = -V_0 \frac{\sin kz}{\sin kl} \cos \omega t$$

$$i(z, t) = \operatorname{Re}\left[\hat{i}(z) \ e^{j\omega t}\right] = \frac{V_0 Y_0 \cos kz \sin \omega t}{\sin kl}$$
(9)





Figure 8-15 The voltage and current distributions on a (a) short circuited and (b) open circuited transmission line excited by sinusoidal voltage sources at z = -l. If the lines are much shorter than a wavelength, they act like reactive circuit elements. (c) As the frequency is raised, the impedance reflected back as a function of z can look capacitive or inductive making the transition through open or short circuits.

The spatial distributions of voltage and current as a function of z at a specific instant of time are plotted in Figure 8-15a and are seen to be 90° out of phase with one another in space with their distributions periodic with wavelength λ given by

$$\lambda = \frac{2\pi}{k} = \frac{2\pi c}{\omega} \tag{10}$$



(b)



(c)

Figure 8-15

598

The complex impedance at any position z is defined as

$$Z(z) = \frac{\hat{v}(z)}{\hat{i}(z)}$$
(11)

which for this special case of a short circuited line is found from (8) as

$$Z(z) = -jZ_0 \tan kz \tag{12}$$

In particular, at z = -l, the transmission line appears to the generator as an impedance of value

$$Z(z=-l) = jZ_0 \tan kl \tag{13}$$

From the solid lines in Figure 8-15c we see that there are various regimes of interest:

- (i) When the line is an integer multiple of a half wavelength long so that $kl = n\pi$, n = 1, 2, 3, ..., the impedance at z = -l is zero and the transmission line looks like a short circuit.
- (ii) When the line is an odd integer multiple of a quarter wavelength long so that $kl = (2n-1)\pi/2$, n = 1, 2, ..., the impedance at z = -l is infinite and the transmission line looks like an open circuit.
- (iii) Between the short and open circuit limits $(n-1)\pi < kl < (2n-1)\pi/2$, $n=1, 2, 3, \ldots$, Z(z=-l) has a positive reactance and hence looks like an inductor.
- (iv) Between the open and short circuit limits $(n-\frac{1}{2})\pi < kl < n\pi$, n = 1, 2, ..., Z(z = -l) has a negative reactance and so looks like a capacitor.

Thus, the short circuited transmission line takes on all reactive values, both positive (inductive) and negative (capacitive), including open and short circuits as a function of kl. Thus, if either the length of the line l or the frequency is changed, the impedance of the transmission line is changed.

Examining (8) we also notice that if $\sin kl = 0$, $(kl = n\pi, n = 1, 2, ...)$, the voltage and current become infinite (in practice the voltage and current become large limited only by losses). Under these conditions, the system is said to be resonant with the resonant frequencies given by

$$\omega_n = n\pi c/l, \qquad n = 1, 2, 3, \ldots \qquad (14)$$

Any voltage source applied at these frequencies will result in very large voltages and currents on the line.

(b) Open Circuited Line

If the short circuit is replaced by an open circuit, as in Figure 8-15b, and for variety we change the source at z = -l to

 $V_0 \sin \omega t$ the boundary conditions are

$$i(z = 0, t) = 0$$

$$v(z = -l, t) = V_0 \sin \omega t = \operatorname{Re} (-jV_0 e^{j\omega t})$$
(15)

Using (3) the complex amplitudes obey the relations

$$\hat{i}(z=0) = 0 = Y_0(\hat{V}_+ - \hat{V}_-)$$

$$\hat{v}(z=-l) = -jV_0 = \hat{V}_+ e^{jkl} + \hat{V}_- e^{-jkl}$$
(16)

which has solutions

$$\hat{\mathbf{V}}_{+} = \hat{\mathbf{V}}_{-} = \frac{-j V_{0}}{2 \cos kl} \tag{17}$$

The spatial dependences of the voltage and current are then

$$\hat{v}(z) = \frac{-jV_0}{2\cos kl} (e^{-jkz} + e^{jkz}) = \frac{-jV_0}{\cos kl}\cos kz$$

$$\hat{v}(z) = \frac{-jV_0Y_0}{2\cos kl} (e^{-jkz} - e^{+jkz}) = -\frac{V_0Y_0}{\cos kl}\sin kz$$
(18)

with instantaneous solutions as a function of space and time:

$$v(z, t) = \operatorname{Re}\left[\hat{v}(z) e^{j\omega t}\right] = \frac{V_0 \cos kz}{\cos kl} \sin \omega t$$

$$i(z, t) = \operatorname{Re}\left[\hat{i}(z) e^{j\omega t}\right] = -\frac{V_0 Y_0}{\cos kl} \sin kz \cos \omega t$$
(19)

The impedance at z = -l is

$$Z(z = -l) = \frac{\hat{v}(-l)}{\hat{i}(-l)} = -jZ_0 \cot kl$$
(20)

Again the impedance is purely reactive, as shown by the dashed lines in Figure 8-15*c*, alternating signs every quarter wavelength so that the open circuit load looks to the voltage source as an inductor, capacitor, short or open circuit depending on the frequency and length of the line.

Resonance will occur if

$$\cos kl = 0 \tag{21}$$

or

$$kl = (2n-1)\pi/2, \qquad n = 1, 2, 3, \dots$$
 (22)

so that the resonant frequencies are

$$\omega_n = \frac{(2n-1)\pi c}{2l} \tag{23}$$

8-3-3 Reactive Circuit Elements as Approximations to Short Transmission Lines

Let us re-examine the results obtained for short and open circuited lines in the limit when l is much shorter than the wavelength λ so that in this long wavelength limit the spatial trigonometric functions can be approximated as

$$\lim_{k \to 1} \begin{cases} \sin kz \approx kz \\ \cos kz \approx 1 \end{cases}$$
(24)

Using these approximations, the voltage, current, and impedance for the short circuited line excited by a voltage source $V_0 \cos \omega t$ can be obtained from (9) and (13) as

$$\lim_{kl\ll 1} \begin{cases} v(z,t) = -\frac{V_0 z}{l} \cos \omega t, & v(-l,t) = V_0 \cos \omega t \\ i(z,t) = \frac{V_0 Y_0}{kl} \sin \omega t, & i(-l,t) = \frac{V_0 \sin \omega t}{(Ll)\omega} \\ Z(-l) = jZ_0 kl = j\frac{\omega Z_0 l}{c} = j\omega(Ll) \end{cases}$$
(25)

We see that the short circuited transmission line acts as an inductor of value (Ll) (remember that L is the inductance per unit length), where we used the relations

$$Z_0 = \frac{1}{Y_0} = \sqrt{\frac{L}{C}}, \qquad c = \frac{1}{\sqrt{LC}}$$
 (26)

Note that at z = -l,

$$v(-l,t) = (Ll)\frac{di(-l,t)}{dt}$$
(27)

Similarly for the open circuited line we obtain:

$$\lim_{kl\ll 1} \begin{cases} v(z,t) = V_0 \sin \omega t \\ i(z,t) = -V_0 Y_0 kz \cos \omega t, \qquad i(-l,t) = (Cl)\omega V_0 \cos \omega t \\ Z(-l) = \frac{-jZ_0}{kl} = \frac{-j}{(Cl)\omega} \end{cases}$$
(28)

For the open circuited transmission line, the terminal voltage and current are simply related as for a capacitor,

$$i(-l,t) = (Cl)\frac{dv(-l,t)}{dt}$$
⁽²⁹⁾

with capacitance given by (Cl).

In general, if the frequency of excitation is low enough so that the length of a transmission line is much shorter than the wavelength, the circuit approximations of inductance and capacitance are appropriate. However, it must be remembered that if the frequencies of interest are so high that the length of a circuit element is comparable to the wavelength, it no longer acts like that element. In fact, as found in Section 8-3-2, a capacitor can even look like an inductor, a short circuit, or an open circuit at high enough frequency while vice versa an inductor can also look capacitive, a short or an open circuit.

In general, if the termination is neither a short nor an open circuit, the voltage and current distribution becomes more involved to calculate and is the subject of Section 8-4.

8-3-4 Effects of Line Losses

(a) Distributed Circuit Approach

If the dielectric and transmission line walls have Ohmic losses, the voltage and current waves decay as they propagate. Because the governing equations of Section 8-1-3 are linear with constant coefficients, in the sinusoidal steady state we assume solutions of the form

$$v(z, t) = \operatorname{Re}\left(\hat{V} e^{j(\omega t - kz)}\right)$$

$$i(z, t) = \operatorname{Re}\left(\hat{I} e^{j(\omega t - kz)}\right)$$
(30)

where now ω and k are not simply related as the nondispersive relation in (4). Rather we substitute (30) into Eq. (28) in Section 8-1-3:

$$\frac{\partial i}{\partial z} = -C \frac{\partial v}{\partial t} - Gv \Rightarrow -jk\hat{I} = -(Cj\omega + G)\hat{V}$$

$$\frac{\partial v}{\partial z} = -L \frac{\partial i}{\partial t} - iR \Rightarrow -jk\hat{V} = -(Lj\omega + R)\hat{I}$$
(31)

which requires that

$$\frac{\hat{\mathbf{V}}}{\hat{I}} = \frac{jk}{(Cj\omega + G)} = \frac{Lj\omega + R}{jk}$$
(32)

We solve (32) self-consistently for k as

$$k^{2} = -(Lj\omega + R)(Cj\omega + G) = LC\omega^{2} - j\omega(RC + LG) - RG$$
(33)

The wavenumber is thus complex so that we find the real and imaginary parts from (33) as

$$k = k_r + jk_i \Rightarrow k_r^2 - k_i^2 = LC\omega^2 - RG$$

$$2k_rk_i = -\omega(RC + LG)$$
(34)

In the low loss limit where $\omega RC \ll 1$ and $\omega LG \ll 1$, the spatial decay of k_i is small compared to the propagation wavenumber k_r . In this limit we have the following approximate solution:

$$\lim_{\substack{\omega RC \ll 1\\ \omega LG \ll 1}} \begin{cases} k_r \approx \pm \omega \sqrt{LC} = \pm \omega/c \\ k_i = -\frac{\omega (RC + LG)}{2k_r} \approx \mp \frac{1}{2} \left[R \sqrt{\frac{C}{L}} + G \sqrt{\frac{L}{C}} \right] \\ \approx \mp \frac{1}{2} (RY_0 + GZ_0) \end{cases}$$
(35)

We use the upper sign for waves propagating in the +z direction and the lower sign for waves traveling in the -z direction.

(b) Distortionless lines

Using the value of k of (33),

$$k = \pm \left[-(Lj\omega + R)(Cj\omega + G) \right]^{1/2}$$
(36)

in (32) gives us the frequency dependent wave impedance for waves traveling in the $\pm z$ direction as

$$\frac{\hat{\mathbf{V}}}{\hat{I}} = \pm \left(\frac{Lj\omega + R}{Cj\omega + G}\right)^{1/2} = \pm \sqrt{\frac{L}{C}} \left(\frac{j\omega + R/L}{j\omega + G/C}\right)^{1/2}$$
(37)

If the line parameters are adjusted so that

$$\frac{R}{L} = \frac{G}{C}$$
(38)

the impedance in (37) becomes frequency independent and equal to the lossless line impedance. Under the conditions of (38) the complex wavenumber reduces to

$$k_r = \pm \omega \sqrt{LC}, \qquad k_i = \mp \sqrt{RG} \tag{39}$$

Although the waves are attenuated, all frequencies propagate at the same phase and group velocities as for a lossless line

$$v_{p} = \frac{\omega}{k_{r}} = \pm \frac{1}{\sqrt{LC}}$$

$$v_{g} = \frac{d\omega}{dk_{r}} = \pm \frac{1}{\sqrt{LC}}$$
(40)

Since all the Fourier components of a pulse excitation will travel at the same speed, the shape of the pulse remains unchanged as it propagates down the line. Such lines are called distortionless.

(c) Fields Approach

If R = 0, we can directly find the TEM wave solutions using the same solutions found for plane waves in Section 7-4-3. There we found that a dielectric with permittivity ε and small Ohmic conductivity σ has a complex wavenumber:

$$\lim_{\sigma/\omega \in \ll 1} k \approx \pm \left(\frac{\omega}{c} - \frac{j\sigma\eta}{2}\right) \tag{41}$$

Equating (41) to (35) with R = 0 requires that $GZ_0 = \sigma \eta$.

The tangential component of **H** at the perfectly conducting transmission line walls is discontinuous by a surface current. However, if the wall has a large but noninfinite Ohmic conductivity σ_w , the fields penetrate in with a characteristic distance equal to the skin depth $\delta = \sqrt{2/\omega\mu\sigma_w}$. The resulting z-directed current gives rise to a z-directed electric field so that the waves are no longer purely TEM.

Because we assume this loss to be small, we can use an approximate perturbation method to find the spatial decay rate of the fields. We assume that the fields between parallel plane electrodes are essentially the same as when the system is lossless except now being exponentially attenuated as $e^{-\alpha x}$, where $\alpha = -k_i$:

$$E_{x}(z, t) = \operatorname{Re}\left[\hat{E} e^{j(\omega t - k_{r}z)} e^{-\alpha z}\right]$$

$$H_{y}(z, t) = \operatorname{Re}\left[\frac{\hat{E}}{\eta} e^{j(\omega t - k_{r}z)} e^{-\alpha z}\right], \quad k_{r} = \frac{\omega}{c}$$
(42)

From the real part of the complex Poynting's theorem derived in Section 7-2-4, we relate the divergence of the time-average electromagnetic power density to the timeaverage dissipated power:

٩

$$\nabla \cdot \langle \boldsymbol{S} \rangle = -\langle \boldsymbol{P}_d \rangle \tag{43}$$

Using the divergence theorem we integrate (43) over a volume of thickness Δz that encompasses the entire width and thickness of the line, as shown in Figure 8-16:

$$\int_{\mathbf{V}} \nabla \cdot \langle \mathbf{S} \rangle d\mathbf{V} = \oint_{\mathbf{S}} \langle \mathbf{S} \rangle \cdot d\mathbf{S}$$
$$= \int_{z + \Delta z} \langle S_{z}(z + \Delta z) \rangle d\mathbf{S}$$
$$- \int_{z} \langle S_{z}(z) \rangle d\mathbf{S} = - \int_{\mathbf{V}} \langle P_{d} \rangle d\mathbf{V} \quad (44)$$

The power $\langle P_d \rangle$ is dissipated in the dielectric and in the walls. Defining the total electromagnetic power as

$$\langle P(z) \rangle = \int_{z} \langle S_{z}(z) \rangle dS$$
 (45)



Figure 8-16 A transmission line with lossy walls and dielectric results in waves that decay as they propagate. The spatial decay rate α of the fields is approximately proportional to the ratio of time average dissipated power per unit length $\langle P_{dL} \rangle$ to the total time average electromagnetic power flow $\langle P \rangle$ down the line.

(44) can be rewritten as

$$\langle P(z+\Delta z)\rangle - \langle P(z)\rangle = -\int \langle P_d \rangle dx dy dz$$
 (46)

Dividing through by $dz = \Delta z$, we have in the infinitesimal limit

$$\lim_{\Delta z \to 0} \frac{\langle P(z + \Delta z) \rangle - \langle P(z) \rangle}{\Delta z} = \frac{d \langle P \rangle}{dz} = -\int_{S} \langle P_{d} \rangle \, dx \, dy$$
$$= -\langle P_{dL} \rangle \tag{47}$$

where $\langle P_{dL} \rangle$ is the power dissipated per unit length. Since the fields vary as $e^{-\alpha z}$, the power flow that is proportional to the square of the fields must vary as $e^{-2\alpha z}$ so that

$$\frac{d < P >}{dz} = -2\alpha < P > = -$$
(48)

which when solved for the spatial decay rate is proportional to the ratio of dissipated power per unit length to the total

605

electromagnetic power flowing down the transmission line:

$$\alpha = \frac{1}{2} \frac{\langle P_{dL} \rangle}{\langle P \rangle} \tag{49}$$

For our lossy transmission line, the power is dissipated both in the walls and in the dielectric. Fortunately, it is not necessary to solve the complicated field problem within the walls because we already approximately know the magnetic field at the walls from (42). Since the wall current is effectively confined to the skin depth δ , the cross-sectional area through which the current flows is essentially $w\delta$ so that we can define the surface conductivity as $\sigma_w \delta$, where the electric field at the wall is related to the lossless surface current as

$$\mathbf{K}_{w} = \boldsymbol{\sigma}_{w} \boldsymbol{\delta} \mathbf{E}_{w} \tag{50}$$

The surface current in the wall is approximately found from the magnetic field in (42) as

$$K_z = -H_y = -E_x/\eta \tag{51}$$

The time-average power dissipated in the wall is then

$$\langle P_{dL} \rangle_{\text{wall}} = \frac{w}{2} \operatorname{Re} \left(\mathbf{E}_{w} \cdot \mathbf{K}_{w}^{*} \right) = \frac{1}{2} \frac{|\mathbf{K}_{w}|^{2} w}{\sigma_{w} \delta} = \frac{1}{2} \frac{|\hat{E}|^{2} w}{\sigma_{w} \delta \eta^{2}} \quad (52)$$

The total time-average dissipated power in the walls and dielectric per unit length for a transmission line system of depth w and plate spacing d is then

$$< P_{dL} > = 2 < P_{dL} >_{\text{wall}} + \frac{1}{2}\sigma |\vec{E}|^2 w d$$
$$= \frac{1}{2} |\vec{E}|^2 w \left(\frac{2}{\eta^2 \sigma_w \delta} + \sigma d\right)$$
(53)

where we multiply (52) by two because of the losses in both electrodes. The time-average electromagnetic power is

$$\langle P \rangle = \frac{1}{2} \frac{|\hat{E}|^2}{\eta} wd \tag{54}$$

so that the spatial decay rate is found from (49) as

$$\alpha = -k_i = \frac{1}{2} \left(\frac{2}{\eta^2 \sigma_w \delta} + \sigma d \right) \frac{\eta}{d} = \frac{1}{2} \left(\sigma \eta + \frac{2}{\eta \sigma_w \delta d} \right)$$
(55)

Comparing (55) to (35) we see that

$$GZ_0 = \sigma \eta, \qquad RY_0 = \frac{2}{\eta \sigma_w \delta d}$$

$$\Rightarrow Z_0 = \frac{1}{Y_0} = \frac{d}{w} \eta, \qquad G = \frac{\sigma w}{d}, \qquad R = \frac{2}{\sigma_w w \delta} \qquad (56)$$

8-4 ARBITRARY IMPEDANCE TERMINATIONS

8-4-1 The Generalized Reflection Coefficient

A lossless transmission line excited at z = -l with a sinusoidal voltage source is now terminated at its other end at z = 0with an arbitrary impedance Z_L , which in general can be a complex number. Defining the load voltage and current at z = 0 as

$$v(z=0, t) = v_L(t) = \operatorname{Re} (V_L e^{j\omega t})$$

$$i(z=0, t) = i_L(t) = \operatorname{Re} (I_L e^{j\omega t}), \qquad I_L = V_L/Z_L$$
(1)

where V_L and I_L are complex amplitudes, the boundary conditions at z = 0 are

$$\mathbf{V}_{+} + \mathbf{V}_{-} = \mathbf{V}_{L} \tag{2}$$

$$Y_0(V_+ - V_-) = I_L = V_L/Z_L$$

We define the reflection coefficient as the ratio

$$\Gamma_L = V_- / V_+ \tag{3}$$

and solve as

$$\Gamma_L = \frac{Z_L - Z_0}{Z_L + Z_0} \tag{4}$$

Here in the sinusoidal steady state with reactive loads, Γ_L can be a complex number as Z_L may be complex. For transient pulse waveforms, Γ_L was only defined for resistive loads. For capacitative and inductive terminations, the reflections were given by solutions to differential equations in time. Now that we are only considering sinusoidal time variations so that time derivatives are replaced by $j\omega$, we can generalize Γ_L for the sinusoidal steady state.

It is convenient to further define the generalized reflection coefficient as

$$\Gamma(z) = \frac{V_{-} e^{jkz}}{V_{+} e^{-jkz}} = \frac{V_{-}}{V_{+}} e^{2jkz} = \Gamma_{L} e^{2jkz}$$
(5)

where Γ_L is just $\Gamma(z = 0)$. Then the voltage and current on the line can be expressed as

$$\hat{v}(z) = \mathbf{V}_{+} e^{-jkz} [1 + \Gamma(z)]$$

$$\hat{\imath}(z) = Y_0 \mathbf{V}_{+} e^{-jkz} [1 - \Gamma(z)]$$
(6)

The advantage to this notation is that now the impedance along the line can be expressed as

$$Z_{n}(z) = \frac{Z(z)}{Z_{0}} = \frac{\hat{v}(z)}{\hat{i}(z)Z_{0}} = \frac{1 + \Gamma(z)}{1 - \Gamma(z)}$$
(7)

where Z_n is defined as the normalized impedance. We can now solve (7) for $\Gamma(z)$ as

$$\Gamma(z) = \frac{Z_n(z) - 1}{Z_n(z) + 1} \tag{8}$$

Note the following properties of $Z_n(z)$ and $\Gamma(z)$ for passive loads:

- (i) $Z_n(z)$ is generally complex. For passive loads its real part is allowed over the range from zero to infinity while its imaginary part can extend from negative to positive infinity.
- (ii) The magnitude of $\Gamma(z)$, $|\Gamma_L|$ must be less than or equal to 1 for passive loads.
- (iii) From (5), if z is increased or decreased by a half wavelength, $\Gamma(z)$ and hence $Z_n(z)$ remain unchanged. Thus, if the impedance is known at any position, the impedance of all-points integer multiples of a half wavelength away have the same impedance.
- (iv) From (5), if z is increased or decreased by a quarter wavelength, $\Gamma(z)$ changes sign, while from (7) $Z_n(z)$ goes to its reciprocal $\Rightarrow 1/Z_n(z) = Y_n(z)$.
- (v) If the line is matched, $Z_L = Z_0$, then $\Gamma_L = 0$ and $Z_n(z) = 1$. The impedance is the same everywhere along the line.

8-4-2 Simple Examples

(a) Load Impedance Reflected Back to the Source

Properties (iii)-(v) allow simple computations for transmission line systems that have lengths which are integer multiples of quarter or half wavelengths. Often it is desired to maximize the power delivered to a load at the end of a transmission line by adding a lumped admittance Y across the line. For the system shown in Figure 8-17a, the impedance of the load is reflected back to the generator and then added in parallel to the lumped reactive admittance Y. The normalized load impedance of $(R_L + jX_L)/Z_0$ inverts when reflected back to the source by a quarter wavelength to $Z_0/(R_L + iX_L)$. Since this is the normalized impedance the actual impedance is found by multiplying by Z_0 to yield $Z(z = -\lambda/4) =$ $Z_0^2/(R_L + jX_L)$. The admittance of this reflected load then adds in parallel to Y to yield a total admittance of $Y + (R_L + jX_L)/Z_0^2$. If Y is pure imaginary and of opposite sign to the reflected load susceptance with value $-jX_L/Z_0^2$, maximum power is delivered to the line if the source resistance R_s also equals the resulting line input impedance, $R_s = Z_0^2/R_L$. Since Y is purely



Figure 8-17 The normalized impedance reflected back through a quarter-wave-long line inverts. (a) The time-average power delivered to a complex load can be maximized if Y is adjusted to just cancel the reactive admittance of the load reflected back to the source with $R_{\rm s}$ equaling the resulting input resistance. (b) If the length l_2 of the second transmission line shown is a quarter wave long or an odd integer multiple of $\lambda/4$ and its characteristic impedance is equal to the geometric average of Z_1 and R_L , the input impedance $Z_{\rm in}$ is matched to Z_1 .

reactive and the transmission line is lossless, half the timeaverage power delivered by the source is dissipated in the load:

$$=\frac{1}{8}\frac{V_0^2}{R_s}=\frac{1}{8}\frac{R_L V_0^2}{Z_0^2}$$
 (9)

Such a reactive element Y is usually made from a variable length short circuited transmission line called a stub. As shown in Section 8-3-2a, a short circuited lossless line always has a pure reactive impedance.

To verify that the power in (9) is actually dissipated in the load, we write the spatial distribution of voltage and current along the line as

$$\hat{v}(z) = V_{+} e^{-jkz} (1 + \Gamma_{L} e^{2jkz})$$

$$\hat{i}(z) = Y_{0} V_{+} e^{-jkz} (1 - \Gamma_{L} e^{2jkz})$$
(10)

where the reflection coefficient for this load is given by (4) as

$$\Gamma_{L} = \frac{R_{L} + jX_{L} - Z_{0}}{R_{L} + jX_{L} + Z_{0}}$$
(11)

At $z = -l = -\lambda/4$ we have the boundary condition

$$\hat{v}(z = -l) = V_0/2 = V_+ e^{jkl} (1 + \Gamma_L e^{-2jkl})$$

= $jV_+(1 - \Gamma_L)$ (12)

which allows us to solve for V+ as

$$V_{+} = \frac{-jV_{0}}{2(1-\Gamma_{L})} = \frac{-jV_{0}}{4Z_{0}}(R_{L} + jX_{L} + Z_{0})$$
(13)

The time-average power dissipated in the load is then

$$= \frac{1}{2} \operatorname{Re} \left[\hat{v}(z=0) \hat{i}^{*}(z=0) \right]$$
$$= \frac{1}{2} \left| \hat{i}(z=0) \right|^{2} R_{L}$$
$$= \frac{1}{2} \left| V_{+} \right|^{2} \left| 1 - \Gamma_{L} \right|^{2} Y_{0}^{2} R_{L}$$
$$= \frac{1}{8} V_{0}^{2} Y_{0}^{2} R_{L}$$
(14)

which agrees with (9).

(b) Quarter Wavelength Matching

It is desired to match the load resistor R_L to the transmission line with characteristic impedance Z_1 for any value of its length l_1 . As shown in Figure 8-17b, we connect the load to Z_1 via another transmission line with characteristic impedance Z_2 . We wish to find the values of Z_2 and l_2 necessary to match R_L to Z_1 .

This problem is analogous to the dielectric coating problem of Example 7-1, where it was found that reflections could be eliminated if the coating thickness between two different dielectric media was an odd integer multiple of a quarter wavelength and whose wave impedance was equal to the geometric average of the impedance in each adjacent region. The normalized load on Z_2 is then $Z_{n2} = R_L/Z_2$. If l_2 is an odd integer multiple of a quarter wavelength long, the normalized impedance Z_{n2} reflected back to the first line inverts to Z_2/R_L . The actual impedance is obtained by multiplying this normalized impedance by Z_2 to give Z_2^2/R_L . For Z_{in} to be matched to Z_1 for any value of l_1 , this impedance must be matched to Z_1 :

$$Z_1 = Z_2^2 / R_L \Rightarrow Z_2 = \sqrt{Z_1 R_L} \tag{15}$$

8-4-3 The Smith Chart

Because the range of allowed values of Γ_L must be contained within a unit circle in the complex plane, all values of $Z_n(z)$ can be mapped by a transformation within this unit circle using (8). This transformation is what makes the substitutions of (3)-(8) so valuable. A graphical aid of this mathematical transformation was developed by P. H. Smith in 1939 and is known as the Smith chart. Using the Smith chart avoids the tedium in problem solving with complex numbers.

Let us define the real and imaginary parts of the normalized impedance at some value of z as

$$Z_n(z) = r + jx \tag{16}$$

The reflection coefficient similarly has real and imaginary parts given as

$$\Gamma(z) = \Gamma_r + j\Gamma_i \tag{17}$$

Using (7) we have

$$r + jx = \frac{1 + \Gamma_r + j\Gamma_i}{1 - \Gamma_r - j\Gamma_i}$$
(18)

Multiplying numerator and denominator by the complex conjugate of the denominator $(1-\Gamma_r+j\Gamma_i)$ and separating real and imaginary parts yields

$$r = \frac{1 - \Gamma_r^2 - \Gamma_i^2}{(1 - \Gamma_r)^2 + \Gamma_i^2}$$

$$x = \frac{2\Gamma_i}{(1 - \Gamma_r)^2 + \Gamma_i^2}$$
(19)

Since we wish to plot (19) in the $\Gamma_r - \Gamma_i$ plane we rewrite these equations as

$$\left(\Gamma_{r} - \frac{r}{1+r}\right)^{2} + \Gamma_{i}^{2} = \frac{1}{(1+r)^{2}}$$

$$(\Gamma_{r} - 1)^{2} + \left(\Gamma_{i} - \frac{1}{x}\right)^{2} = \frac{1}{x^{2}}$$
(20)

Both equations in (20) describe a family of orthogonal circles. The upper equation is that of a circle of radius 1/(1+r) whose center is at the position $\Gamma_i = 0$, $\Gamma_r = r/(1+r)$. The lower equation is a circle of radius |1/x| centered at the position $\Gamma_r = 1$, $\Gamma_i = 1/x$. Figure 8-18*a* illustrates these circles for a particular value of *r* and *x*, while Figure 8-18*b* shows a few representative values of *r* and *x*. In Figure 8-19, we have a complete Smith chart. Only those parts of the circles that lie within the unit circle in the Γ plane are considered for passive



Figure 8-18 For passive loads the Smith chart is constructed within the unit circle in the complex Γ plane. (a) Circles of constant normalized resistance r and reactance x are constructed with the centers and radii shown. (b) Smith chart construction for various values of r and x.

resistive-reactive loads. The values of $\Gamma(z)$ themselves are usually not important and so are not listed, though they can be easily found from (8). Note that all circles pass through the point $\Gamma_r = 1$, $\Gamma_i = 0$.

The outside of the circle is calibrated in wavelengths toward the generator, so if the impedance is known at any point on the transmission line (usually at the load end), the impedance at any other point on the line can be found using just a compass and a ruler. From the definition of $\Gamma(z)$ in (5) with z negative, we move clockwise around the Smith chart when heading towards the source and counterclockwise when moving towards the load.



Figure 8-18

In particular, consider the transmission line system in Figure 8-20*a*. The normalized load impedance is $Z_n = 1 + j$. Using the Smith chart in Figure 8-20*b*, we find the load impedance at position *A*. The effective impedance reflected back to z = -l must lie on the circle of constant radius returning to *A* whenever *l* is an integer multiple of a half wavelength. The table in Figure 8-20 lists the impedance at z = -l for various line lengths. Note that at point *C*, where $l = \lambda/4$, that the normalized impedance is the reciprocal of



Figure 8-19 A complete Smith chart.

that at A. Similarly the normalized impedance at B is the reciprocal of that at D.

The current from the voltage source is found using the equivalent circuit shown in Figure 8-20c as

$$\mathbf{i} = |\hat{I}| \sin(\omega t - \boldsymbol{\phi}) \tag{21}$$

where the current magnitude and phase angle are

$$|\hat{I}| = \frac{V_0}{|50+Z(z=-l)|}, \qquad \phi = \tan^{-1} \frac{\operatorname{Im} [Z(z=-l)]}{50+\operatorname{Re} [Z(z=-l)]}$$
(22)

Representative numerical values are listed in Figure 8-20.



Figure 8-20 (a) The load impedance at z = 0 reflected back to the source is found using the (b) Smith chart for various line lengths. Once this impedance is known the source current is found by solving the simple series circuit in (c).

8-4-4 Standing Wave Parameters

The impedance and reflection coefficient are not easily directly measured at microwave frequencies. In practice, one slides an ac voltmeter across a slotted transmission line and measures the magnitude of the peak or rms voltage and not its phase angle.

From (6) the magnitude of the voltage and current at any position z is

$$|\hat{v}(z)| = |V_{+}| |1 + \Gamma(z)|$$

$$|\hat{i}(z)| = Y_{0}|V_{+}| |1 - \Gamma(z)|$$
(23)

From (23), the variations of the voltage and current magnitudes can be drawn by a simple construction in the Γ plane, as shown in Figure 8-21. Note again that $|V_+|$ is just a real number independent of z and that $|\Gamma(z)| \leq 1$ for a passive termination. We plot $|1+\Gamma(z)|$ and $|1-\Gamma(z)|$ since these terms are proportional to the voltage and current magnitudes, respectively. The following properties from this con-



Figure 8-21 The voltage and current magnitudes along a transmission line are respectively proportional to the lengths of the vectors $|1+\Gamma(z)|$ and $|1-\Gamma(z)|$ in the complex Γ plane.

617

struction are apparent:

- (i) The magnitude of the current is smallest and the voltage magnitude largest when $\Gamma(z) = 1$ at point A and vice versa when $\Gamma(z) = -1$ at point B.
- (ii) The voltage and current are in phase at the points of maximum or minimum magnitude of either at points A or B.
- (iii) A rotation of $\Gamma(z)$ by an angle π corresponds to a change of $\lambda/4$ in z, thus any voltage (or current) maximum is separated by $\lambda/4$ from its nearest minima on either side.

By plotting the lengths of the phasors $|1 \pm \Gamma(z)|$, as in Figure 8-22, we obtain a plot of what is called the standing wave pattern on the line. Observe that the curves are not sinusoidal. The minima are sharper than the maxima so the minima are usually located in position more precisely by measurement than the maxima.

From Figures 8-21 and 8-22, the ratio of the maximum voltage magnitude to the minimum voltage magnitude is defined as the voltage standing wave ratio, or VSWR for short:

$$\frac{|\hat{v}(z)|_{\max}}{|\hat{v}(z)|_{\min}} = \frac{1+|\Gamma_L|}{1-|\Gamma_L|} = \text{VSWR}$$
(24)

The VSWR is measured by simply recording the largest and smallest readings of a sliding voltmeter. Once the VSWR is measured, the reflection coefficient magnitude can be calculated from (24) as

$$|\Gamma_L| = \frac{\text{VSWR} - 1}{\text{VSWR} + 1}$$
(25)

The angle ϕ of the reflection coefficient

$$\Gamma_L = |\Gamma_L| \ e^{j\phi} \tag{26}$$

can also be determined from these standing wave measurements. According to Figure 8-21, $\Gamma(z)$ must swing clockwise through an angle $\phi + \pi$ as we move from the load at z = 0toward the generator to the first voltage minimum at *B*. The shortest distance d_{\min} that we must move to reach the first voltage minimum is given by

$$2kd_{\min} = \phi + \pi \tag{27}$$

$$\frac{\phi}{\pi} = 4 \frac{d_{\min}}{\lambda} - 1 \tag{28}$$

or



Figure 8-22 Voltage and current standing wave patterns plotted for various values of the VSWR.

A measurement of d_{\min} , as well as a determination of the wavelength (the distance between successive minima or maxima is $\lambda/2$) yields the complex reflection coefficient of the load using (25) and (28). Once we know the complex reflection coefficient we can calculate the load impedance

from (7). These standing wave measurements are sufficient to determine the terminating load impedance Z_L . These measurement properties of the load reflection coefficient and its relation to the load impedance are of great importance at high frequencies where the absolute measurement of voltage or current may be difficult. Some special cases of interest are:

- (i) Matched line—If $\Gamma_L = 0$, then VSWR = 1. The voltage magnitude is constant everywhere on the line.
- (ii) Short or open circuited line—If $|\Gamma_L| = 1$, then VSWR = ∞ . The minimum voltage on the line is zero.
- (iii) The peak normalized voltage $|\hat{v}(z)/V_+|$ is $1+|\Gamma_L|$ while the minimum normalized voltage is $1-|\Gamma_L|$.
- (iv) The normalized voltage at z=0 is $|1+\Gamma_r|$ while the normalized current $|\hat{i}(z)/Y_0V_+|$ at z=0 is $|1-\Gamma_L|$.
- (v) If the load impedance is real $(Z_L = R_L)$, then (4) shows us that Γ_L is real. Then evaluating (7) at z = 0, where $\Gamma(z=0) = \Gamma_L$, we see that when $Z_L > Z_0$ that VSWR = Z_L/Z_0 while if $Z_L < Z_0$, VSWR = Z_0/Z_L .

For a general termination, if we know the VSWR and d_{min} , we can calculate the load impedance from (7) as

$$Z_{L} = Z_{0} \frac{1 + |\Gamma_{L}| e^{j\phi}}{1 - |\Gamma_{L}| e^{j\phi}}$$

= $Z_{0} \frac{[VSWR + 1 + (VSWR - 1) e^{j\phi}]}{[VSWR + 1 - (VSWR - 1) e^{j\phi}]}$ (29)

Multiplying through by $e^{-j\phi/2}$ and then simplifying yields

$$Z_{L} = \frac{Z_{0}[VSWR - j \tan(\phi/2)]}{[1 - j VSWR \tan(\phi/2)]}$$
$$= \frac{Z_{0}[1 - j VSWR \tan kd_{\min}]}{[VSWR - j \tan kd_{\min}]}$$
(30)

EXAMPLE 8-2 VOLTAGE STANDING WAVE RATIO

The VSWR on a 50-Ohm (characteristic impedance) transmission line is 2. The distance between successive voltage minima is 40 cm while the distance from the load to the first minima is 10 cm. What is the reflection coefficient and load impedance?

SOLUTION

We are given

$$VSWR = 2$$

$$kd_{\min} = \frac{2\pi(10)}{2(40)} = \frac{\pi}{4}$$

The reflection coefficient is given from (25)–(28) as

$$\Gamma_L = \frac{1}{3} e^{-j\pi/2} = \frac{-j}{3}$$

while the load impedance is found from (30) as

$$Z_L = \frac{50(1-2j)}{2-j} = 40 - 30j \text{ ohm}$$

8-5 STUB TUNING

In practice, most sources are connected to a transmission line through a series resistance matched to the line. This eliminates transient reflections when the excitation is turned on or off. To maximize the power flow to a load, it is also necessary for the load impedance reflected back to the source to be equal to the source impedance and thus equal to the characteristic impedance of the line, Z_0 . This matching of the load to the line for an arbitrary termination can only be performed by adding additional elements along the line.

Usually these elements are short circuited transmission lines, called stubs, whose lengths can be varied. The reactance of the stub can be changed over the range from $-j\infty$ to $j\infty$ simply by varying its length, as found in Section 8-3-2, for the short circuited line. Because stubs are usually connected in parallel to a transmission line, it is more convenient to work with admittances rather than impedances as admittances in parallel simply add.

8-5-1 Use of the Smith Chart for Admittance Calculations

Fortunately the Smith chart can also be directly used for admittance calculations where the normalized admittance is defined as

$$Y_{n}(z) = \frac{Y(z)}{Y_{0}} = \frac{1}{Z_{n}(z)}$$
(1)

If the normalized load admittance Y_{nL} is known, straightforward impedance calculations first require the computation

$$Z_{nL} = 1/Y_{nL} \tag{2}$$

so that we could enter the Smith chart at Z_{nL} . Then we rotate by the required angle corresponding to 2kz and read the new $Z_n(z)$. Then we again compute its reciprocal to find

$$Y_n(z) = 1/Z_n(z) \tag{3}$$

The two operations of taking the reciprocal are tedious. We can use the Smith chart itself to invert the impedance by using the fact that the normalized impedance is inverted by a $\lambda/4$ section of line, so that a rotation of $\Gamma(z)$ by 180° changes a normalized impedance into its reciprocal. Hence, if the admittance is given, we enter the Smith chart with a given value of normalized admittance Y_n and rotate by 180° to find Z_n . We then rotate by the appropriate number of wavelengths to find $Z_n(z)$. Finally, we again rotate by 180° to find $Y_n(z) =$ $1/Z_n(z)$. We have actually rotated the reflection coefficient by an angle of $2\pi + 2kz$. Rotation by 2π on the Smith chart, however, brings us back to wherever we started, so that only the 2kz rotation is significant. As long as we do an even number of π rotations by entering the Smith chart with an admittance and leaving again with an admittance, we can use the Smith chart with normalized admittances exactly as if they were normalized impedances.

EXAMPLE 8-3 USE OF THE SMITH CHART FOR ADMITTANCE CALCULATIONS

The load impedance on a 50-Ohm line is

$$Z_L = 50(1+j)$$

What is the admittance of the load?

SOLUTION

By direct computation we have

$$Y_L = \frac{1}{Z_L} = \frac{1}{50(1+j)} = \frac{(1-j)}{100}$$

To use the Smith chart we find the normalized impedance at A in Figure 8-23:

$$Z_{nL} = 1 + j$$



Figure 8-23 The Smith chart offers a convenient way to find the reciprocal of a complex number using the property that the normalized impedance reflected back by a quarter wavelength inverts. Thus, the normalized admittance is found by locating the normalized impedance and rotating this point by 180° about the constant $|\Gamma_L|$ circle.

The normalized admittance that is the reciprocal of the normalized impedance is found by locating the impedance a distance $\lambda/4$ away from the load end at B:

$$Y_{nL} = 0.5(1-j) \Rightarrow Y_L = Y_n Y_0 = (1-j)/100$$

Note that the point *B* is just 180° away from *A* on the constant $|\Gamma_L|$ circle. For more complicated loads the Smith chart is a convenient way to find the reciprocal of a complex number.

8-5-2 Single-Stub Matching

A termination of value $Z_L = 50(1+j)$ on a 50-Ohm transmission line is to be matched by means of a short circuited stub at a distance l_1 from the load, as shown in Figure 8-24*a*. We need to find the line length l_1 and the length of the stub l_2 such that the impedance at the junction is matched to the line $(Z_{in} = 50 \text{ Ohm})$. Then we know that all further points to the left of the junction have the same impedance of 50 Ohms.

Because of the parallel connection, it is simpler to use the Smith chart as an admittance transformation. The normalized load admittance can be computed using the Smith chart by rotating by 180° from the normalized load impedance at A, as was shown in Figure 8-23 and Example 8-3,

$$Z_{nL} = 1 + j \tag{4}$$

to yield

$$Y_{nL} = 0.5(1-j)$$
(5)

at the point **B**.

Now we know from Section 8-3-2 that the short circuited stub can only add an imaginary component to the admittance. Since we want the total normalized admittance to be unity to the left of the stub in Figure 8-24

$$Y_{in} = Y_1 + Y_2 = 1 \tag{6}$$

when Y_{nL} is reflected back to be Y_1 it must wind up on the circle whose real part is 1 (as Y_2 can only be imaginary), which occurs either at C or back at A allowing l_1 to be either 0.25 λ at A or $(0.25+0.177)\lambda = 0.427\lambda$ at C (or these values plus any integer multiple of $\lambda/2$). Then Y_1 is either of the following two conjugate values:

$$Y_1 = \begin{cases} 1+j, & l_1 = 0.25\lambda \ (A) \\ 1-j, & l_1 = 0.427\lambda \ (C) \end{cases}$$
(7)

For Y_{in} to be unity we must pick Y_2 to have an imaginary part to just cancel the imaginary part of Y_1 :

$$Y_2 = \begin{cases} -j, & l_1 = 0.25\lambda \\ +j, & l_1 = 0.427\lambda \end{cases}$$
(8)

which means, since the shorted end has an infinite admittance at D that the stub must be of length such as to rotate the admittance to the points E or F requiring a stub length l_2 of $(\lambda/8)(E)$ or $(3\lambda/8)(F)$ (or these values plus any integer multiple



Figure 8-24 (a) A single stub tuner consisting of a variable length short circuited line l_2 can match any load to the line by putting the stub at the appropriate distance l_1 from the load. (b) Smith chart construction. (c) Voltage standing wave pattern.

624



or



of $\lambda/2$). Thus, the solutions can be summarized as

$$l_1 = 0.25\lambda + n\lambda/2, \qquad l_2 = \lambda/8 + m\lambda/2 l_1 = 0.427\lambda + n\lambda/2, \qquad l_2 = 3\lambda/8 + m\lambda/2$$
(9)

where n and m are any nonnegative integers (including zero).

When the load is matched by the stub to the line, the VSWR to the left of the stub is unity, while to the right of the stub over the length l_1 the reflection coefficient is

$$\Gamma_L = \frac{Z_{nL} - 1}{Z_{nL} + 1} = \frac{j}{2 + j} \tag{10}$$

which has magnitude

$$|\Gamma_L| = 1/\sqrt{5} \approx 0.447$$
 (11)

so that the voltage standing wave ratio is

$$VSWR = \frac{1 + |\Gamma_L|}{1 - |\Gamma_L|} \approx 2.62$$
(12)

The disadvantage to single-stub tuning is that it is not easy to vary the length l_1 . Generally new elements can only be connected at the ends of the line and not inbetween.

8-5-3 Double-Stub Matching

This difficulty of not having a variable length line can be overcome by using two short circuited stubs a fixed length apart, as shown in Figure 8-25*a*. This fixed length is usually $\frac{3}{8}\lambda$. A match is made by adjusting the length of the stubs l_1 and



Figure 8-25 (a) A double stub tuner of fixed spacing cannot match all loads but is useful because additional elements can only be placed at transmission line terminations and not at any general position along a line as required for a single-stub tuner. (b) Smith chart construction. If the stubs are $\frac{3}{5}\lambda$ apart, normalized load admittances whose real part exceeds 2 cannot be matched.

626

 l_2 . One problem with the double-stub tuner is that not all loads can be matched for a given stub spacing.

The normalized admittances at each junction are related as

$$Y_a = Y_1 + Y_L \tag{13}$$

$$Y_n = Y_2 + Y_b \tag{(11)}$$

where Y_1 and Y_2 are the purely reactive admittances of the stubs reflected back to the junctions while Y_b is the admittance of Y_a reflected back towards the load by $\frac{3}{8}\lambda$. For a match we require that Y_n be unity. Since Y_2 is purely imaginary, the real part of Y_b must lie on the circle with a real part of unity. Then Y_a must lie somewhere on this circle when each point on the circle is reflected back by $\frac{3}{8}\lambda$. This generates another circle that is $\frac{3}{2}\pi$ back in the counterclockwise direction as we are moving toward the load, as illustrated in Figure 8-25b. To find the conditions for a match, we work from left to right towards the load using the following reasoning:

- (i) Since Y_2 is purely imaginary, the real part of Y_b must lie on the circle with a real part of unity, as in Figure 8-25b.
- (ii) Every possible point on Y_b must be reflected towards the load by $\frac{3}{8}\lambda$ to find the locus of possible match for Y_a . This generates another circle that is $\frac{3}{2}\pi$ back in the counter-clockwise direction as we move towards the load, as in Figure 8-25b.

Again since Y_1 is purely imaginary, the real part of Y_a must also equal the real part of the load admittance. This yields two possible solutions if the load admittance is outside the forbidden circle enclosing all load admittances with a real part greater than 2. Only loads with normalized admittances whose real part is less than 2 can be matched by the doublestub tuner of $\frac{3}{8}\lambda$ spacing. Of course, if a load is within the forbidden circle, it can be matched by a double-stub tuner if the stub spacing is different than $\frac{3}{8}\lambda$.

EXAMPLE 8-4 DOUBLE-STUB MATCHING

The load impedance $Z_L = 50(1+j)$ on a 50-Ohm line is to be matched by a double-stub tuner of $\frac{3}{8}\lambda$ spacing. What stub lengths l_1 and l_2 are necessary?

SOLUTION

The normalized load impedance $Z_{nL} = 1 + j$ corresponds to a normalized load admittance:

$$Y_{nL} = 0.5(1-j)$$



Figure 8-26 (a) The Smith chart construction for a double-stub tuner of $\frac{3}{8}\lambda$ spacing with $Z_{nL} = 1 + j$. (b) The voltage standing wave pattern.

628

Then the two solutions for Y_a lie on the intersection of the circle shown in Figure 8-26*a* with the r = 0.5 circle:

$$Y_{a1} = 0.5 - 0.14j$$

 $Y_{a2} = 0.5 - 1.85j$

We then find Y_1 by solving for the imaginary part of the upper equation in (13):

$$Y_1 = j \operatorname{Im} (Y_a - Y_L) = \begin{cases} 0.36j \Rightarrow l_1 = 0.305\lambda & (F) \\ -1.35j \Rightarrow l_1 = 0.1\lambda & (E) \end{cases}$$

By rotating the Y_a solutions by $\frac{3}{8}\lambda$ back to the generator (270° clockwise, which is equivalent to 90° counterclockwise), their intersection with the r = 1 circle gives the solutions for Y_b as

$$Y_{b1} = 1.0 - 0.72j$$
$$Y_{b2} = 1.0 + 2.7j$$

This requires Y_2 to be

$$Y_2 = -j \operatorname{Im}(Y_b) = \begin{cases} 0.72j \Rightarrow l_2 = 0.349\lambda & (G) \\ -2.7j \Rightarrow l_2 = 0.056\lambda & (H) \end{cases}$$

The voltage standing wave pattern along the line and stubs is shown in Figure 8.26b. Note the continuity of voltage at the junctions. The actual stub lengths can be those listed plus any integer multiple of $\lambda/2$.

8-6 THE RECTANGULAR WAVEGUIDE

We showed in Section 8-1-2 that the electric and magnetic fields for TEM waves have the same form of solutions in the plane transverse to the transmission line axis as for statics. The inner conductor within a closed transmission line structure such as a coaxial cable is necessary for TEM waves since it carries a surface current and a surface charge distribution, which are the source for the magnetic and electric fields. A hollow conducting structure, called a waveguide, cannot propagate TEM waves since the static fields inside a conducting structure enclosing no current or charge is zero.

However, new solutions with electric or magnetic fields along the waveguide axis as well as in the transverse plane are allowed. Such solutions can also propagate along transmission lines. Here the axial displacement current can act as a source of the transverse magnetic field giving rise to transverse magnetic (TM) modes as the magnetic field lies entirely within the transverse plane. Similarly, an axial time varying magnetic field generates transverse electric (TE) modes. The most general allowed solutions on a transmission line are TEM, TM, and TE modes. Removing the inner conductor on a closed transmission line leaves a waveguide that can only propagate TM and TE modes.

8-6-1 Governing Equations

To develop these general solutions we return to Maxwell's equations in a linear source-free material:

$$\nabla \times \mathbf{E} = -\mu \frac{\partial \mathbf{H}}{\partial t}$$

$$\nabla \times \mathbf{H} = \varepsilon \frac{\partial \mathbf{E}}{\partial t}$$

$$\varepsilon \nabla \cdot \mathbf{E} = 0$$

$$\mu \nabla \cdot \mathbf{H} = 0$$
(1)

Taking the curl of Faraday's law, we expand the double cross product and then substitute Ampere's law to obtain a simple vector equation in **E** alone:

$$\nabla \times (\nabla \times \mathbf{E}) = \nabla (\nabla \cdot \mathbf{E}) - \nabla^{2} \mathbf{E}$$
$$= -\mu \frac{\partial}{\partial t} (\nabla \times \mathbf{H})$$
$$= -\varepsilon \mu \frac{\partial^{2} \mathbf{E}}{\partial t^{2}}$$
(2)

Since $\nabla \cdot \mathbf{E} = 0$ from Gauss's law when the charge density is zero, (2) reduces to the vector wave equation in \mathbf{E} :

$$\nabla^2 \mathbf{E} = \frac{1}{c^2} \frac{\partial^2 \mathbf{E}}{\partial t^2}, \qquad c^2 = \frac{1}{\epsilon \mu}$$
(3)

If we take the curl of Ampere's law and perform similar operations, we also obtain the vector wave equation in H:

$$\nabla^2 \mathbf{H} = \frac{1}{c^2} \frac{\partial^2 \mathbf{H}}{\partial t^2} \tag{4}$$
The solutions for \mathbf{E} and \mathbf{H} in (3) and (4) are not independent. If we solve for either \mathbf{E} or \mathbf{H} , the other field is obtained from (1). The vector wave equations in (3) and (4) are valid for any shaped waveguide. In particular, we limit ourselves in this text to waveguides whose cross-sectional shape is rectangular, as shown in Figure 8-27.

8-6-2 Transverse Magnetic (TM) Modes

We first consider TM modes where the magnetic field has x and y components but no z component. It is simplest to solve (3) for the z component of electric field and then obtain the other electric and magnetic field components in terms of E_z directly from Maxwell's equations in (1).

We thus assume solutions of the form

$$E_{z} = \operatorname{Re}\left[\hat{E}_{z}(\mathbf{x}, y) e^{j(\omega t - k_{z}^{z})}\right]$$
(5)

where an exponential z dependence is assumed because the cross-sectional area of the waveguide is assumed to be uniform in z so that none of the coefficients in (1) depends on z. Then substituting into (3) yields the Helmholtz equation:



Figure 8-27 A lossless waveguide with rectangular cross section.

This equation can be solved by assuming the same product solution as used for solving Laplace's equation in Section 4-2-1, of the form

$$\hat{E}_{z}(x, y) = X(x) Y(y)$$
(7)

where X(x) is only a function of the x coordinate and Y(y) is only a function of y. Substituting this assumed form of solution into (6) and dividing through by X(x)Y(y) yields

$$\frac{1}{X}\frac{d^{2}X}{dx^{2}} + \frac{1}{Y}\frac{d^{2}Y}{dy^{2}} = k_{z}^{2} - \frac{\omega^{2}}{c^{2}}$$
(8)

When solving Laplace's equation in Section 4-2-1 the righthand side was zero. Here the reasoning is the same. The first term on the left-hand side in (8) is only a function of x while the second term is only a function of y. The only way a function of x and a function of y can add up to a constant for all x and y is if each function alone is a constant,

$$\frac{1}{X}\frac{d^2X}{dx^2} = -k_x^2$$

$$\frac{1}{Y}\frac{d^2Y}{dy^2} = -k_y^2$$
(9)

where the separation constants must obey the relation

$$k_x^2 + k_y^2 + k_z^2 = k^2 = \omega^2 / c^2 \tag{10}$$

When we solved Laplace's equation in Section 4-2-6, there was no time dependence so that $\omega = 0$. Then we found that at least one of the wavenumbers was imaginary, yielding decaying solutions. For finite frequencies it is possible for all three wavenumbers to be real for pure propagation. The values of these wavenumbers will be determined by the dimensions of the waveguide through the boundary conditions.

The solutions to (9) are sinusoids so that the transverse dependence of the axial electric field $\hat{E}_{z}(x, y)$ is

$$\hat{E}_{z}(x, y) = (A_{1} \sin k_{x}x + A_{2} \cos k_{x}x)(B_{1} \sin k_{y}y + B_{2} \cos k_{y}y)$$
(11)

Because the rectangular waveguide in Figure 8-27 is composed of perfectly conducting walls, the tangential component of electric field at the walls is zero:

$$\hat{E}_{z}(x, y = 0) = 0, \qquad \hat{E}_{z}(x = 0, y) = 0$$

$$\hat{E}_{z}(x, y = b) = 0, \qquad \hat{E}_{z}(x = a, y) = 0$$
(12)

These boundary conditions then require that A_2 and B_2 are zero so that (11) simplifies to

$$\hat{E}_{x}(x, y) = E_{0} \sin k_{x} x \sin k_{y} y \qquad (13)$$

where E_0 is a field amplitude related to a source strength and the transverse wavenumbers must obey the equalities

$$k_x = m\pi/a, \qquad m = 1, 2, 3, \dots$$

 $k_y = n\pi/b, \qquad n = 1, 2, 3, \dots$
(14)

Note that if either m or n is zero in (13), the axial electric field is zero. The waveguide solutions are thus described as TM_{mn} modes where both m and n are integers greater than zero.

The other electric field components are found from the z component of Faraday's law, where $H_z = 0$ and the charge-free Gauss's law in (1):

$$\frac{\partial E_y}{\partial x} = \frac{\partial E_x}{\partial y}$$

$$\frac{\partial E_x}{\partial x} + \frac{\partial E_y}{\partial y} + \frac{\partial E_z}{\partial z} = 0$$
(15)

By taking $\partial/\partial x$ of the top equation and $\partial/\partial y$ of the lower equation, we eliminate E_x to obtain

$$\frac{\partial^2 E_y}{\partial x^2} + \frac{\partial^2 E_y}{\partial y^2} = -\frac{\partial^2 E_z}{\partial y \, \partial z}$$
(16)

where the right-hand side is known from (13). The general solution for E_y must be of the same form as (11), again requiring the tangential component of electric field to be zero at the waveguide walls,

$$\hat{E}_{y}(x=0, y) = 0, \qquad \hat{E}_{y}(x=a, y) = 0$$
 (17)

so that the solution to (16) is

$$\hat{E}_{y} = -\frac{jk_{y}k_{z}E_{0}}{k_{x}^{2} + k_{y}^{2}} \sin k_{x}x \cos k_{y}y$$
(18)

We then solve for E_x using the upper equation in (15):

$$\hat{E}_{x} = -\frac{jk_{x}k_{z}E_{0}}{k_{x}^{2} + k_{y}^{2}}\cos k_{x}x\sin k_{y}y$$
(19)

where we see that the boundary conditions

$$\hat{E}_{\mathbf{x}}(\mathbf{x}, \mathbf{y}=0) = 0, \qquad \hat{E}_{\mathbf{x}}(\mathbf{x}, \mathbf{y}=b) = 0$$
 (20)

are satisfied.

The magnetic field is most easily found from Faraday's law

$$\hat{\mathbf{H}}(\mathbf{x}, \mathbf{y}) = -\frac{1}{j\omega\mu} \nabla \times \hat{\mathbf{E}}(\mathbf{x}, \mathbf{y})$$
(21)

to yield

$$\hat{H}_{x} = -\frac{1}{j\omega\mu} \left(\frac{\partial \hat{E}_{x}}{\partial y} - \frac{\partial \hat{E}_{y}}{\partial z} \right)$$

$$= -\frac{k_{y}k^{2}}{j\omega\mu(k_{x}^{2} + k_{y}^{2})} E_{0} \sin k_{x}x \cos k_{y}y$$

$$= \frac{j\omega\varepsilon k_{y}}{k_{x}^{2} + k_{y}^{2}} E_{0} \sin k_{x}x \cos k_{y}y$$

$$\hat{H}_{y} = -\frac{1}{j\omega\mu} \left(\frac{\partial \hat{E}_{x}}{\partial z} - \frac{\partial \hat{E}_{z}}{\partial x} \right)$$

$$= \frac{k_{x}k^{2}E_{0}}{j\omega\mu(k_{x}^{2} + k_{y}^{2})} \cos k_{x}x \sin k_{y}y$$

$$= -\frac{j\omega\varepsilon k_{x}}{k_{x}^{2} + k_{y}^{2}} E_{0} \cos k_{x}x \sin k_{y}y$$

$$\hat{H}_{z} = 0$$
(22)

Note the boundary conditions of the normal component of **H** being zero at the waveguide walls are automatically satisfied:

$$\hat{H}_{y}(x, y = 0) = 0, \qquad \hat{H}_{y}(x, y = b) = 0$$

$$\hat{H}_{x}(x = 0, y) = 0, \qquad \hat{H}_{y}(x = a, y) = 0$$
(23)

The surface charge distribution on the waveguide walls is found from the discontinuity of normal **D** fields:

$$\hat{\sigma}_{f}(x=0, y) = \varepsilon \hat{E}_{x}(x=0, y) = -\frac{jk_{x}k_{x}\varepsilon}{k_{x}^{2}+k_{y}^{2}} E_{0} \sin k_{y}y$$

$$\hat{\sigma}_{f}(x=a, y) = -\varepsilon \hat{E}_{x}(x=a, y) = \frac{jk_{x}k_{x}\varepsilon}{k_{x}^{2}+k_{y}^{2}} E_{0} \cos m\pi \sin k_{y}y$$

$$\hat{\sigma}_{f}(x, y=0) = \varepsilon \hat{E}_{y}(x, y=0) = -\frac{jk_{x}k_{y}\varepsilon}{k_{x}^{2}+k_{y}^{2}} E_{0} \sin k_{x}x$$

$$\hat{\sigma}_{f}(x, y=b) = -\varepsilon \hat{E}_{y}(x, y=b) = \frac{jk_{x}k_{y}\varepsilon}{k_{x}^{2}+k_{y}^{2}} E_{0} \cos n\pi \sin k_{x}x$$
(24)

Similarly, the surface currents are found by the discontinuity in the tangential components of H to be purely z directed:

$$\hat{K}_{z}(x, y = 0) = -\hat{H}_{x}(x, y = 0) = \frac{k_{y}k^{2}E_{0}\sin k_{x}x}{j\omega\mu(k_{x}^{2} + k_{y}^{2})}$$

$$\hat{K}_{z}(x, y = b) = \hat{H}_{x}(x, y = b) = -\frac{k_{y}k^{2}E_{0}}{j\omega\mu(k_{x}^{2} + k_{y}^{2})}\sin k_{x}x\cos n\pi$$

$$\hat{K}_{z}(x = 0, y) = \hat{H}_{y}(x = 0, y) = \frac{k_{x}k^{2}E_{0}}{j\omega\mu(k_{x}^{2} + k_{y}^{2})}\sin k_{y}y$$

$$\hat{K}_{z}(x = a, y) = -\hat{H}_{y}(x = a, y) = -\frac{k_{x}k^{2}E_{0}\cos m\pi \sin k_{y}y}{j\omega\mu(k_{x}^{2} + k_{y}^{2})}$$

We see that if m or n are even, the surface charges and surface currents on opposite walls are of opposite sign, while if m or n are odd, they are of the same sign. This helps us in plotting the field lines for the various TM_{mn} modes shown in Figure 8-28. The electric field is always normal and the magnetic field tangential to the waveguide walls. Where the surface charge is positive, the electric field points out of the wall, while it points in where the surface charge is negative. For higher order modes the field patterns shown in Figure 8-28 repeat within the waveguide.

Slots are often cut in waveguide walls to allow the insertion of a small sliding probe that measures the electric field. These slots must be placed at positions of zero surface current so that the field distributions of a particular mode are only negligibly disturbed. If a slot is cut along the z direction on the y = b surface at x = a/2, the surface current given in (25) is zero for TM modes if $sin(k_xa/2) = 0$, which is true for the m = even modes.

8-6-3 Transverse Electric (TE) Modes

When the electric field lies entirely in the xy plane, it is most convenient to first solve (4) for H_z . Then as for TM modes we assume a solution of the form

$$H_{z} = \operatorname{Re}\left[\hat{H}_{z}(\mathbf{x}, \mathbf{y}) e^{j(\omega t - k_{z} z)}\right]$$
(26)

which when substituted into (4) yields

$$\frac{\partial^2 \hat{H}_z}{\partial x^2} + \frac{\partial^2 \hat{H}_z}{\partial y^2} - \left(k_z^2 - \frac{\omega^2}{c^2}\right)\hat{H}_z = 0$$
(27)

636



Figure 8-28 The transverse electric and magnetic field lines for the TM_{11} and TM_{21} modes. The electric field is purely z directed where the field lines converge.

Again this equation is solved by assuming a product solution and separating to yield a solution of the same form as (11):

$$\hat{H}_{z}(x, y) = (A_{1} \sin k_{x}x + A_{2} \cos k_{x}x)(B_{1} \sin k_{y}y + B_{2} \cos k_{y}y) \quad (28)$$

The boundary conditions of zero normal components of **H** at the waveguide walls require that

$$\hat{H}_{x}(x=0, y) = 0, \qquad \hat{H}_{x}(x=a, y) = 0$$

 $\hat{H}_{y}(x, y=0) = 0, \qquad \hat{H}_{y}(x, y=b) = 0$ (29)

Using identical operations as in (15)-(20) for the TM modes the magnetic field solutions are

$$\hat{H}_{x} = \frac{jk_{x}k_{x}H_{0}}{k_{x}^{2} + k_{y}^{2}} \sin k_{x}x \cos k_{y}, \qquad k_{x} = \frac{m\pi}{a}, \quad k_{y} = \frac{n\pi}{b}$$

$$\hat{H}_{y} = \frac{jk_{z}k_{y}H_{0}}{k_{x}^{2} + k_{y}^{2}} \cos k_{x}x \sin k_{y}y$$

$$\hat{H}_{z} = H_{0} \cos k_{x}x \cos k_{y}y$$
(30)

The electric field is then most easily obtained from Ampere's law in (1),

$$\hat{\mathbf{E}} = \frac{1}{j\omega\varepsilon} \nabla \times \hat{\mathbf{H}}$$
(31)

to yield

$$\hat{E}_{x} = \frac{1}{j\omega\varepsilon} \left(\frac{\partial}{\partial y} \hat{H}_{z} - \frac{\partial}{\partial z} \hat{H}_{y} \right)$$

$$= -\frac{k_{y}k^{2}H_{0}}{j\omega\varepsilon(k_{x}^{2} + k_{y}^{2})} \cos k_{x}x \sin k_{y}y$$

$$= \frac{j\omega\mu k_{y}}{k_{x}^{2} + k_{y}^{2}} H_{0} \cos k_{x}x \sin k_{y}y$$

$$\hat{E}_{y} = \frac{1}{j\omega\varepsilon} \left(\frac{\partial \hat{H}_{x}}{\partial z} - \frac{\partial \hat{H}_{x}}{\partial x} \right)$$

$$= \frac{k_{x}k^{2}H_{0}}{j\omega\varepsilon(k_{x}^{2} + k_{y}^{2})} \sin k_{x}x \cos k_{y}y$$

$$= -\frac{j\omega\mu k_{x}}{k_{x}^{2} + k_{y}^{2}} H_{0} \sin k_{x}x \cos k_{y}y$$

$$\hat{E}_{y} = 0$$
(32)

We see in (32) that as required the tangential components of the electric field at the waveguide walls are zero. The surface charge densities on each of the walls are:

$$\hat{\sigma}_{f}(x=0, y) = \varepsilon \hat{E}_{x}(x=0, y) = \frac{-k_{y}k^{2}H_{0}}{j\omega(k_{x}^{2}+k_{y}^{2})} \sin k_{y}y$$

$$\hat{\sigma}_{f}(x=a, y) = -\varepsilon \hat{E}_{x}(x=a, y) = \frac{k_{y}k^{2}H_{0}}{j\omega(k_{x}^{2}+k_{y}^{2})} \cos m\pi \sin k_{y}y$$

$$\hat{\sigma}_{f}(x, y=0) = \varepsilon \hat{E}_{y}(x, y=0) = \frac{k_{x}k^{2}H_{0}}{j\omega(k_{x}^{2}+k_{y}^{2})} \sin k_{x}x$$

$$\hat{\sigma}_{f}(x, y=b) = -\varepsilon \hat{E}_{y}(x, y=b) = -\frac{k_{x}k^{2}H_{0}}{j\omega(k_{x}^{2}+k_{y}^{2})} \cos n\pi \sin k_{x}x$$
(33)

For TE modes, the surface currents determined from the discontinuity of tangential **H** now flow in closed paths on the waveguide walls:

$$\hat{\mathbf{K}}(\mathbf{x} = 0, \mathbf{y}) = \mathbf{i}_{\mathbf{x}} \times \hat{\mathbf{H}}(\mathbf{x} = 0, \mathbf{y})$$

$$= \mathbf{i}_{z} \hat{H}_{y}(\mathbf{x} = 0, \mathbf{y}) - \mathbf{i}_{y} \hat{H}_{z}(\mathbf{x} = 0, \mathbf{y})$$

$$\hat{\mathbf{K}}(\mathbf{x} = \mathbf{a}, \mathbf{y}) = -\mathbf{i}_{\mathbf{x}} \times \hat{\mathbf{H}}(\mathbf{x} = \mathbf{a}, \mathbf{y})$$

$$= -\mathbf{i}_{z} \hat{H}_{y}(\mathbf{x} = \mathbf{a}, \mathbf{y}) + \mathbf{i}_{y} \hat{H}_{z}(\mathbf{x} = \mathbf{a}, \mathbf{y})$$

$$\hat{\mathbf{K}}(\mathbf{x}, \mathbf{y} = 0) = \mathbf{i}_{y} \times \hat{\mathbf{H}}(\mathbf{x}, \mathbf{y} = 0)$$

$$= -\mathbf{i}_{z} \hat{H}_{x}(\mathbf{x}, \mathbf{y} = 0) + \mathbf{i}_{x} \hat{H}_{z}(\mathbf{x}, \mathbf{y} = 0)$$

$$\hat{\mathbf{K}}(\mathbf{x}, \mathbf{y} = \mathbf{b}) = -\mathbf{i}_{y} \times \hat{\mathbf{H}}(\mathbf{x}, \mathbf{y} = \mathbf{b})$$

$$= \mathbf{i}_{z} \hat{H}_{x}(\mathbf{x}, \mathbf{y} = \mathbf{b}) - \mathbf{i}_{x} \hat{H}_{z}(\mathbf{x}, \mathbf{y} = \mathbf{b})$$

(34)

Note that for TE modes either n or m (but not both) can be zero and still yield a nontrivial set of solutions. As shown in Figure 8-29, when n is zero there is no variation in the fields in the y direction and the electric field is purely y directed while the magnetic field has no y component. The TE₁₁ and TE₂₁ field patterns are representative of the higher order modes.

8-6-4 Cut-Off

The transverse wavenumbers are

$$k_{x} = \frac{m\pi}{a}, \qquad k_{y} = \frac{n\pi}{b} \tag{35}$$

so that the axial variation of the fields is obtained from (10) as

$$k_{z} = \left[\frac{\omega_{2}}{c^{2}} - k_{x}^{2} - k_{y}^{2}\right]^{1/2} = \left[\frac{\omega^{2}}{c^{2}} - \left(\frac{m\pi}{a}\right)^{2} - \left(\frac{n\pi}{b}\right)^{2}\right]^{1/2}$$
(36)



Figure 8-29 (a) The transverse electric and magnetic field lines for various TE modes. The magnetic field is purely z directed where the field lines converge. The TE₁₀ mode is called the dominant mode since it has the lowest cut-off frequency. (b) Surface current lines for the TE₁₀ mode.





Thus, although k_x and k_y are real, k_z can be either pure real or pure imaginary. A real value of k_z represents power flow down the waveguide in the z direction. An imaginary value of k_z means exponential decay with no time-average power flow. The transition from propagating waves (k_z real) to evanescence (k_z imaginary) occurs for $k_z = 0$. The frequency when k_z is zero is called the cut-off frequency ω_c :

$$\omega_c = c \left[\left(\frac{m\pi}{a} \right)^2 + \left(\frac{n\pi}{b} \right)^2 \right]^{1/2}$$
(37)

This frequency varies for each mode with the mode parameters *m* and *n*. If we assume that *a* is greater than *b*, the lowest cut-off frequency occurs for the TE₁₀ mode, which is called the dominant or fundamental mode. No modes can propagate below this lowest critical frequency ω_{c0} :

$$\omega_{c0} = \frac{\pi c}{a} \Rightarrow f_{c0} = \frac{\omega_{c0}}{2\pi} = \frac{c}{2a} \operatorname{Hz}$$
(38)

If an air-filled waveguide has a = 1 cm, then $f_{c0} = 1.5 \times 10^{10}$ Hz, while if a = 10 m, then $f_{c0} = 15$ MHz. This explains why we usually cannot hear the radio when driving through a tunnel. As the frequency is raised above ω_{c0} , further modes can propagate.

The phase and group velocity of the waves are

$$v_{p} = \frac{\omega}{k_{z}} = \frac{\omega}{\left[\frac{\omega^{2}}{c^{2}} - \left(\frac{m\pi}{a}\right)^{2} - \left(\frac{n\pi}{b}\right)^{2}\right]^{1/2}}$$

$$v_{g} = \frac{d\omega}{dk_{z}} = \frac{k_{z}c^{2}}{\omega} = \frac{c^{2}}{v_{p}} \Rightarrow v_{g}v_{p} = c^{2}$$
(39)

At cut-off, $v_g = 0$ and $v_p = \infty$ with their product always a constant.

8-6-5 Waveguide Power Flow

The time-averaged power flow per unit area through the waveguide is found from the Poynting vector:

$$\langle \boldsymbol{S} \rangle = \frac{1}{2} \operatorname{Re} \left(\hat{\mathbf{E}} \times \hat{\mathbf{H}}^* \right)$$
 (40)

(a) Power Flow for the TM Modes

Substituting the field solutions found in Section 8-6-2 into (40) yields

$$< \mathbf{S} >= \frac{1}{2} \operatorname{Re} \left[(\hat{E}_{x} \mathbf{i}_{x} + \hat{E}_{y} \mathbf{i}_{y} + \hat{E}_{z} \mathbf{i}_{z}) e^{-jk_{z}z} \times (\hat{H}_{x}^{*} \mathbf{i}_{x} + \hat{H}_{y}^{*} \mathbf{i}_{y}) e^{+jk_{z}^{*}z} \right]$$

$$= \frac{1}{2} \operatorname{Re} \left[(\hat{E}_{x} \hat{H}_{y}^{*} - \hat{E}_{y} \hat{H}_{x}^{*}) \mathbf{i}_{z} + \hat{E}_{z} (\hat{H}_{x}^{*} \mathbf{i}_{y} - \hat{H}_{y}^{*} \mathbf{i}_{z}) \right] e^{-j(k_{z} - k_{z}^{*})z}$$
(41)

where we remember that k_z may be imaginary for a particular mode if the frequency is below cut-off. For propagating modes where k_z is real so that $k_z = k_z^*$, there is no z dependence in (41). For evanescent modes where k_z is pure imaginary, the z dependence of the Poynting vector is a real decaying exponential of the form $e^{-2|k_z|z}$. For either case we see from (13) and (22) that the product of \hat{E}_z with \hat{H}_x and \hat{H}_y is pure imaginary so that the real parts of the x- and y-directed time average power flow are zero in (41). Only the z-directed power flow can have a time average:

$$< S > = \frac{\omega \varepsilon |E_0|^2}{2(k_x^2 + k_y^2)} \operatorname{Re} \left[k_z \, e^{-j(k_z - k_z^*)^2} (k_x^2 \cos^2 k_x x \sin^2 k_y y + k_y^2 \sin^2 k_x x \cos^2 k_y y)\right] \mathbf{i}_z$$
(42)

If k_z is imaginary, we have that $\langle S \rangle = 0$ while a real k_z results in a nonzero time-average power flow. The total z-directed power flow is found by integrating (42) over the crosssectional area of the waveguide:

$$\langle P \rangle = \int_{x=0}^{a} \int_{y=0}^{b} \langle S_{z} \rangle \, dx \, dy$$
$$= \frac{\omega \varepsilon k_{z} a b E_{0}^{2}}{8(k_{z}^{2} + k_{y}^{2})}$$
(43)

where it is assumed that k_z is real, and we used the following identities:

$$\int_{0}^{a} \sin^{2} \frac{m\pi x}{a} dx = \frac{a}{m\pi} \left(\frac{1}{2} \frac{m\pi x}{a} - \frac{1}{4} \sin \frac{2m\pi x}{a} \right) \Big|_{0}^{a}$$
$$= \begin{cases} a/2, & m \neq 0\\ 0, & m = 0 \end{cases}$$
$$\int_{0}^{a} \cos^{2} \frac{m\pi x}{a} dx = \frac{a}{m\pi} \left(\frac{1}{2} \frac{m\pi x}{a} + \frac{1}{4} \sin \frac{2m\pi x}{a} \right) \Big|_{0}^{a}$$
$$= \begin{cases} a/2, & m \neq 0\\ a, & m = 0 \end{cases}$$
(44)

For the TM modes, both m and n must be nonzero.

(b) Power Flow for the TE Modes

The same reasoning is used for the electromagnetic fields found in Section 8-6-3 substituted into (40):

$$<\mathbf{S}> = \frac{1}{2} \operatorname{Re} \left[(\hat{E}_{x} \mathbf{i}_{x} + \hat{E}_{y} \mathbf{i}_{y}) e^{-jk_{z}z} \times (\hat{H}_{x}^{*} \mathbf{i}_{x} + \hat{H}_{y}^{*} \mathbf{i}_{y} + \hat{H}_{z}^{*} \mathbf{i}_{z}) e^{+jk_{z}^{*}z} \right]$$

$$= \frac{1}{2} \operatorname{Re} \left[(\hat{E}_{x} \hat{H}_{y}^{*} - \hat{E}_{y} \hat{H}_{x}^{*}) \mathbf{i}_{z} - \hat{H}_{z}^{*} (\hat{E}_{x} \mathbf{i}_{y} - \hat{E}_{y} \mathbf{i}_{x}) \right] e^{-j(k_{z} - k_{z}^{*})z}$$
(45)

Similarly, again we have that the product of H_z^* with \hat{E}_x and \hat{E}_y is pure imaginary so that there are no x- and y-directed time average power flows. The z-directed power flow reduces to

.

$$= \frac{1}{2} \frac{\omega \mu H_{0}^{2}}{(k_{x}^{2} + k_{y}^{2})} (k_{y}^{2} \cos^{2} k_{x} x \sin^{2} k_{y} y + k_{x}^{2} \sin^{2} k_{x} x \cos^{2} k_{y} y) \operatorname{Re}(k_{z} e^{-j(k_{z} - k_{z}^{*})^{2}})$$
(46)

Again we have nonzero z-directed time average power flow only if k_z is real. Then the total z-directed power is

$$< P > = \int_{x=0}^{a} \int_{y=0}^{b} dx \, dy = \begin{cases} \frac{\omega \mu k_{z} a b H_{0}^{2}}{8(k_{x}^{2} + k_{y}^{2})}, & m, n \neq 0\\ \frac{\omega \mu k_{z} a b H_{0}^{2}}{4(k_{x}^{2} + k_{y}^{2})}, & m \text{ or } n = 0 \end{cases}$$

$$(47)$$

where we again used the identities of (44). Note the factor of 2 differences in (47) for either the TE_{10} or TE_{01} modes. Both m and n cannot be zero as the TE_{00} mode reduces to the trivial spatially constant uncoupled z-directed magnetic field.

8-6-6 Wall Losses

If the waveguide walls have a high but noninfinite Ohmic conductivity σ_w , we can calculate the spatial attenuation rate using the approximate perturbation approach described in Section 8-3-4b. The fields decay as $e^{-\alpha x}$, where

$$\alpha = \frac{1}{2} \frac{\langle P_{dL} \rangle}{\langle P \rangle} \tag{48}$$

where $\langle P_{dL} \rangle$ is the time-average dissipated power per unit length and $\langle P \rangle$ is the electromagnetic power flow in the lossless waveguide derived in Section 8-6-5 for each of the modes.

In particular, we calculate α for the TE₁₀ mode ($k_x = \pi/a$, $k_y = 0$). The waveguide fields are then

$$\hat{\mathbf{H}} = H_0 \left(\mathbf{i}_x \frac{j \mathbf{k}_z a}{\pi} \sin \frac{\pi x}{a} + \cos \frac{\pi x}{a} \mathbf{i}_z \right)$$
$$\hat{\mathbf{E}} = -\frac{j \omega \mu a}{\pi} H_0 \sin \frac{\pi x}{a} \mathbf{i}, \qquad (49)$$

The surface current on each wall is found from (34) as

$$\hat{\mathbf{K}}(\mathbf{x}=0, \mathbf{y}) = \hat{\mathbf{K}}(\mathbf{x}=a, \mathbf{y}) = -H_0 \mathbf{i}_{\mathbf{y}}$$
$$\hat{\mathbf{K}}(\mathbf{x}, \mathbf{y}=0) = -\hat{\mathbf{K}}(\mathbf{x}, \mathbf{y}=b) = H_0 \left(-\mathbf{i}_z \frac{j\mathbf{k}_z a}{\pi} \sin \frac{\pi x}{a} + \mathbf{i}_x \cos \frac{\pi x}{a}\right)$$
(50)

With lossy walls the electric field component \mathbf{E}_{w} within the walls is in the same direction as the surface current proportional by a surface conductivity $\sigma_{w}\delta$, where δ is the skin depth as found in Section 8-3-4b. The time-average dissipated power density per unit area in the walls is then:

$$\langle P_{d}(\mathbf{x}=0, \mathbf{y}) \rangle = \langle P_{d}(\mathbf{x}=a, \mathbf{y}) \rangle$$
$$= \frac{1}{2} \operatorname{Re} \left(\hat{\mathbf{E}}_{w} \cdot \hat{\mathbf{K}}^{*} \right) = \frac{1}{2} \frac{H_{0}^{2}}{\sigma_{w} \delta}$$
$$\langle P_{d}(\mathbf{x}, \mathbf{y}=0) \rangle = \langle P_{d}(\mathbf{x}, \mathbf{y}=b) \rangle$$
$$= \frac{1}{2} \frac{H_{0}^{2}}{\sigma_{w} \delta} \left[\left(\frac{\mathbf{k}_{z}a}{\pi} \right)^{2} \sin^{2} \frac{\pi \mathbf{x}}{a} + \cos^{2} \frac{\pi \mathbf{x}}{a} \right]$$
(51)

The total time average dissipated power per unit length $\langle P_{dL} \rangle$ required in (48) is obtained by integrating each of the

terms in (51) along the waveguide walls:

$$< P_{dL} > = \int_{0}^{b} \left[< P_{d}(x = 0, y) > + < P_{d}(x = a, y) > \right] dy + \int_{0}^{a} \left[< P_{d}(x, y = 0) > + < P_{d}(x, y = b) > \right] dx = \frac{H_{0}^{2}b}{\sigma_{w}\delta} + \frac{H_{0}^{2}}{\sigma_{w}\delta} \int_{0}^{a} \left[\left(\frac{k_{x}a}{\pi} \right)^{2} \sin^{2} \frac{\pi x}{a} + \cos^{2} \frac{\pi x}{a} \right] dx = \frac{H_{0}^{2}}{\sigma_{w}\delta} \left\{ b + \frac{a}{2} \left[\left(\frac{k_{z}a}{\pi} \right)^{2} + 1 \right] \right\} = \frac{H_{0}^{2}}{\sigma_{w}\delta} \left[b + \frac{a}{2} \left(\frac{\omega^{2}a^{2}}{\pi^{2}c^{2}} \right) \right]$$
(52)

while the electromagnetic power above cut-off for the TE_{10} mode is given by (47),

$$\langle P \rangle = \frac{\omega \mu k_z a b H_0^2}{4(\pi/a)^2} \tag{53}$$

so that

$$\alpha = \frac{1}{2} \frac{\langle P_{dL} \rangle}{\langle P \rangle} = \frac{2\left(\frac{\pi}{a}\right)^2 \left[b + \frac{a}{2}\left(\frac{\omega^2 a^2}{\pi^2 c^2}\right)\right]}{\omega \mu abk_z \sigma_w \delta}$$
(54)

where

$$k_{z} = \left[\frac{\omega^{2}}{c^{2}} - \left(\frac{\pi}{a}\right)^{2}\right]^{1/2}; \qquad \frac{\omega}{c} > \frac{\pi}{a}$$
(55)

8-7 DIELECTRIC WAVEGUIDE

We found in Section 7-10-6 for fiber optics that electromagnetic waves can also be guided by dielectric structures if the wave travels from the dielectric to free space at an angle of incidence greater than the critical angle. Waves propagating along the dielectric of thickness 2d in Figure 8-30 are still described by the vector wave equations derived in Section 8-6-1.

8-7-1 TM Solutions

We wish to find solutions where the fields are essentially confined within the dielectric. We neglect variations with y so that for TM waves propagating in the z direction the z component of electric field is given in Section 8-6-2 as

$$E_{z}(x, t) = \begin{cases} \operatorname{Re} \left[A_{2} e^{-\alpha(x-d)} e^{j(\omega t - k_{z}^{2})} \right], & x \ge d \\ \operatorname{Re} \left[(A_{1} \sin k_{x}x + B_{1} \cos k_{x}x) e^{j(\omega t - k_{z}^{2})} \right], & |x| \le d \\ \operatorname{Re} \left[A_{3} e^{\alpha(x+d)} e^{j(\omega t - k_{z}^{2})} \right], & x \le -d \end{cases}$$
(1)



Figure 8-30 TE and TM modes can also propagate along dielectric structures. The fields can be essentially confined to the dielectric over a frequency range if the speed of the wave in the dielectric is less than that outside. It is convenient to separate the solutions into even and odd modes.

where we choose to write the solution outside the dielectric in the decaying wave form so that the fields are predominantly localized around the dielectric.

The wavenumbers and decay rate obey the relations

$$k_x^2 + k_z^2 = \omega^2 \varepsilon \mu$$

- $\alpha^2 + k_z^2 = \omega^2 \varepsilon_0 \mu_0$ (2)

The z component of the wavenumber must be the same in all regions so that the boundary conditions can be met at each interface. For propagation in the dielectric and evanescence in free space, we must have that

$$\boldsymbol{\omega}^2 \boldsymbol{\varepsilon}_0 \boldsymbol{\mu}_0 < \boldsymbol{k}_z < \boldsymbol{\omega}^2 \boldsymbol{\varepsilon} \boldsymbol{\mu} \tag{3}$$

All the other electric and magnetic field components can be found from (1) in the same fashion as for metal waveguides in Section 8-6-2. However, it is convenient to separately consider each of the solutions for E_z within the dielectric.

(a) Odd Solutions

If E_z in each half-plane above and below the centerline are oppositely directed, the field within the dielectric must vary solely as $\sin k_x x$:

$$\hat{E}_{z} = \begin{cases} A_{2} e^{-\alpha(x-d)}, & x \ge d \\ A_{1} \sin k_{x}x, & |x| \le d \\ A_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(4)

Then because in the absence of volume charge the electric field has no divergence,

$$\frac{\partial \hat{E}_{x}}{\partial x} - jk_{x}\hat{E}_{z} \Rightarrow \hat{E}_{x} = \begin{cases} -\frac{jk_{z}}{\alpha}A_{2} e^{-\alpha(x-d)}, & x \ge d \\ -\frac{jk_{z}}{\alpha}A_{1} \cos k_{x}x, & |x| \le d \\ \frac{jk_{z}}{\alpha}A_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(5)

while from Faraday's law the magnetic field is

$$\hat{H}_{y} = -\frac{1}{j\omega\mu} \left(-jk_{z}\hat{E}_{x} - \frac{\partial\hat{E}_{z}}{\partial x} \right)$$

$$\Rightarrow \hat{H}_{y} = \begin{cases} -\frac{j\omega\varepsilon_{0}A_{2}}{\alpha}e^{-\alpha(x-d)}, & x \ge d \\ -\frac{j\omega\varepsilon A_{1}}{k_{x}}\cos k_{x}x, & |x| \le d \\ \frac{j\omega\varepsilon_{0}A_{3}}{\alpha}e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(6)

At the boundaries where $x = \pm d$ the tangential electric and magnetic fields are continuous:

$$E_{z}(x = \pm d_{-}) = E_{z}(x = \pm d_{+}) \Rightarrow A_{1} \sin k_{x}d = A_{2}$$

$$-A_{1} \sin k_{x}d = A_{3}$$

$$H_{y}(x = \pm d_{-}) = H_{y}(x = \pm d_{+}) \Rightarrow \frac{-j\omega\varepsilon A_{1}}{k_{x}}\cos k_{x}d = \frac{-j\omega\varepsilon_{0}A_{2}}{\alpha}$$
(7)
$$\frac{-j\omega\varepsilon A_{1}}{k_{x}}\cos k_{x}d = \frac{j\omega\varepsilon_{0}A_{3}}{\alpha}$$

which when simultaneously solved yields

$$\frac{A_2}{A_1} = \sin k_x d = \frac{\varepsilon \alpha}{\varepsilon_0 k_x} \cos k_x d$$

$$\frac{A_3}{A_1} = -\sin k_x d = -\frac{\varepsilon \alpha}{\varepsilon_0 k_x} \cos k_x d$$

$$\Rightarrow \alpha = \frac{\varepsilon_0}{\varepsilon} k_x \tan k_x d \quad (8)$$

The allowed values of α and k_x are obtained by self-consistently solving (8) and (2), which in general requires a numerical method. The critical condition for a guided wave occurs when $\alpha = 0$, which requires that $k_x d = n\pi$ and $k_z^2 = \omega^2 \varepsilon_0 \mu_0$. The critical frequency is then obtained from (2) as

$$\omega^{2} = \frac{k_{x}^{2}}{\varepsilon \mu - \varepsilon_{0} \mu_{0}} = \frac{(n\pi/d)^{2}}{\varepsilon \mu - \varepsilon_{0} \mu_{0}}$$
(9)

Note that this occurs for real frequencies only if $\epsilon \mu > \epsilon_0 \mu_0$.

(b) Even Solutions

If E_z is in the same direction above and below the dielectric, solutions are similarly

$$\hat{E}_{z} = \begin{cases} B_{2} e^{-\alpha(x-d)}, & x \ge d \\ B_{1} \cos k_{x}x, & |x| \le d \\ B_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(10)

$$\hat{E}_{x} = \begin{cases} -\frac{jk_{x}}{\alpha}B_{2} e^{-\alpha(x-d)}, & x \ge d \\ \frac{jk_{x}}{k_{x}}B_{1} \sin k_{x}x, & |x| \le d \\ jk_{x} = -\alpha(x+d) \end{cases}$$
(11)

$$\begin{cases} \frac{j}{\alpha} B_3 e^{a(x+a)}, & x \le -d \\ \left(-\frac{j\omega\varepsilon_0}{\alpha} B_2 e^{-\alpha(x-d)}, & x \ge d \end{cases} \end{cases}$$

$$\hat{H}_{y} = \begin{cases} \frac{\omega}{k_{x}} B_{1} \sin k_{x} x, & |x| \leq d \\ \frac{j\omega\varepsilon_{0}}{\alpha} B_{3} e^{\alpha(x+d)}, & x \leq -d \end{cases}$$
(12)

Continuity of tangential electric and magnetic fields at $x = \pm d$ requires

$$B_1 \cos k_x d = B_2, \qquad B_1 \cos k_x d = B_3$$
$$\frac{j\omega\varepsilon}{k_x} B_1 \sin k_x d = -\frac{j\omega\varepsilon_0}{\alpha} B_2, \qquad -\frac{j\omega\varepsilon B_1}{k_x} \sin k_x d = \frac{j\omega\varepsilon_0 B_3}{\alpha} \qquad (13)$$

or

$$\frac{B_2}{B_1} = \cos k_x d = -\frac{\varepsilon \alpha}{\varepsilon_0 k_x} \sin k_x d \Rightarrow \alpha = -\frac{\varepsilon_0 k_x}{\varepsilon} \cot k_x d \quad (14)$$
$$\Rightarrow \alpha = -\frac{\varepsilon_0 k_x}{\varepsilon} \cot k_x d \quad (14)$$

8-7-2 TE Solutions

The same procedure is performed for the TE solutions by first solving for H_z .

(a) Odd Solutions

$$\hat{H}_{z} = \begin{cases} A_{2} e^{-\alpha(x-d)}, & x \ge d \\ A_{1} \sin k_{x}x, & |x| \le d \\ A_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(15)

$$\hat{H}_{x} = \begin{cases} -\frac{jk_{x}}{\alpha}A_{2} e^{-\alpha(x-d)}, & x \ge d \\ -\frac{jk_{x}}{k_{x}}A_{1} \cos k_{x}x, & |x| \le d \\ \frac{jk_{z}}{\alpha}A_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$

$$\hat{E}_{y} = \begin{cases} \frac{j\omega\mu_{0}}{\alpha}A_{2} e^{-\alpha(x-d)}, & x \ge d \\ \frac{j\omega\mu}{k_{x}}A_{1} \cos k_{x}x, & |x| \le d \\ -\frac{j\omega\mu_{0}}{\alpha}A_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(16)

where continuity of tangential **E** and **H** across the boundaries requires

$$\alpha = \frac{\mu_0}{\mu} k_x \tan k_x d \tag{18}$$

(b) Even Solutions

$$\hat{H}_{z} = \begin{cases} B_{2} e^{-\alpha(x-d)}, & x \ge d \\ B_{1} \cos h_{x}x, & |x| \le d \\ B_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(19)

$$\hat{H}_{x} = \begin{cases} -\frac{jk_{z}}{\alpha}B_{2} e^{-\alpha(x-d)}, & x \ge d \\ \frac{jk_{z}}{k_{x}}B_{1} \sin k_{x}x, & |x| \le d \\ \vdots \end{cases}$$
(20)

$$\left(\frac{jk_{z}}{\alpha}B_{3}e^{\alpha(x+d)}, \qquad x\leq -d\right)$$

$$\hat{E}_{y} = \begin{cases} \frac{j\omega\mu_{0}}{\alpha}B_{2} e^{-\alpha(x-d)}, & x \ge d \\ -\frac{j\omega\mu}{k_{x}}B_{1}\sin k_{x}x, & |x| \le d \\ -\frac{j\omega\mu_{0}}{\alpha}B_{3} e^{\alpha(x+d)}, & x \le -d \end{cases}$$
(21)

where α and k_x are related as

$$\alpha = -\frac{\mu_0}{\mu} \mathbf{k}_{\mathbf{x}} \cot \mathbf{k}_{\mathbf{x}} d \tag{22}$$

Section 8-1

1. Find the inductance and capacitance per unit length and the characteristic impedance for the wire above plane and two wire line shown in Figure 8-3. (**Hint:** See Section 2-6-4c.)

2. The inductance and capacitance per unit length on a lossless transmission line is a weak function of z as the distance between electrodes changes slowly with z.



(a) For this case write the transmission line equations as single equations in voltage and current.

(b) Consider an exponential line, where

$$L(z) = L_0 e^{\alpha z}, \qquad C(z) = C_0 e^{-\alpha z}$$

If the voltage and current vary sinusoidally with time as

$$v(z, t) = \operatorname{Re}\left[\hat{v}(z) \ e^{j\omega t}\right], \qquad i(z, t) = \operatorname{Re}\left[\hat{i}(z) \ e^{j\omega t}\right]$$

find the general form of solution for the spatial distributions of $\hat{v}(z)$ and $\hat{i}(z)$.

(c) The transmission line is excited by a voltage source $V_0 \cos \omega t$ at z = 0. What are the voltage and current distributions if the line is short or open circuited at z = l?

(d) For what range of frequency do the waves strictly decay with distance? What is the cut-off frequency for wave propagation?

(e) What are the resonant frequencies of the short circuited line?

(f) What condition determines the resonant frequencies of the open circuited line.

3. Two conductors of length l extending over the radial distance $a \le r \le b$ are at a constant angle α apart.

(a) What are the electric and magnetic fields in terms of the voltage and current?

(b) Find the inductance and capacitance per unit length. What is the characteristic impedance?



4. A parallel plate transmission line is filled with a conducting plasma with constitutive law



(a) How are the electric and magnetic fields related?

(b) What are the transmission line equations for the voltage and current?

(c) For sinusoidal signals of the form $e^{j(\omega t - kz)}$, how are ω and k related? Over what frequency range do we have propagation or decay?

(d) The transmission line is short circuited at z = 0 and excited by a voltage source $V_0 \cos \omega t$ at z = -l. What are the voltage and current distributions?

(e) What are the resonant frequencies of the system?

5. An unusual type of distributed system is formed by series capacitors and shunt inductors.



(a) What are the governing partial differential equations relating the voltage and current?

(b) What is the dispersion relation between ω and k for signals of the form $e^{j(\omega t - kx)}$?

(c) What are the group and phase velocities of the waves? Why are such systems called "backward wave"?

(d) A voltage $V_0 \cos \omega t$ is applied at z = -l with the z = 0 end short circuited. What are the voltage and current distributions along the line?

(e) What are the resonant frequencies of the system?

Section 8-2

6. An infinitely long transmission line is excited at its center by a step voltage V_0 turned on at t=0. The line is initially at rest.



(a) Plot the voltage and current distributions at time T.

(b) At this time T the voltage is set to zero. Plot the voltage and current everywhere at time 2T.

7. A transmission line of length l excited by a step voltage source has its ends connected together. Plot the voltage and current at z = l/4, l/2, and 3l/4 as a function of time.



8. The dc steady state is reached for a transmission line loaded at z = l with a resistor R_L and excited at z = 0 by a dc voltage V_0 applied through a source resistor R_s . The voltage source is suddenly set to zero at t = 0.

(a) What is the initial voltage and current along the line?



(b) Find the voltage at the z = l end as a function of time. (Hint: Use difference equations.)

9. A step current source turned on at t = 0 is connected to the z = 0 end of a transmission line in parallel with a source resistance R_s . A load resistor R_L is connected at z = l.



(a) What is the load voltage and current as a function of time? (Hint: Use a Thevenin equivalent network at z = 0 with the results of Section 8-2-3.)

(b) With $R_s = \infty$ plot versus time the load voltage when $R_L = \infty$ and the load current when $R_L = 0$.

(c) If $R_s = \infty$ and $R_t = \infty$, solve for the load voltage in the quasi-static limit assuming the transmission line is a capacitor. Compare with (b).

(d) If R_s is finite but $R_L = 0$, what is the time dependence of the load current?

(e) Repeat (d) in the quasi-static limit where the transmission line behaves as an inductor. When are the results of (d) and (e) approximately equal?

10. Switched transmission line systems with an initial dc voltage can be used to generate high voltage pulses of short time duration. The line shown is charged up to a dc voltage V_0 when at t=0 the load switch is closed and the source switch is opened.



(a) What are the initial line voltage and current? What are V_+ and V_- ?

(b) Sketch the time dependence of the load voltage.

11. For the trapezoidal voltage excitation shown, plot versus time the current waveforms at z=0 and z=l for $R_L=2Z_0$ and $R_L=\frac{1}{2}Z_0$.



12. A step voltage is applied to a loaded transmission line with $R_L = 2Z_0$ through a matching source resistor.



(a) Sketch the source current $i_s(t)$.

(b) Using superposition of delayed step voltages find the time dependence of $i_s(t)$ for the various pulse voltages shown.

(c) By integrating the appropriate solution of (b), find $i_s(t)$ if the applied voltage is the triangle wave shown.

13. A dc voltage has been applied for a long time to the transmission line circuit shown with switches S_1 and S_2 open

when at t = 0:

- (a) S_2 is suddenly closed with S_1 kept open;
- (b) S_1 is suddenly closed with S_2 kept open;
- (c) Both S_1 and S_2 are closed.



For each of these cases plot the source current $i_s(t)$ versus time.

14. For each of the transmission line circuits shown, the switch opens at t=0 after the dc voltage has been applied for a long time.



(a) What are the transmission line voltages and currents right before the switches open? What are V_+ and V_- at t=0?

(b) Plot the voltage and current as a function of time at z = l/2.

15. A transmission line is connected to another transmission line with double the characteristic impedance.

(a) With switch S_2 open, switch S_1 is suddenly closed at t=0. Plot the voltage and current as a function of time half-way down each line at points a and b.

(b) Repeat (a) if S_2 is closed.



Section 8-3

16. A transmission line is excited by a voltage source $V_0 \cos \omega t$ at z = -l. The transmission line is loaded with a purely reactive load with impedance jX at z = 0.



(a) Find the voltage and current distribution along the line.

(b) Find an expression for the resonant frequencies of the system if the load is capacitive or inductive. What is the solution if $|X| = Z_0$?

(c) Repeat (a) and (b) if the transmission line is excited by a current source $I_0 \cos \omega t$ at z = -l.

17. (a) Find the resistance and conductance per unit lengths for a coaxial cable whose dielectric has a small Ohmic conductivity σ and walls have a large conductivity σ_{w} . (Hint: The skin depth δ is much smaller than the radii or thickness of either conductor.)



- (b) What is the decay rate of the fields due to the losses?
- (c) If the dielectric is lossless ($\sigma = 0$) with a fixed value of

outer radius b, what value of inner radius a will minimize the decay rate? (Hint: $1+1/3.6 \approx \ln 3.6$.)

18. A transmission line of length l is loaded by a resistor R_L .



(a) Find the voltage and current distributions along the line.

(b) Reduce the solutions of (a) when the line is much shorter than a wavelength.

(c) Find the approximate equivalent circuits in the long wavelength limit $(kl \ll 1)$ when R_L is very small $(R_L \ll Z_0)$ and when it is very large $(R_L \gg Z_0)$.

Section 8-4

19. For the transmission line shown:



(a) Find the values of lumped reactive admittance Y = jB and non-zero source resistance R_s that maximizes the power delivered by the source. (Hint: Do not use the Smith chart.)

(b) What is the time-average power dissipated in the load?

20. (a) Find the time-average power delivered by the source for the transmission line system shown when the switch is open or closed. (**Hint:** Do not use the Smith chart.)



(b) For each switch position, what is the time average power dissipated in the load resistor R_L ?

(c) For each switch position what is the VSWR on each line?

21. (a) Using the Smith chart find the source current delivered (magnitude and phase) for the transmission line system shown, for $l = \lambda/8$, $\lambda/4$, $3\lambda/8$, and $\lambda/2$.



(b) For each value of l, what are the time-average powers delivered by the source and dissipated in the load impedance Z_L ?

(c) What is the VSWR?

22. (a) Without using the Smith chart find the voltage and current distributions for the transmission line system shown.



(b) What is the VSWR?

(c) At what positions are the voltages a maximum or a minimum? What is the voltage magnitude at these positions?

23. The VSWR on a 100-Ohm transmission line is 3. The distance between successive voltage minima is 50 cm while the distance from the load to the first minima is 20 cm. What are the reflection coefficient and load impedance?

Section 8-5

24. For each of the following load impedances in the singlestub tuning transmission line system shown, find all values of the length of the line l_1 and stub length l_2 necessary to match the load to the line.

(a)
$$Z_L = 100(1-j)$$
 (c) $Z_L = 25(2-j)$
(b) $Z_L = 50(1+2j)$ (d) $Z_L = 25(1+2j)$



25. For each of the following load impedances in the doublestub tuning transmission line system shown, find stub lengths l_1 and l_2 to match the load to the line.



26. (a) Without using the Smith chart, find the input impedance Z_{in} at $z = -l = -\lambda/4$ for each of the loads shown. (b) What is the input current i(z = -l, t) for each of the loads?



(c) The frequency of the source is doubled to $2\omega_0$. The line length l and loads L and C remain unchanged. Repeat (a) and (b).

(d) The frequency of the source is halved to $\frac{1}{2}\omega_0$. Repeat (a) and (b).

Section 8-6

27. A rectangular metal waveguide is filled with a plasma with constitutive law

$$\frac{\partial \mathbf{J}_f}{\partial t} = \boldsymbol{\omega}_p^2 \boldsymbol{\varepsilon} \mathbf{E}$$

(a) Find the TE and TM solutions that satisfy the boundary conditions.

(b) What is the wavenumber k_z along the axis? What is the cut-off frequency?

(c) What are the phase and group velocities of the waves?

(d) What is the total electromagnetic power flowing down the waveguide for each of the modes?

(e) If the walls have a large but finite conductivity, what is the spatial decay rate for TE_{10} propagating waves?

28. (a) Find the power dissipated in the walls of a waveguide with large but finite conductivity σ_w for the TM_{mn} modes (**Hint:** Use Equation (25).)

(b) What is the spatial decay rate for propagating waves?

29. (a) Find the equations of the electric and magnetic field lines in the xy plane for the TE and TM modes.

(b) Find the surface current field lines on each of the

waveguide surfaces for the TE_{mn} modes. Hint:

$$\int \tan x dx = -\ln \cos x$$
$$\int \cot x dx = \ln \sin x$$

(c) For all modes verify the conservation of charge relation on the x = 0 surface:

$$\nabla_{\Sigma} \cdot \mathbf{K} + \frac{\partial \sigma_f}{\partial t} = 0$$

30. (a) Find the first ten lowest cut-off frequencies if a = b = 1 cm in a free space waveguide.

(b) What are the necessary dimensions for a square free space waveguide to have a lowest cut-off frequency of 10^{10} , 10^8 , 10^6 , 10^4 , or 10^2 Hz?

31. A rectangular waveguide of height b and width a is short circuited by perfectly conducting planes at z = 0 and z = l.

(a) Find the general form of the TE and TM electric and magnetic fields. (Hint: Remember to consider waves traveling in the $\pm z$ directions.)

(b) What are the natural frequencies of this resonator?

(c) If the walls have a large conductivity σ_w find the total time-average power $\langle P_d \rangle$ dissipated in the TE₁₀₁ mode.

(d) What is the total time-average electromagnetic energy $\langle W \rangle$ stored in the resonator?

(e) Find the Q of the resonator, defined as

$$Q = \frac{\omega_0 < W >}{< P_d >}$$

where ω_0 is the resonant frequency.

Section 8.7

32. (a) Find the critical frequency where the spatial decay rate α is zero for all the dielectric modes considered.

(b) Find approximate values of α , k_x , and k_z for a very thin dielectric, where $k_x d \ll 1$.

(c) For each of the solutions find the time-average power per unit length in each region.

(d) If the dielectric has a small Ohmic conductivity σ , what is the approximate attenuation rate of the fields.

33. A dielectric waveguide of thickness d is placed upon a perfect conductor.

(a) Which modes can propagate along the dielectric?

(b) For each of these modes, what are the surface current and charges on the conductor?



(c) Verify the conservation of charge relation:

$$\nabla_{\Sigma} \cdot \mathbf{K} + \frac{\partial \sigma_f}{\partial t} = 0$$

(d) If the conductor has a large but noninfinite Ohmic conductivity σ_{uv} , what is the approximate power per unit area dissipated?

(e) What is the approximate attenuation rate of the fields?

.

chapter 9

radiation

In low-frequency electric circuits and along transmission lines, power is guided from a source to a load along highly conducting wires with the fields predominantly confined to the region around the wires. At very high frequencies these wires become antennas as this power can radiate away into space without the need of any guiding structure.

9-1 THE RETARDED POTENTIALS

9-1-1 Nonhomogeneous Wave Equations

Maxwell's equations in complete generality are

$$\nabla \times \mathbf{E} = -\frac{\partial \mathbf{B}}{\partial t} \tag{1}$$

$$\nabla \times \mathbf{H} = \mathbf{J}_f + \frac{\partial \mathbf{D}}{\partial t}$$
(2)

$$\nabla \cdot \mathbf{B} = 0 \tag{3}$$

$$\nabla \cdot \mathbf{D} = \boldsymbol{\rho}_f \tag{4}$$

In our development we will use the following vector identities

$$\nabla \times (\nabla V) = 0 \tag{5}$$

$$\nabla \cdot (\nabla \times \mathbf{A}) = 0 \tag{6}$$

$$\nabla \times (\nabla \times \mathbf{A}) = \nabla (\nabla \cdot \mathbf{A}) - \nabla^2 \mathbf{A} \tag{7}$$

where A and V can be any functions but in particular will be the magnetic vector potential and electric scalar potential, respectively.

Because in (3) the magnetic field has no divergence, the identity in (6) allows us to again define the vector potential \mathbf{A} as we had for quasi-statics in Section 5-4:

$$\mathbf{B} = \nabla \times \mathbf{A} \tag{8}$$

so that Faraday's law in (1) can be rewritten as

$$\nabla \times \left(\mathbf{E} + \frac{\partial \mathbf{A}}{\partial t} \right) = 0 \tag{9}$$

Then (5) tells us that any curl-free vector can be written as the gradient of a scalar so that (9) becomes

$$\mathbf{E} + \frac{\partial \mathbf{A}}{\partial t} = -\nabla V \tag{10}$$

where we introduce the negative sign on the right-hand side so that V becomes the electric potential in a static situation when A is independent of time. We solve (10) for the electric field and with (8) rewrite (2) for linear dielectric media ($\mathbf{D} = \varepsilon \mathbf{E}, \mathbf{B} = \mu \mathbf{H}$):

$$\nabla \times (\nabla \times \mathbf{A}) = \mu \mathbf{J}_f + \frac{1}{c^2} \left[-\nabla \left(\frac{\partial V}{\partial t} \right) - \frac{\partial^2 \mathbf{A}}{\partial t^2} \right], \qquad c^2 = \frac{1}{\epsilon \mu}$$
(11)

The vector identity of (7) allows us to reduce (11) to

$$\nabla^{2}\mathbf{A} - \nabla \left[\nabla \cdot \mathbf{A} + \frac{1}{c^{2}} \frac{\partial V}{\partial t} \right] - \frac{1}{c^{2}} \frac{\partial^{2}\mathbf{A}}{\partial t^{2}} = -\mu \mathbf{J}_{f}$$
(12)

Thus far, we have only specified the curl of A in (8). The Helmholtz theorem discussed in Section 5-4-1 told us that to uniquely specify the vector potential we must also specify the divergence of A. This is called setting the gauge. Examining (12) we see that if we set

$$\nabla \cdot \mathbf{A} = -\frac{1}{c^2} \frac{\partial V}{\partial t} \tag{13}$$

the middle term on the left-hand side of (12) becomes zero so that the resulting relation between A and J_f is the non-homogeneous vector wave equation:

$$\nabla^2 \mathbf{A} - \frac{1}{c^2} \frac{\partial^2 \mathbf{A}}{\partial t^2} = -\mu \mathbf{J}_f \tag{14}$$

The condition of (13) is called the Lorentz gauge. Note that for static conditions, $\nabla \cdot \mathbf{A} = 0$, which is the value also picked in Section 5-4-2 for the magneto-quasi-static field. With (14) we can solve for \mathbf{A} when the current distribution \mathbf{J}_f is given and then use (13) to solve for V. The scalar potential can also be found directly by using (10) in Gauss's law of (4) as

$$\nabla^2 V + \frac{\partial}{\partial t} (\nabla \cdot \mathbf{A}) = \frac{-\rho_f}{\varepsilon}$$
(15)

The second term can be put in terms of V by using the Lorentz gauge condition of (13) to yield the scalar wave equation:

$$\nabla^2 V - \frac{1}{c^2} \frac{\partial^2 V}{\partial t^2} = \frac{-\rho_f}{\varepsilon}$$
(16)

Note again that for static situations this relation reduces to Poisson's equation, the governing equation for the quasi-static electric potential.

9-1-2 Solutions to the Wave Equation

We see that the three scalar equations of (14) (one equation for each vector component) and that of (16) are in the same form. If we can thus find the general solution to any one of these equations, we know the general solution to all of them.

As we had earlier proceeded for quasi-static fields, we will find the solution to (16) for a point charge source. Then the solution for any charge distribution is obtained using superposition by integrating the solution for a point charge over all incremental charge elements.

In particular, consider a stationary point charge at r=0 that is an arbitrary function of time Q(t). By symmetry, the resulting potential can only be a function of r so that (16) becomes

$$\frac{1}{r^2}\frac{\partial}{\partial r}\left(r^2\frac{\partial V}{\partial r}\right) - \frac{1}{c^2}\frac{\partial^2 V}{\partial t^2} = 0, \qquad r > 0 \qquad (17)$$

where the right-hand side is zero because the charge density is zero everywhere except at r=0. By multiplying (17) through by r and realizing that

$$\frac{1}{r}\frac{\partial}{\partial r}\left(r^{2}\frac{\partial V}{\partial r}\right) = \frac{\partial^{2}}{\partial r^{2}}(rV)$$
(18)

we rewrite (17) as a homogeneous wave equation in the variable (rV):

$$\frac{\partial^2}{\partial r^2}(rV) - \frac{1}{c^2} \frac{\partial^2}{\partial t^2}(rV) = 0$$
 (19)

which we know from Section 7-3-2 has solutions

$$rV = f_+\left(t - \frac{r}{c}\right) + f_-\left(t_j + \frac{r_r^0}{c}\right)$$
(20)

We throw out the negatively traveling wave solution as there are no sources for r>0 so that all waves emanate radially outward from the point charge at r=0. The arbitrary function f_+ is evaluated by realizing that as $r \rightarrow 0$ there can be no propagation delay effects so that the potential should approach the quasi-static Coulomb potential of a point charge:

$$\lim_{r \to 0} V = \frac{Q(t)}{4\pi\varepsilon r} \Rightarrow f_+(t) = \frac{Q(t)}{4\pi\varepsilon}$$
(21)
The potential due to a point charge is then obtained from (20) and (21) replacing time t with the retarded time t - r/c:

$$V(r,t) = \frac{Q(t-r/c)}{4\pi\epsilon r}$$
(22)

The potential at time t depends not on the present value of charge but on the charge value a propagation time r/c earlier when the wave now received was launched.

The potential due to an arbitrary volume distribution of charge $\rho_f(t)$ is obtained by replacing Q(t) with the differential charge element $\rho_f(t) dV$ and integrating over the volume of charge:

$$V(r, t) = \int_{\text{all charge}} \frac{\rho_f(t - r_{QP}/c)}{4\pi\varepsilon r_{QP}} \, d\mathbf{V}$$
(23)

where r_{QP} is the distance between the charge as a source at point Q and the field point at P.

The vector potential in (14) is in the same direction as the current density J_{f} . The solution for A can be directly obtained from (23) realizing that each component of A obeys the same equation as (16) if we replace ρ_f / ε by μJ_f :

$$\mathbf{A}(r, t) = \int_{\text{all current}} \frac{\mu \mathbf{J}_f(t - r_{QP}/c)}{4\pi r_{QP}} \, d\mathbf{V}$$
(24)

9-2 RADIATION FROM POINT DIPOLES

9-2-1 The Electric Dipole

The simplest building block for a transmitting antenna is that of a uniform current flowing along a conductor of incremental length dl as shown in Figure 9-1. We assume that this current varies sinusoidally with time as

$$i(t) = \operatorname{Re}\left(\hat{I} e^{j\omega t}\right) \tag{1}$$

Because the current is discontinuous at the ends, charge must be deposited there being of opposite sign at each end $[q(t) = \operatorname{Re}(\hat{Q}e^{j\omega t})]$:

$$i(t) = \pm \frac{dq}{dt} \Rightarrow \hat{I} = \pm j\omega \hat{Q}, \qquad z = \pm \frac{dl}{2}$$
 (2)

This forms an electric dipole with moment

$$\mathbf{p} = q \, dl \, \mathbf{i}_{\mathbf{x}} \tag{3}$$

If we can find the potentials and fields from this simple element, the solution for any current distribution is easily found by superposition.



Figure 9-1 A point dipole antenna is composed of a very short uniformly distributed current-carrying wire. Because the current is discontinuous at the ends, equal magnitude but opposite polarity charges accumulate there forming an electric dipole.

By symmetry, the vector potential cannot depend on the angle ϕ ,

$$A_{z} = \operatorname{Re}\left[\hat{A}_{z}(r,\theta) e^{j\omega t}\right]$$
(4)

and must be in the same direction as the current:

$$A_{z}(r, t) = \operatorname{Re}\left[\int_{-dl/2}^{+dl/2} \frac{\mu \hat{I} e^{j[\omega(t-r_{QP}/c)]}}{4\pi r_{QP}} dz\right]$$
(5)

Because the dipole is of infinitesimal length, the distance from the dipole to any field point is just the spherical radial distance τ and is constant for all points on the short wire. Then the integral in (5) reduces to a pure multiplication to yield

$$\hat{A}_{z} = \frac{\mu \hat{I} \, dl}{4 \pi r} e^{-jkr}, \qquad A_{z}(r, t) = \operatorname{Re}\left[\hat{A}_{z}(r) \, e^{j\omega t}\right] \tag{6}$$

where we again introduce the wavenumber $k = \omega/c$ and neglect writing the sinusoidal time dependence present in all field and source quantities. The spherical components of \hat{A}_{z}

are
$$(\mathbf{i}_z = \mathbf{i}_r \cos \theta - \mathbf{i}_\theta \sin \theta)$$
:

$$\hat{A}_r = \hat{A}_z \cos \theta, \qquad \hat{A}_\theta = -\hat{A}_z \sin \theta, \qquad \hat{A}_\phi = 0$$
 (7)

Once the vector potential is known, the electric and magnetic fields are most easily found from

$$\hat{\mathbf{H}} = \frac{1}{\mu} \nabla \times \hat{\mathbf{A}}, \qquad \mathbf{H}(r, t) = \operatorname{Re} \left[\hat{\mathbf{H}}(r, \theta) e^{j\omega t} \right]$$

$$\hat{\mathbf{E}} = \frac{1}{j\omega\varepsilon} \nabla \times \hat{\mathbf{H}}, \qquad \mathbf{E}(r, t) = \operatorname{Re} \left[\hat{\mathbf{E}}(r, \theta) e^{j\omega t} \right]$$
(8)

Before we find these fields, let's examine an alternate approach.

9-2-2 Alternate Derivation Using the Scalar Potential

It was easiest to find the vector potential for the point electric dipole because the integration in (5) reduced to a simple multiplication. The scalar potential is due solely to the opposite point charges at each end of the dipole,

$$\hat{V} = \frac{\hat{Q}}{4\pi\varepsilon} \left(\frac{e^{-jkr_+}}{r_+} - \frac{e^{-jkr_-}}{r_-} \right) \tag{9}$$

where r_+ and r_- are the distances from the respective dipole charges to any field point, as shown in Figure 9-1. Just as we found for the quasi-static electric dipole in Section 3-1-1, we cannot let r_+ and r_- equal r as a zero potential would result. As we showed in Section 3-1-1, a first-order correction must be made, where

$$r_{+} \approx r - \frac{dl}{2} \cos \theta$$

$$r_{-} \approx r + \frac{dl}{2} \cos \theta$$
(10)

so that (9) becomes

$$\hat{V} \approx \frac{\hat{Q}}{4\pi\varepsilon r} e^{-jkr} \left(\frac{e^{jk(dl/2)\cos\theta}}{\left(1 - \frac{dl}{2r}\cos\theta\right)} - \frac{e^{-jk(dl/2)\cos\theta}}{\left(1 + \frac{dl}{2r}\cos\theta\right)} \right)$$
(11)

Because the dipole length dl is assumed much smaller than the field distance r and the wavelength, the phase factors in the exponentials are small so they and the 1/r dependence in the denominators can be expanded in a first-order Taylor series to result in:

$$\lim_{\substack{l \neq d \leq 1 \\ k \neq r \leq 1}} \hat{V} \approx \frac{\hat{Q}}{4\pi\varepsilon r} e^{-jkr} \Big[\Big(1 + j\frac{k\,dl}{2}\cos\theta \Big) \Big(1 + \frac{dl}{2r}\cos\theta \Big) \\ - \Big(1 - jk\frac{dl}{2}\cos\theta \Big) \Big(1 - \frac{dl}{2r}\cos\theta \Big) \Big] \\ = \frac{\hat{Q}\,dl}{4\pi\varepsilon r^2} e^{-jkr}\cos\theta (1 + jkr)$$
(12)

When the frequency becomes very low so that the wavenumber also becomes small, (12) reduces to the quasi-static electric dipole potential found in Section 3-1-1 with dipole moment $\hat{p} = \hat{Q} dl$. However, we see that the radiation correction terms in (12) dominate at higher frequencies (large k) far from the dipole ($kr \gg 1$) so that the potential only dies off as 1/r rather than the quasi-static $1/r^2$. Using the relationships $\hat{Q} = \hat{I}/j\omega$ and $c = 1/\sqrt{\epsilon\mu}$, (12) could have been obtained immediately from (6) and (7) with the Lorentz gauge condition of Eq. (13) in Section 9-1-1:

$$\hat{V} = \frac{-c^2}{j\omega} \nabla \cdot \hat{A} = \frac{-c^2}{j\omega} \left(\frac{1}{r^2} \frac{\partial}{\partial r} (r^2 \hat{A}_r) + \frac{1}{r \sin \theta} \frac{\partial}{\partial \theta} (\hat{A}_\theta \sin \theta) \right)$$
$$= \frac{\mu \hat{I} \, dl \, c^2}{4 \pi j \omega} \frac{(1 + jkr)}{r^2} e^{-jkr} \cos \theta$$
$$= \frac{\hat{Q} \, dl}{4 \pi \epsilon r^2} (1 + jkr) \, e^{-jkr} \cos \theta \tag{13}$$

9-2-3 The Electric and Magnetic Fields

Using (6), the fields are directly found from (8) as

$$\hat{\mathbf{H}} = \frac{1}{\mu} \nabla \times \hat{\mathbf{A}}$$

$$= \mathbf{i}_{\phi} \frac{1}{\mu r} \left(\frac{\partial}{\partial r} (r \hat{A}_{\theta}) - \frac{\partial \hat{A}_{r}}{\partial \theta} \right)$$

$$= -\mathbf{i}_{\phi} \frac{\hat{I} \, dl}{4\pi} k^{2} \sin \theta \left(\frac{1}{jkr} + \frac{1}{(jkr)^{2}} \right) e^{-jkr} \qquad (14)$$

$$\begin{aligned} \hat{\mathbf{E}} &= \frac{1}{j\omega\varepsilon} \nabla \times \hat{\mathbf{H}} \\ &= \frac{1}{j\omega\varepsilon} \left(\frac{1}{r\sin\theta} \frac{\partial}{\partial\theta} (\hat{H}_{\phi}\sin\theta) \mathbf{i}_{r} - \frac{1}{r} \frac{\partial}{\partial r} (r\hat{H}_{\phi}) \mathbf{i}_{\theta} \right) \\ &= -\frac{\hat{I} \, dl \, k^{2}}{4\pi} \sqrt{\frac{\mu}{\varepsilon}} \Big\{ \mathbf{i}_{r} \Big[2\cos\theta \Big(\frac{1}{(jkr)^{2}} + \frac{1}{(jkr)^{3}} \Big) \Big] \\ &+ \mathbf{i}_{\theta} \Big[\sin\theta \Big(\frac{1}{jkr} + \frac{1}{(jkr)^{2}} + \frac{1}{(jkr)^{3}} \Big) \Big] \Big\} e^{-jkr} \end{aligned}$$
(15)

Note that even this simple source generates a fairly complicated electromagnetic field. The magnetic field in (14) points purely in the ϕ direction as expected by the right-hand rule for a z-directed current. The term that varies as $1/r^2$ is called the induction field or near field for it predominates at distances close to the dipole and exists even at zero frequency. The new term, which varies as 1/r, is called the radiation field since it dominates at distances far from the dipole and will be shown to be responsible for time-average power flow away from the source. The near field term does not contribute to power flow but is due to the stored energy in the magnetic field and thus results in reactive power.

The $1/r^3$ terms in (15) are just the electric dipole field terms present even at zero frequency and so are often called the electrostatic solution. They predominate at distances close to the dipole and thus are the near fields. The electric field also has an intermediate field that varies as $1/r^2$, but more important is the radiation field term in the i_0 component, which varies as 1/r. At large distances $(kr \gg 1)$ this term dominates.

In the far field limit $(kr \gg 1)$, the electric and magnetic fields are related to each other in the same way as for plane waves:

$$\lim_{kr \gg 1} \hat{E}_{\theta} = \sqrt{\frac{\mu}{\varepsilon}} \hat{H}_{\phi} = \frac{\hat{E}_0}{jkr} \sin \theta \, e^{-jkr}, \qquad \hat{E}_0 = -\frac{\hat{I} \, dl \, k^2}{4 \, \pi} \sqrt{\frac{\mu}{\varepsilon}}$$
(16)

The electric and magnetic fields are perpendicular and their ratio is equal to the wave impedance $\eta = \sqrt{\mu/\epsilon}$. This is because in the far field limit the spherical wavefronts approximate a plane.

9-2-4 Electric Field Lines

Outside the dipole the volume charge density is zero, which allows us to define an electric vector potential **C**:

$$\nabla \cdot \mathbf{E} = \mathbf{0} \Rightarrow \mathbf{E} = \nabla \times \mathbf{C} \tag{17}$$

Because the electric field in (15) only has r and θ components, **C** must only have a ϕ component, $C_{\phi}(r, \theta)$:

$$\mathbf{E} = \nabla \times \mathbf{C} = \frac{1}{r \sin \theta} \frac{\partial}{\partial \theta} (\sin \theta C_{\phi}) \mathbf{i}_{r} - \frac{1}{r} \frac{\partial}{\partial r} (rC_{\phi}) \mathbf{i}_{\theta} \qquad (18)$$

We follow the same procedure developed in Section 4-4-3b, where the electric field lines are given by

$$\frac{dr}{r\,d\theta} = \frac{E_r}{E_{\theta}} = -\frac{\frac{\partial}{\partial\theta}(\sin\theta C_{\phi})}{\sin\theta\frac{\partial}{\partial\tau}(rC_{\phi})}$$
(19)

which can be rewritten as an exact differential,

$$\frac{\partial}{\partial r}(r\sin\theta C_{\phi}) dr + \frac{\partial}{\partial \theta}(r\sin\theta C_{\phi}) d\theta = 0 \Rightarrow d(r\sin\theta C_{\phi}) = 0$$
(20)

so that the field lines are just lines of constant stream-function $r \sin \theta C_{\phi}$. C_{ϕ} is found by equating each vector component in (18) to the solution in (15):

$$\frac{1}{r\sin\theta} \frac{\partial}{\partial\theta} (\sin\theta \hat{C}_{\phi})$$

$$= \hat{E}_{r} = -\frac{\hat{I} dl k^{2}}{4\pi} \sqrt{\frac{\mu}{\epsilon}} \left[2\cos\theta \left(\frac{1}{(jkr)^{2}} + \frac{1}{(jkr)^{3}}\right) \right] e^{-jkr}$$

$$-\frac{1}{r} \frac{\partial}{\partial r} (r\hat{C}_{\phi})$$

$$= \hat{E}_{\theta} = -\frac{\hat{I} dl k^{2}}{4\pi} \sqrt{\frac{\mu}{\epsilon}} \left[\sin\theta \left(\frac{1}{(jkr)} + \frac{1}{(jkr)^{2}} + \frac{1}{(jkr)^{3}}\right) \right] e^{-jkr}$$
(21)

which integrates to

$$\hat{C}_{\phi} = \frac{\hat{I} \, dl}{4 \pi} \sqrt{\frac{\mu}{\varepsilon}} \frac{\sin \theta}{r} \left(1 - \frac{j}{(kr)} \right) e^{-jkr} \tag{22}$$

Then assuming \hat{I} is real, the instantaneous value of C_{ϕ} is

$$C_{\phi} = \operatorname{Re}\left(\hat{C}_{\phi} e^{j\omega t}\right)$$
$$= \frac{\hat{I} dl}{4\pi} \sqrt{\frac{\mu}{\varepsilon}} \frac{\sin \theta}{r} \left(\cos \left(\omega t - kr\right) + \frac{\sin \left(\omega t - kr\right)}{kr}\right)$$
(23)

so that, omitting the constant amplitude factor in (23), the field lines are

$$rC_{\phi}\sin\theta = \operatorname{const} \Rightarrow \sin^{2}\theta \left(\cos\left(\omega t - kr\right) + \frac{\sin\left(\omega t - kr\right)}{kr}\right) = \operatorname{const}$$
(24)



Figure 9-2 The electric field lines for a point electric dipole at $\omega t = 0$ and $\omega t = \pi/2$.

These field lines are plotted in Figure 9-2 at two values of time. We can check our result with the static field lines for a dipole given in Section 3-1-1. Remembering that $k = \omega/c$, at low frequencies,

$$\lim_{\omega \to 0} \begin{cases} \cos(\omega t - kr) \approx 1 \\ \frac{\sin(\omega t - kr)}{kr} \approx \frac{(t - r/c)}{r/c} \approx \frac{t}{r/c} - 1 \end{cases}$$
(25)

so that, in the low-frequency limit at a fixed time, (24) approaches the result of Eq. (6) of Section 3-1-1:

$$\lim_{\omega \to 0} \sin^2 \theta \left(\frac{ct}{r}\right) = \text{const}$$
 (26)

Note that the field lines near the dipole are those of a static dipole field, as drawn in Figure 3-2. In the far field limit

$$\lim_{k_{T}\gg 1}\sin^{2}\theta\cos\left(\omega t-k_{T}\right)=\mathrm{const}$$
(27)

the field lines repeat with period $\lambda = 2\pi/k$.

9-2-5 Radiation Resistance

Using the electric and magnetic fields of Section 9-2-3, the time-average power density is

$$\langle \boldsymbol{S} \rangle = \frac{1}{2} \operatorname{Re} \left(\hat{\mathbf{E}} \times \hat{\mathbf{H}}^{*} \right)$$

$$= \operatorname{Re} \left\{ \frac{|\hat{I} dl|^{2} \eta k^{4}}{2(4\pi)^{2}} \left[-\mathbf{i}_{\theta} \sin 2\theta \left(-\frac{1}{(jkr)^{3}} + \frac{1}{(jkr)^{5}} \right) \right]$$

$$+ \mathbf{i}_{r} \sin^{2} \theta \left(-\frac{1}{(jkr)^{2}} + \frac{1}{(jkr)^{5}} \right) \right\}$$

$$= \frac{1}{2} |\hat{I} dl|^{2} \left(\frac{k}{4\pi} \right)^{2} \frac{\eta}{r^{2}} \sin^{2} \theta \mathbf{i}_{r}$$

$$= \frac{1}{2} \frac{|\hat{E}_{0}|^{2}}{\eta} \frac{\sin^{2} \theta}{(kr)^{2}} \mathbf{i}_{r} \qquad (28)$$

where \hat{E}_0 is defined in (16).

Only the far fields contributed to the time-average power flow. The near and intermediate fields contributed only imaginary terms in (28) representing reactive power.

The power density varies with the angle θ , being zero along the electric dipole's axis ($\theta = 0, \pi$) and maximum at right angles to it ($\theta = \pi/2$), illustrated by the radiation power pattern in Fig. 9-3. The strength of the power density is proportional to the length of the vector from the origin to the



Figure 9-3 The strength of the electric field and power density due to a z-directed point dipole as a function of angle θ is proportional to the length of the vector from the origin to the radiation pattern.

radiation pattern. These directional properties are useful in beam steering, where the directions of power flow can be controlled.

The total time-average power radiated by the electric dipole is found by integrating the Poynting vector over a spherical surface at any radius r:

$$= \int_{\theta=0}^{\pi} \int_{\phi=0}^{2\pi} r^{2} \sin \theta \, d\theta \, d\phi$$

$$= \frac{1}{2} |\hat{I} \, dl|^{2} \left(\frac{k}{4\pi}\right)^{2} \eta 2\pi \int_{\theta=0}^{\pi} \sin^{3} \theta \, d\theta$$

$$= \frac{|\hat{I} \, dl|^{2}}{16\pi} \eta k^{2} [-\frac{1}{3} \cos \theta (\sin^{2} \theta + 2)] \Big|_{0}^{\pi}$$

$$= \frac{|\hat{I} \, dl|^{2}}{12\pi} \eta k^{2}$$
(29)

As far as the dipole is concerned, this radiated power is lost in the same way as if it were dissipated in a resistance R,

$$< P > = \frac{1}{2} |\hat{I}|^2 R$$
 (30)

where this equivalent resistance is called the radiation resistance:

$$R = \frac{\eta}{6\pi} (k \, dl)^2 = \frac{2\pi\eta}{3} \left(\frac{dl}{\lambda}\right)^2, \qquad k = \frac{2\pi}{\lambda} \tag{31}$$

In free space $\eta_0 = \sqrt{\mu_0/\epsilon_0} \approx 120 \pi$, the radiation resistance is

$$R_0 = 80 \pi^2 \left(\frac{dl}{\lambda}\right)^2$$
 (free space) (32)

These results are only true for point dipoles, where dl is much less than a wavelength $(dl/\lambda \ll 1)$. This verifies the validity of the quasi-static approximation for geometries much smaller than a radiated wavelength, as the radiated power is then negligible.

If the current on a dipole is not constant but rather varies with z over the length, the only term that varies with z for the vector potential in (5) is $\hat{I}(z)$:

$$\hat{A}_{z}(r) = \operatorname{Re}\left[\int_{-dl/2}^{+dl/2} \frac{\mu \hat{I}(z) \ e^{-jkr_{QP}}}{4\pi r_{QP}} dz\right] \approx \operatorname{Re}\left[\frac{\mu \ e^{-jkr_{QP}}}{4\pi r_{QP}} \int_{-dl/2}^{+dl/2} \hat{I}(z) \ dz\right]$$
(33)

where, because the dipole is of infinitesimal length, the distance r_{QP} from any point on the dipole to any field point far from the dipole is essentially r, independent of z. Then, all further results for the electric and magnetic fields are the same as in Section 9-2-3 if we replace the actual dipole length dl by its effective length,

$$dl_{\rm eff} = \frac{1}{\hat{I}_0} \int_{-dl/2}^{+dl/2} \hat{I}(z) \, dz \tag{34}$$

where \hat{I}_0 is the terminal current feeding the center of the dipole.

Generally the current is zero at the open circuited ends, as for the linear distribution shown in Figure 9-4,

$$\hat{I}(z) = \begin{cases} I_0(1 - 2z/dl), & 0 \le z \le dl/2\\ I_0(1 + 2z/dl), & -dl/2 \le z \le 0 \end{cases}$$
(35)

so that the effective length is half the actual length:

$$dl_{\rm eff} = \frac{1}{I_0} \int_{-dl/2}^{+dl/2} \hat{I}(z) \, dz = \frac{dl}{2} \tag{36}$$



Figure 9-4 (a) If a point electric dipole has a nonuniform current distribution, the solutions are of the same form if we replace the actual dipole length dl by an effective length dl_{eff} . (b) For a triangular current distribution the effective length is half the true length.

Because the fields are reduced by half, the radiation resistance is then reduced by $\frac{1}{4}$:

$$R = \frac{2\pi\eta}{3} \left(\frac{dl_{eff}}{\lambda}\right)^2 = 20\pi^2 \sqrt{\frac{\mu_r}{\varepsilon_r}} \left(\frac{dl}{\lambda}\right)^2 \tag{37}$$

In free space the relative permeability μ_r and relative permittivity ε_r are unity.

Note also that with a spatially dependent current distribution, a line charge distribution is found over the whole length of the dipole and not just on the ends:

$$\hat{\lambda} = -\frac{1}{j\omega} \frac{d\hat{I}}{dz}$$
(38)

For the linear current distribution described by (35), we see that:

$$\hat{\lambda} = \pm \frac{2I_0}{j\omega \, dl} \begin{cases} 0 \le z \le dl/2\\ -dl/2 \le z \le 0 \end{cases}$$
(39)

9-2-6 Rayleigh Scattering (or why is the sky blue?)

If a plane wave electric field Re $[E_0 e^{j\omega t}\mathbf{i}_x]$ is incident upon an atom that is much smaller than the wavelength, the induced dipole moment also contributes to the resultant field, as illustrated in Figure 9-5. The scattered power is perpendicular to the induced dipole moment. Using the dipole model developed in Section 3-1-4, where a negative spherical electron cloud of radius R_0 with total charge -Q surrounds a fixed



(b)

Figure 9-5 An incident electric field polarizes dipoles that then re-radiate their energy primarily perpendicular to the polarizing electric field. The time-average scattered power increases with the fourth power of frequency so shorter wavelengths of light are scattered more than longer wavelengths. (a) During the daytime an earth observer sees more of the blue scattered light so the sky looks blue (short wavelengths). (b) Near sunset the light reaching the observer lacks blue so the sky appears reddish (long wavelength).

678

positive point nucleus, Newton's law for the charged cloud with mass m is:

$$\frac{d^2x}{dt^2} + \omega_0^2 x = \operatorname{Re}\left(\frac{QE_0}{m}e^{j\omega t}\right), \qquad \omega_0^2 = \frac{Q^2}{4\pi\varepsilon mR_0^3} \qquad (40)$$

The resulting dipole moment is then

$$\hat{p} = Q\hat{x} = \frac{Q^2 E_0 / m}{\omega_0^2 - \omega^2}$$
(41)

where we neglect damping effects. This dipole then re-radiates with solutions given in Sections 9-2-1-9-2-5 using the dipole moment of (41) $(\hat{I} dl \rightarrow j\omega p)$. The total time-average power radiated is then found from (29) as

$$<\!P\!> = \frac{\omega^4 |\not\!p|^2 \eta}{12 \pi c^2} = \frac{\omega^4 \eta (Q^2 E_0/m)^2}{12 \pi c^2 (\omega_0^2 - \omega^2)^2}$$
(42)

To approximately compute ω_0 , we use the approximate radius of the electron found in Section 3-8-2 by equating the energy stored in Einstein's relativistic formula relating mass to energy:

$$mc^{2} = \frac{3Q^{2}}{20\pi\epsilon R_{0}} \Rightarrow R_{0} = \frac{3Q^{2}}{20\pi\epsilon mc^{2}} \approx 1.69 \times 10^{-15} \,\mathrm{m} \qquad (43)$$

Then from (40)

$$\omega_0 = \frac{\sqrt{5/3} \ 20 \,\pi\varepsilon \,mc^3}{3 Q^2} \approx 2.3 \times 10^{23} \,\text{radian/sec}$$
(44)

is much greater than light frequencies ($\omega \approx 10^{15}$) so that (42) becomes approximately

$$\lim_{\omega_0 \gg \omega} <\! P \! \approx \! \frac{\eta}{12\pi} \left(\frac{Q^2 E_0 \omega^2}{m c \omega_0^2} \right)^2 \tag{45}$$

0

0

This result was originally derived by Rayleigh to explain the blueness of the sky. Since the scattered power is proportional to ω^4 , shorter wavelength light dominates. However, near sunset the light is scattered parallel to the earth rather than towards it. The blue light received by an observer at the earth is diminished so that the longer wavelengths dominate and the sky appears reddish.

9-2-7 Radiation from a Point Magnetic Dipole

A closed sinusoidally varying current loop of very small size flowing in the z = 0 plane also generates radiating waves. Because the loop is closed, the current has no divergence so that there is no charge and the scalar potential is zero. The vector potential phasor amplitude is then

$$\hat{\mathbf{A}}(r) = \int \frac{\mu \hat{\mathbf{I}} e^{-jkr_{QP}}}{4\pi r_{QP}} dl$$
(46)

We assume the dipole to be much smaller than a wavelength, $k(r_{QP}-r) \ll 1$, so that the exponential factor in (46) can be linearized to

$$\lim_{k(r_{QP}-r)\ll 1} e^{-jkr_{QP}} = e^{-jkr} e^{-jk(r_{QP}-r)} \approx e^{-jkr} [1-jk(r_{QP}-r)]$$
(47)

Then (46) reduces to

$$\hat{\mathbf{A}}(r) = \int \frac{\mu \hat{\mathbf{I}}}{4\pi} e^{-jkr} \left(\frac{1+jkr}{r_{QP}} - jk\right) dl$$
$$= e^{-jkr} \int \frac{\mu \hat{\mathbf{I}}}{4\pi} \left(\frac{1+jkr}{r_{QP}} - jk\right) dl$$
$$= \frac{\mu}{4\pi} e^{-jkr} \left((1+jkr) \int \frac{\hat{\mathbf{I}}}{r_{QP}} - jk \int \hat{\mathbf{I}} dl\right)$$
(48)

where all terms that depend on r can be taken outside the integrals because r is independent of dl. The second integral is zero because the vector current has constant magnitude and flows in a closed loop so that its average direction integrated over the loop is zero. This is most easily seen with a rectangular loop where opposite sides of the loop contribute equal magnitude but opposite signs to the integral, which thus sums to zero. If the loop is circular with radius a,

$$\hat{I} dl = \hat{I} \mathbf{i}_{\phi} a \, d\phi \Rightarrow \int_{0}^{2\pi} \mathbf{i}_{\phi} \, d\phi = \int_{0}^{2\pi} (-\sin \phi \mathbf{i}_{x} + \cos \phi \mathbf{i}_{y}) \, d\phi = 0$$
(49)

the integral is again zero as the average value of the unit vector \mathbf{i}_{ϕ} around the loop is zero.

The remaining integral is the same as for quasi-statics except that it is multiplied by the factor $(1+jkr) e^{-jkr}$. Using the results of Section 5-5-1, the quasi-static vector potential is also multiplied by this quantity:

$$\hat{\mathbf{A}} = \frac{\mu \hat{m}}{4\pi r^2} \sin \theta (1 + jkr) \, e^{-jkr} \mathbf{i}_{\phi}, \qquad \hat{m} = \hat{I} \, dS \qquad (50)$$

The electric and magnetic fields are then

$$\hat{\mathbf{H}} = \frac{1}{\mu} \nabla \times \hat{\mathbf{A}} = -\frac{\hat{m}}{4\pi} jk^3 e^{-jkr} \Big\{ \mathbf{i}_r \Big[2\cos\theta \Big(\frac{1}{(jkr)^2} + \frac{1}{(jkr)^3} \Big) \Big] \\ + \mathbf{i}_{\theta} \Big[\sin\theta \Big(\frac{1}{jkr} + \frac{1}{(jkr)^2} + \frac{1}{(jkr)^3} \Big) \Big] \Big\}$$
(51)
$$\hat{\mathbf{E}} = \frac{1}{j\omega\varepsilon} \nabla \times \hat{\mathbf{H}} = \frac{\hat{m}jk^3}{4\pi} \eta e^{-jkr} \sin\theta \Big(\frac{1}{(jkr)} + \frac{1}{(jkr)^2} \Big) \mathbf{i}_{\phi}$$

The magnetic dipole field solutions are the dual to those of the electric dipole where the electric and magnetic fields reverse roles if we replace the electric dipole moment with the magnetic dipole moment:

$$\frac{\mathbf{p}}{\varepsilon} = \frac{q \, \mathbf{dl}}{\varepsilon} = \frac{\mathbf{I} \, dl}{j\omega\varepsilon} \to \mathbf{m}$$
(52)

9-3 POINT DIPOLE ARRAYS

The power density for a point electric dipole varies with the broad angular distribution $\sin^2 \theta$. Often it is desired that the power pattern be highly directive with certain angles carrying most of the power with negligible power density at other angles. It is also necessary that the directions for maximum power flow be controllable with no mechanical motion of the antenna. These requirements can be met by using more dipoles in a periodic array.

9-3-1 A Simple Two Element Array

To illustrate the basic principles of antenna arrays we consider the two element electric dipole array shown in Figure 9-6. We assume each element carries uniform currents \hat{I}_1 and \hat{I}_2 and has lengths dl_1 and dl_2 , respectively. The elements are a distance 2a apart. The fields at any point P are given by the superposition of fields due to each dipole alone. Since we are only interested in the far field radiation pattern where $\theta_1 \approx \theta_2 \approx \theta$, we use the solutions of Eq. (16) in Section 9-2-3 to write:

$$\hat{E}_{\theta} = \eta \hat{H}_{\phi} = \frac{\hat{E}_1 \sin \theta \, e^{-jkr_1}}{jkr_1} + \frac{\hat{E}_2 \sin \theta \, e^{-jkr_2}}{jkr_2} \tag{1}$$

where

$$\hat{E}_1 = -\frac{\hat{I}_1 \, dl_1 \, k^2}{4 \, \pi} \, \eta, \qquad \hat{E}_2 = -\frac{\hat{I}_2 \, dl_2 \, k^2 \, \eta}{4 \, \pi}$$



Figure 9-6 The field at any point P due to two-point dipoles is just the sum of the fields due to each dipole alone taking into account the difference in distances to each dipole.

Remember, we can superpose the fields but we cannot superpose the power flows.

From the law of cosines the distances r_1 and r_2 are related as

$$r_{2} = [r^{2} + a^{2} - 2ar\cos(\pi - \xi)]^{1/2} = [r^{2} + a^{2} + 2ar\cos\xi]^{1/2}$$

$$r_{1} = [r^{2} + a^{2} - 2ar\cos\xi]^{1/2}$$
(2)

where ξ is the angle between the unit radial vector **i**, and the x axis:

$$\cos \xi = \mathbf{i}_r \cdot \mathbf{i}_s = \sin \theta \cos \phi$$

Since we are interested in the far field pattern, we linearize (2) to

$$\lim_{r \gg a} \begin{cases} r_2 \approx r \left[1 + \frac{1}{2} \left(\frac{a^2}{r^2} + \frac{2a}{r} \sin \theta \cos \phi \right) \right] \approx r + a \sin \theta \cos \phi \\ r_1 \approx r \left[1 + \frac{1}{2} \left(\frac{a^2}{r^2} - \frac{2a}{r} \sin \theta \cos \phi \right) \right] \approx r - a \sin \theta \cos \phi \end{cases}$$
(3)

In this far field limit, the correction terms have little effect in the denominators of (1) but can have significant effect in the exponential phase factors if a is comparable to a wavelength so that ka is near or greater than unity. In this spirit we include the first-order correction terms of (3) in the phase factors of (1), but not anywhere else, so that (1) is rewritten as

$$\hat{E}_{\theta} = \eta \hat{H}_{\phi}$$

$$= \underbrace{\frac{jk\eta}{4\pi r} \sin \theta \, e^{-jkr}}_{\text{element factor}} \underbrace{(\hat{I}_1 \, dl_1 \, e^{jka \sin \theta \cos \phi} + \hat{I}_2 \, dl_2 \, e^{-jka \sin \theta \cos \phi})}_{\text{array factor}} \quad (4)$$

The first factor is called the element factor because it is the radiation field per unit current element $(\hat{I} dl)$ due to a single dipole at the origin. The second factor is called the array factor because it only depends on the geometry and excitations (magnitude and phase) of each dipole element in the array.

To examine (4) in greater detail, we assume the two dipoles are identical in length and that the currents have the same magnitude but can differ in phase χ :

$$dl_1 = dl_2 \equiv dl$$

$$\hat{I}_1 = \hat{I}, \qquad \hat{I}_2 = \hat{I} e^{ix} \Rightarrow \hat{E}_1 = \hat{E}_0, \qquad \hat{E}_2 = \hat{E}_0 e^{ix}$$
(5)

so that (4) can be written as

$$\hat{E}_{\theta} = \eta \hat{H}_{\phi} = \frac{2\hat{E}_{0}^{*}}{jkr} e^{-jkr} \sin \theta \, e^{j\chi/2} \cos \left(ka \sin \theta \cos \phi - \frac{\chi}{2}\right) \tag{6}$$

Now the far fields also depend on ϕ . In particular, we focus attention on the $\theta = \pi/2$ plane. Then the power flow,

$$\lim_{\theta = \pi/2} \langle S_r \rangle = \frac{1}{2\eta} |\hat{E}_{\theta}|^2 = \frac{2|\hat{E}_0|^2}{\eta (kr)^2} \cos^2\left(ka \cos \phi - \frac{\chi}{2}\right)$$
(7)

depends strongly on the dipole spacing 2a and current phase difference χ .

(a) Broadside Array

Consider the case where the currents are in phase $(\chi = 0)$ but the dipole spacing is a half wavelength $(2a = \lambda/2)$. Then, as illustrated by the radiation pattern in Figure 9-7*a*, the field strengths cancel along the *x* axis while they add along the *y* axis. This is because along the *y* axis $r_1 = r_2$, so the fields due to each dipole add, while along the *x* axis the distances differ by a half wavelength so that the dipole fields cancel. Wherever the array factor phase ($ka \cos \phi - \chi/2$) is an integer multiple of π , the power density is maximum, while wherever it is an odd integer multiple of $\pi/2$, the power density is zero. Because this radiation pattern is maximum in the direction perpendicular to the array, it is called a broadside pattern.



Figure 9-7 The power radiation pattern due to two-point dipoles depends strongly on the dipole spacing and current phases. With a half wavelength dipole spacing $(2a = \lambda/2)$, the radiation pattern is drawn for various values of current phase difference in the $\theta = \pi/2$ plane. The broadside array in (a) with the currents in phase ($\chi = 0$) has the power lobe in the direction perpendicular to the array while the end-fire array in (e) has out-of-phase currents ($\chi = \pi$) with the power lobe in the direction along the array.

(b) End-fire Array

If, however, for the same half wavelength spacing the currents are out of phase ($\chi = \pi$), the fields add along the x axis but cancel along the y axis. Here, even though the path lengths along the y axis are the same for each dipole, because the currents are out of phase the fields cancel. Along the x axis the extra π phase because of the half wavelength path difference is just canceled by the current phase difference of π so that the fields due to each dipole add. The radiation pattern is called end-fire because the power is maximum in the direction along the array, as shown in Figure 9-7*e*.

(c) Arbitrary Current Phase

For arbitrary current phase angles and dipole spacings, a great variety of radiation patterns can be obtained, as illustrated by the sequences in Figures 9-7 and 9-8. More power lobes appear as the dipole spacing is increased.

9-3-2 An N Dipole Array

If we have (2N+1) equally spaced dipoles, as shown in Figure 9-9, the *n*th dipole's distance to the far field point is approximately,

$$\lim_{r \gg |n_{\alpha}|} r_{n} \approx r - na \sin \theta \cos \phi \tag{8}$$

so that the array factor of (4) generalizes to

$$AF = \sum_{-N}^{+N} \hat{I}_n \, dI_n \, e^{jkna\sin\theta\cos\phi} \tag{9}$$

where for symmetry we assume that there are as many dipoles to the left (negative n) as to the right (positive n) of the z axis, including one at the origin (n = 0). In the event that a dipole is not present at a given location, we simply let its current be zero. The array factor can be varied by changing the current magnitude or phase in the dipoles. For simplicity here, we assume that all dipoles have the same length dl, the same current magnitude I_0 , and differ in phase from its neighbors by a constant angle χ_0 so that

$$\hat{I}_n = I_0 e^{-jn\chi_0}, \qquad -N \le n \le N \tag{10}$$

and (9) becomes

$$AF = I_0 dl \sum_{-N}^{+N} e^{jn(ka\sin\theta\cos\phi - \chi_0)}$$
(11)





Figure 9-8 With a full wavelength dipole spacing $(2a = \lambda)$ there are four main power lobes.

Defining the parameter

$$\boldsymbol{\beta} = e^{j(ka\sin\theta\cos\phi - \chi_0)} \tag{12}$$

the geometric series in (11) can be written as

$$S = \sum_{-N}^{+N} \beta^{n} = \beta^{-N} + \beta^{-N+1} + \dots + \beta^{-2} + \beta^{-1} + 1 + \beta + \beta^{2} + \dots + \beta^{N-1} + \beta^{N}$$
(13)

If we multiply this series by β and subtract from (13), we have

$$S(1-\beta) = \beta^{-N} - \beta^{N+1} \tag{14}$$

which allows us to write the series sum in closed form as

$$S = \frac{\beta^{-N} - \beta^{N+1}}{1 - \beta} = \frac{\beta^{-(N+1/2)} - \beta^{(N+1/2)}}{\beta^{-1/2} - \beta^{1/2}}$$
$$= \frac{\sin\left[(N + \frac{1}{2})(ka\sin\theta\cos\phi - \chi_0)\right]}{\sin\left[\frac{1}{2}(ka\sin\theta\cos\phi - \chi_0)\right]} \quad (15)$$

In particular, we again focus on the solution in the $\theta = \pi/2$ plane so that the array factor is

$$AF = I_0 dl \frac{\sin \left[(N + \frac{1}{2}) (ka \cos \phi - \chi_0) \right]}{\sin \left[\frac{1}{2} (ka \cos \phi - \chi_0) \right]}$$
(16)

The radiation pattern is proportional to the square of the array factor. Maxima occur where

$$ka \cos \phi - \chi_0 = 2n\pi$$
 $n = 0, 1, 2, ...$ (17)

The principal maximum is for n = 0 as illustrated in Figure 9-10 for various values of ka and χ_0 . The larger the number of dipoles N, the narrower the principal maximum with smaller amplitude side lobes. This allows for a highly directive beam at angle ϕ controlled by the incremental current phase angle χ_0 , so that $\cos \phi = \chi_0/ka$, which allows for electronic beam steering by simply changing χ_0 .

9-4 LONG DIPOLE ANTENNAS

The radiated power, proportional to $(dl/\lambda)^2$, is small for point dipole antennas where the dipole's length dl is much less than the wavelength λ . More power can be radiated if the length of the antenna is increased. Then however, the fields due to each section of the antenna may not add constructively.



Figure 9-9 A linear point dipole array with 2N+1 equally spaced dipoles.

9-4-1 Far Field Solution

Consider the long dipole antenna in Figure 9-11 carrying a current $\hat{I}(z)$. For simplicity we restrict ourselves to the far field pattern where $r \gg L$. Then, as we found for dipole arrays, the differences in radial distance for each incremental current element of length dz are only important in the exponential phase factors and not in the 1/r dependences.

From Section 9-2-3, the incremental current element at position z generates a far electric field:

$$d\hat{E}_{\theta} = \eta \, d\hat{H}_{\phi} = \frac{jk\eta}{4\pi} \frac{\hat{I}(z) \, dz}{r} \sin \theta \, e^{-jk(r-z \cos \theta)} \tag{1}$$

where we again assume that in the far field the angle θ is the same for all incremental current elements.

The total far electric field due to the entire current distribution is obtained by integration over all current elements:

$$\hat{E}_{\theta} = \eta \hat{H}_{\phi} = \frac{jk\eta}{4\pi r} \sin \theta \, e^{-jkr} \int_{-L/2}^{+L/2} \hat{I}(z) \, e^{jkz \cos \theta} \, dz \qquad (2)$$

If the current distribution is known, the integral in (2) can be directly evaluated. The practical problem is difficult because the current distribution along the antenna is determined by the near fields through the boundary conditions.



Figure 9-10 The radiation pattern for an N dipole linear array for various values of N, dipole spacing 2a, and relative current phase χ_0 in the $\theta = \pi/2$ plane.

Since the fields and currents are coupled, an exact solution is impossible no matter how simple the antenna geometry. In practice, one guesses a current distribution and calculates the resultant (near and far) fields. If all boundary conditions along the antenna are satisfied, then the solution has been found. Unfortunately, this never happens with the first guess. Thus based on the field solution obtained from the originally guessed current, a corrected current distribution is used and

689



Figure 9-10

the resulting fields are again calculated. This procedure is numerically iterated until convergence is obtained with selfconsistent fields and currents.

9-4-2 Uniform Current

A particularly simple case is when $\hat{I}(z) = \hat{I}_0$ is a constant. Then (2) becomes:

$$\hat{E}_{\theta} = \eta \hat{H}_{\phi} = \frac{jk\eta}{4\pi r} \sin \theta \, e^{-jkr} \hat{I}_0 \int_{-L/2}^{+L/2} e^{jkz\cos\theta} dz$$
$$= \frac{jk\eta}{4\pi r} \sin \theta \, e^{-jkr} \hat{I}_0 \frac{e^{jkz\cos\theta}}{jk\cos\theta} \Big|_{-L/2}^{+L/2}$$
$$= \frac{\hat{I}_0 \eta}{4\pi r} \tan \theta \, e^{-jkr} \Big[2j\sin\left(\frac{kL}{2}\cos\theta\right) \Big] \qquad (3)$$

The time-average power density is then

$$< S_r > = \frac{1}{2\eta} |\hat{E}_{\theta}|^2 = \frac{|\hat{E}_0|^2 \tan^2 \theta \sin^2 [(kL/2) \cos \theta]}{2\eta (kr)^2 (kL/2)^2}$$
(4)

where

$$\hat{E}_0 = \frac{\hat{I}_0 L \eta k^2}{4\pi} \tag{5}$$

This power density is plotted versus angle θ in Figure 9-12 for various lengths *L*. The principal maximum always appears at $\theta = \pi/2$, becoming sharper as *L* increases. For $L > \lambda$, zero power density occurs at angles

$$\cos\theta = \frac{2n\pi}{kL} = \frac{n\lambda}{L}, \qquad n = 1, 2, \dots$$
(6)

Secondary maxima then occur at nearby angles but at much smaller amplitudes compared to the main lobe at $\theta = \pi/2$.

9-4-3 Radiation Resistance

The total time-average radiated power is obtained by integrating (4) over all angles:

$$= \int_{\phi=0}^{2\pi} \int_{\theta=0}^{\pi} r^2 \sin \theta \, d\theta \, d\phi$$
$$= \frac{|\hat{E}_0|^2 \pi}{k^2 \eta (kL/2)^2} \int_{\theta=0}^{\pi} \frac{\sin^3 \theta}{\cos^2 \theta} \sin^2 \left(\frac{kL}{2} \cos \theta\right) d\theta \qquad (7)$$

If we introduce the change of variable,

$$v = \frac{kL}{2}\cos\theta, \qquad dv = -\frac{kL}{2}\sin\theta\,d\theta$$
 (8)

the integral of (7) becomes

$$=\frac{|\hat{E}_{0}|^{2}\pi}{k^{2}\eta(kL/2)^{2}}\int_{+kL/2}^{-kL/2}\left(\frac{2}{kL}\sin^{2}v\,dv-\frac{kL}{2}\frac{\sin^{2}v}{v^{2}}\right)dv$$
(9)

The first term is easily integrable as

$$\int \sin^2 v \, dv = \frac{1}{2}v - \frac{1}{4}\sin 2v \tag{10}$$

The second integral results in a new tabulated function Si(x) called the sine integral, defined as:

$$Si(\mathbf{x}) = \int_0^x \frac{\sin t}{t} dt \tag{11}$$



Figure 9-11 (a) For a long dipole antenna, each incremental current element at coordinate z is at a slightly different distance to any field point P. (b) The simplest case study has the current uniformly distributed over the length of the dipole.

which is plotted in Figure 9-13. Then the second integral in (9) can be expanded and integrated by parts:

$$\int \frac{\sin^2 v}{v^2} dv = \int \frac{(1 - \cos 2v)}{2v^2} dv$$
$$= -\frac{1}{2v} - \int \cos 2v \frac{dv}{2v^2}$$
$$= -\frac{1}{2v} + \frac{\cos 2v}{2v} + \int \frac{\sin 2v d(2v)}{2v}$$
$$= -\frac{1}{2v} + \frac{\cos 2v}{2v} + Si(2v)$$
(12)

Then evaluating the integrals of (10) and (12) in (9) at the upper and lower limits yields the time-average power as:

$$=\frac{|\hat{E}_{0}|^{2}\pi}{k^{2}\eta(kL/2)^{2}}\left(\frac{\sin kL}{kL}+\cos kL-2+kLSi(kL)\right) \quad (13)$$

where we used the fact that the sine integral is an odd function Si(x) = -Si(x).

Using (5), the radiation resistance is then

$$R = \frac{2 < P >}{|\hat{I}_0|^2} = \frac{\eta}{2\pi} \left(\frac{\sin kL}{kL} + \cos kL - 2 + kLSi(kL) \right)$$
(14)



Figure 9-12 The radiation pattern for a long dipole for various values of its length.



Figure 9-13 The sine integral Si(x) increases linearly for small arguments and approaches $\pi/2$ for large arguments oscillating about this value for intermediate arguments.



Figure 9-14 The radiation resistance for a dipole antenna carrying a uniformly distributed current increases with the square of its length when it is short $(L/\lambda \ll 1)$ and only linearly with its length when it is long $(L/\lambda \gg 1)$. For short lengths, the radiation resistance approximates that of a point dipole.

694

which is plotted versus kL in Fig. 9-14. This result can be checked in the limit as L becomes very small ($kL \ll 1$) since the radiation resistance should approach that of a point dipole given in Section 9-2-5. In this short dipole limit the bracketed terms in (14) are

$$\lim_{kL\ll 1} \begin{cases} \frac{\sin kL}{kL} \approx 1 - \frac{(kL)^2}{6} \\ \cos kL \approx 1 - \frac{(kL)^2}{2} \\ kLSi(kL) \approx (kL)^2 \end{cases}$$
(15)

so that (14) reduces to

$$\lim_{kL\ll 1} R \approx \frac{\eta}{2\pi} \frac{(kL)^2}{3} = \frac{2\pi\eta}{3} \left(\frac{L}{\lambda}\right)^2 = 80\pi^2 \left(\frac{L}{\lambda}\right)^2 \sqrt{\frac{\mu_r}{\varepsilon_r}} \qquad (16)$$

which agrees with the results in Section 9-2-5. Note that for large dipoles $(kL \gg 1)$, the sine integral term dominates with Si(kL) approaching a constant value of $\pi/2$ so that

$$\lim_{kL \to 1} R \approx \frac{\eta kL}{4} = 60 \sqrt{\frac{\mu_r}{\varepsilon_r}} \pi^2 \frac{L}{\lambda}$$
(17)

PROBLEMS

Section 9-1

1. We wish to find the properties of waves propagating within a linear dielectric medium that also has an Ohmic conductivity σ .

(a) What are Maxwell's equations in this medium?

(b) Defining vector and scalar potentials, what gauge condition decouples these potentials?

(c) A point charge at r = 0 varies sinusoidally with time as $Q(t) = \text{Re}(\hat{Q}e^{j\omega t})$. What is the scalar potential?

(d) Repeat (a)-(c) for waves in a plasma medium with constitutive law

$$\frac{\partial \mathbf{J}_f}{\partial \iota} = \boldsymbol{\omega}_p^2 \boldsymbol{\varepsilon} \mathbf{E}$$

2. An infinite current sheet at z = 0 varies as Re $[K_0 e^{j(\omega t - k_x x)} i_x]$.

(a) Find the vector and scalar potentials.

(b) What are the electric and magnetic fields?

(c) Repeat (a) and (b) if the current is uniformly distributed over a planar slab of thickness 2a:

$$\mathbf{J}_{f} = \begin{cases} J_{0} e^{j(\omega t - k_{x}z)} \mathbf{i}_{x}, & -a < z < a \\ 0, & |z| > a \end{cases}$$

3. A sphere of radius R has a uniform surface charge distribution $\sigma_f = \operatorname{Re}(\hat{\sigma}_0 e^{j\omega t})$ where the time varying surface charge is due to a purely radial conduction current.

(a) Find the scalar and vector potentials, inside and outside the sphere. (Hint: $r_{QP}^2 = r^2 + R^2 - 2rR \cos \theta$; $r_{QP} dr_{QP} = rR \sin \theta d\theta$.)

(b) What are the electric and magnetic fields everywhere?

Section 9.2

4. Find the effective lengths, radiation resistances and line charge distributions for each of the following current distributions valid for |z| < dl/2 on a point electric dipole with short length dl:

- (a) $\hat{I}(z) = I_0 \cos \alpha z$
- (b) $\hat{I}(z) = I_0 e^{-\alpha |z|}$
- (c) $\hat{I}(z) = I_0 \cosh \alpha z$

5. What is the time-average power density, total time-average power, and radiation resistance of a point magnetic dipole?

6. A plane wave electric field Re $(\mathbf{E}_0 e^{j\omega t})$ is incident upon a perfectly conducting spherical particle of radius R that is much smaller than the wavelength.

(a) What is the induced dipole moment? (Hint: See Section 4-4-3.)

(b) If the small particle is, instead, a pure lossless dielectric with permittivity ε , what is the induced dipole moment?

(c) For both of these cases, what is the time-average scattered power?

7. A plane wave magnetic field Re $(\mathbf{H}_0 e^{j\omega t})$ is incident upon a perfectly conducting particle that is much smaller than the wavelength.

(a) What is the induced magnetic dipole moment? (Hint: See Section 5-7-2*ii* and 5-5-1.)

(b) What are the re-radiated electric and magnetic fields?

(c) What is the time-average scattered power? How does it vary with frequency?

8. (a) For the magnetic dipole, how are the magnetic field lines related to the vector potential **A**?

(b) What is the equation of these field lines?

Section 9.3

9. Two aligned dipoles $\hat{I}_1 dl$ and $\hat{I}_2 dl$ are placed along the z axis a distance 2a apart. The dipoles have the same length

697 Problems



while the currents have equal magnitudes but phase difference χ .

(a) What are the far electric and magnetic fields?

(b) What is the time-average power density?

(c) At what angles is the power density zero or maximum?

(d) For $2a = \lambda/2$, what values of χ give a broadside or end-fire array?

(e) Repeat (a)-(c) for 2N+1 equally spaced aligned dipoles along the z axis with incremental phase difference χ_0 .

10. Three dipoles of equal length dl are placed along the z axis.



(a) Find the far electric and magnetic fields.

(b) What is the time average power density?

(c) For each of the following cases find the angles where the power density is zero or maximum.

- (i) $\hat{I}_1 = \hat{I}_3 = I_0, \ \hat{I}_2 = 2I_0$ (ii) $\hat{I}_1 = \hat{I}_3 = I_0, \ \hat{I}_2 = -2I_0$ (iii) $\hat{I}_1 = -\hat{I}_3 = I_0, \ \hat{I}_2 = 2jI_0$

11. Many closely spaced point dipoles of length dl placed along the x axis driven in phase approximate a z-directed current sheet Re $(K_0 e^{j\omega t} \mathbf{i}_z)$ of length L.



(a) Find the far fields from this current sheet.

(b) At what angles is the power density minimum or maximum?

Section 9.4

12. Find the far fields and time-average power density for each of the following current distributions on a long dipole:

(a)
$$\hat{I}(z) = \begin{cases} I_0(1-2z/L), & 0 < z < L/2 \\ I_0(1+2z/L), & -L/2 < z < 0 \end{cases}$$

Hint:

$$\int z e^{az} dz = \frac{e^{az}}{a^2} (az - 1)$$
(b) $\hat{I}(z) = I_0 \cos \pi z/L$, $-L/2 < z < L/2$

Hint:

$$\int e^{az} \cos pz \, dz = e^{az} \frac{(a \cos pz + p \sin pz)}{(a^2 + p^2)}$$

(c) For these cases find the radiation resistance when $kL \ll 1$.

SOLUTIONS TO SELECTED PROBLEMS

Chapter 1

1. Area =
$$\pi a^2$$

3. (a) $\mathbf{A} + \mathbf{B} = 6\mathbf{i}_x - 2\mathbf{i}_y - 6\mathbf{i}_z$
(b) $\mathbf{A} \cdot \mathbf{B} = 6$
(c) $\mathbf{A} \times \mathbf{B} = -14\mathbf{i}_x + 12\mathbf{i}_y - 18\mathbf{i}_z$
5. (b) $\mathbf{B}_{\parallel} = 2(-\mathbf{i}_x + 2\mathbf{i}_y - \mathbf{i}_z), \mathbf{B}_{\perp} = 5\mathbf{i}_x + \mathbf{i}_y - 3\mathbf{i}_z$
7. (a) $\mathbf{A} \cdot \mathbf{B} = -75$
(b) $\mathbf{A} \times \mathbf{B} = -100\mathbf{i}_z$
(c) $\theta = 126.87^\circ$
12. (a) $\nabla f = (az + 3bx^2y)\mathbf{i}_x + bx^3\mathbf{i}_y + ax\mathbf{i}_z$
14. (a) $\nabla \cdot \mathbf{A} = 3$
17. (b) $\Phi = \frac{1}{2}abc$
18. (a) $\nabla \times \mathbf{A} = (x - y^2)\mathbf{i}_x - y\mathbf{i}_y - x^2\mathbf{i}_z$
23. (b) $\nabla f = \frac{1}{h_u}\frac{\partial f}{\partial u}\mathbf{i}_u + \frac{1}{h_v}\frac{\partial f}{\partial v}\mathbf{i}_v + \frac{1}{h_w}\frac{\partial f}{\partial w}\mathbf{i}_w$
(c) $d\mathbf{V} = h_uh_vh_w du dv dw$
(d) $\nabla \cdot \mathbf{A} = \frac{1}{h_uh_vh_w} \left[\frac{\partial}{\partial u}(h_vh_wA_u) + \frac{\partial}{\partial v}(h_uh_wA_v) + \frac{\partial}{\partial w}(h_uh_vA_w)\right]$
 $(\nabla \times \mathbf{A})_u = \frac{1}{h_vh_w} \left[\frac{\partial(h_wA_w)}{\partial v} - \frac{\partial(h_vA_v)}{\partial w}\right]$
25. (a) $r_{QP} = \sqrt{30}$, (b) $\mathbf{i}_{QP} = \frac{\mathbf{r}_{QP}}{r_{QP}} = \frac{\mathbf{i}_x - 5\mathbf{i}_y + 2\mathbf{i}_z}{\sqrt{30}}$,
(c) $\mathbf{n} = \frac{5\mathbf{i}_x + \mathbf{i}_y}{\sqrt{26}}$

Chapter 2

3.
$$E_0 = \frac{4}{3} \frac{\pi R^3 \rho_m g}{q}$$
4.
$$Q_2 = \frac{2\pi \varepsilon_0 d^3 M g}{Q_1 \sqrt{l^2 - \left(\frac{d}{2}\right)^2}}$$
5. (a)
$$\omega = \left[\frac{Q_1 Q_2}{4\pi \varepsilon_0 R^3 m}\right]^{1/2}$$

699

7. (a) $m = \frac{m_1 m_2}{m_1 + m_2}$ (b) $v = \pm \sqrt{\frac{-q_1 q_2}{2 \pi c_1 m} \left(\frac{1}{r_1} - \frac{1}{r_2}\right)},$ (d) $t = \frac{\pi}{2} r_0^{3/2} \left[\frac{2\pi m \varepsilon_0}{-c_0 c_0} \right]^{1/2}$ 8. $h = \frac{qE_0L^2}{2mr^2}$ 10. (b) $q = \frac{6\sqrt{3}}{\pi^{3/2}}Q$ (b) $q = \frac{4}{3}\pi\rho_0 a^3$, (c) $q = 2\sigma_0 ab\pi$ 12. (a) $q = 2\lambda_0 a$, 15. $\theta = \tan^{-1} \left[\frac{Q\sigma_0}{2c_1 M \sigma} \right]$ 16. (a) $E_r = \frac{\lambda L}{2\pi \epsilon_r r \sqrt{L^2 + r^2}},$ (b) $E_x = \frac{\sigma_0}{2\pi\epsilon_0} \left[\sin^{-1} \left(\frac{L^2 - x^2}{L^2 + x^2} \right) + \frac{\pi}{2} \right]; \quad x > 0$ 18. (a) $E_y = \frac{-\lambda_0 a^2}{\pi \epsilon_0 [z^2 + a^2]^{3/2}}$ (b) $E_y = \frac{-\sigma_0}{\pi\epsilon_0} \left\{ \frac{-a}{\sqrt{z^2 + a^2}} + \ln \left| \frac{a + \sqrt{z^2 + a^2}}{|z|} \right| \right\}$ 20. (a) $E_y = -\frac{\lambda_0 a^2}{\pi \epsilon_0 (a^2 + \tau^2)^{3/2}}$ 21. $E_y = \frac{\lambda_0 z^2}{2\pi\epsilon_0 (a^2 + z^2)^{3/2}}$ 22. (a) $Q_T = 4\pi\varepsilon_0 A R^4$ 23. (c) $E_{x} = \begin{cases} \frac{\rho_{0}}{2\varepsilon_{0}d} (x^{2} - d^{2}) & |x| < d \\ 0 & |x| > d \end{cases}$ 25. (c) $E_{r} = \begin{cases} \frac{\rho_{0}r^{2}}{3\varepsilon_{0}a} & r < a \\ \frac{\rho_{0}a^{2}}{3\varepsilon_{0}r} & r > a \end{cases}$ 23. (c) 26. $\mathbf{E} = \frac{\rho_0 d}{2\epsilon_0} \mathbf{i}_x$ 27. $W = -\frac{\lambda \sigma_0 l^2}{4\epsilon_0}$

700

28. (a) $v_0 \ge \sqrt{\frac{qQ}{2\pi\varepsilon_0 Rm}}$, (b) r = 4R29. (a) $\mathbf{E} = -2Ax\mathbf{i}_x, \rho_f = -2A\varepsilon_0$ 31. (a) $\Delta v = \frac{\sigma_0 a}{\varepsilon_0}$ 32. (a) $dq = -\frac{Q}{R}dz'$ 33. (c) $V \approx \frac{q_0 a}{4\pi\varepsilon_0 r^2}\cos\theta$, (d) $r = r_0\sin^2\theta$ 34. (d) $q_c = -\frac{qV_b}{V_c}$ 36. (a) $E_y = -\frac{\sigma_0}{2\pi\varepsilon_0}\ln\left(1-\frac{d}{y}\right)$ 38. (a) $x_0 = \sqrt{\frac{q}{16\pi\varepsilon_0 E_0}}$, (b) $v_0 > \frac{1}{2}\sqrt{\frac{q}{m}}\left[\frac{qE_0}{\pi\varepsilon_0}\right]^{1/4}$, (c) $W = \frac{q^2}{16\pi\varepsilon_0 d}$ 43. (e) $\lambda = \pm \sqrt{\frac{R_1}{R_2}}, \alpha = \pm \frac{R_1}{R_2}$ 44. (g) $q_T = -4\pi\varepsilon_0 R^2 \frac{\pi^2}{6}$

Chapter 3

2. (a) $p_{z} = \lambda_{0}L^{2}$, (e) $p_{z} = QR$ 4. (a) $\rho_{0} = \frac{3Q}{\pi R_{0}^{3}}$ 7. (a) $\mathbf{d} = \frac{4\pi\varepsilon_{0}R_{0}^{3}\mathbf{E}_{0}}{Q}$ 8. (b) $\frac{Q}{L^{2}} = 2\pi\varepsilon_{0}E_{0}$ 10. (a) $\mathbf{p}_{ind} = \mathbf{p}\frac{R^{3}}{D^{3}}$ 12. (a) $V(\mathbf{x}) = \frac{V_{0}}{2} \frac{\sinh x/l_{d}}{\sinh l/l_{d}}$ 15. (b) $Q = \frac{m\omega RA\sigma}{q}$

17. (a)
$$D_r = \frac{\lambda}{2\pi r}$$

19. (a) $\lambda' = -\lambda'' = \frac{\lambda(\varepsilon_2 - \varepsilon_1)}{\varepsilon_1 + \varepsilon_2}, \lambda''' = \frac{2\varepsilon_2 \lambda}{\varepsilon_1 + \varepsilon_2}$
23. (a) $E_r = \begin{cases} -\frac{P_0 r}{\varepsilon_0 R} & r < R \\ 0 & r > R \end{cases}$
26. (a) $R = \frac{s \ln \frac{\sigma_2}{\sigma_1}}{lD(\sigma_2 - \sigma_1)}$
31. $C = \frac{2\pi l(\varepsilon_2 a - \varepsilon_1 b)}{(b - a) \ln \frac{\varepsilon_2 a}{\varepsilon_1 b}}$
33. $\sigma_f(r = a_1) = \frac{\rho_0 a_0^2}{3a_1} (1 - e^{-l/r}); \tau = \varepsilon/\sigma$
35. $\rho_f = \rho_0 e^{-\sigma r^{3/(3\varepsilon A)}}$
38. (a) $v(z) = -\frac{V_0 \sinh \sqrt{2RG}(z - l)}{\sinh \sqrt{2RG}l}$
41. (b) $\frac{\varepsilon\mu}{2} [E^2(l) - E^2(0)] + \varepsilon \frac{dv}{dt} = J(t)l$
(c) $E(l) = \frac{V_0/l}{1 - \frac{\mu t V_0}{2l^2}},$ (f) $\tau = \frac{2l^2}{\mu V_0} (1 - e^{-1/2})$
42. (c) $E_i^2 = \left(\frac{V_0}{R_0 - R_i}\right)^2 = \frac{I}{2\pi \varepsilon \mu l}$
43. (a) $W = -\frac{1}{2\mathbf{p}} \cdot \mathbf{E}$
44. $W = \frac{p^2}{12\pi\varepsilon_0 R^3}$
47. (a) $W = \frac{-Q^2}{8\pi\varepsilon_0 R}$
48. (a) $W_{init} = \frac{1}{2}CV_0^2,$ (b) $W_{final} = \frac{1}{4}CV_0^2$
49. (b) $W = -pE(\cos \theta - 1)$
50. $h = \frac{1}{2}(\varepsilon - \varepsilon_0)\frac{V_0^2}{\rho_m g^2}$

702
52. (b)
$$f_{y} = \frac{1}{2} \frac{\varepsilon_{0}A}{(s+d)^{2}} \left[V_{0} + \frac{P_{0}d}{\varepsilon_{0}} \right]^{2}$$

54. (b) $f_{z} = \frac{\pi V_{0}^{2}}{\ln \frac{b}{a}} (\varepsilon - \varepsilon_{0})$
55. $f_{x} = -\frac{1}{2} \frac{\varepsilon_{0}d}{s} V_{0}^{2}$
56. (c) $T = \frac{1}{2} v^{2} \frac{dC}{d\theta} = \frac{-NV_{0}^{2}R^{2}\varepsilon_{0}}{s}$
57. (a) $v(t) = \frac{\sigma_{f}Uwt}{4\pi\varepsilon_{0}R}$
58. (a) $\rho_{f} = \rho_{0} e^{-\sigma_{z}/\varepsilon U}$
59. (a) $nC_{i} > \frac{1}{R} + \frac{2}{R_{L}}$, (c) $\frac{nC_{i}}{2} > \frac{1}{R}, \omega_{0} = \frac{\sqrt{3}}{2} \frac{nC_{i}}{C}$

Chapter 4

2. (a)

$$V = \begin{cases} \frac{\sigma_0}{2\varepsilon a} \cos ay e^{-ax} & x > 0 \\ \frac{\sigma_0}{2\varepsilon a} \cos ay e^{ax} & x < 0 \end{cases}$$

4. (a)
$$V = \frac{4V_1}{\pi} \sum_{\substack{n=1\\n \text{ odd}}}^{\infty} \frac{\sin \frac{n\pi y}{d} \sinh \frac{n\pi (l-x)}{d}}{n \sinh \frac{n\pi l}{d}}$$

7. (a)
$$V_p = \frac{\rho_0}{\varepsilon_0 a^2} \sin ax$$

12.

$$V(\mathbf{r}, \phi) = \begin{cases} \left[\frac{P_2 - P_1}{2\varepsilon_0} - E_0\right] \mathbf{r} \cos \phi & 0 \le \mathbf{r} \le a \\ \left[-E_0 \mathbf{r} + \frac{(P_2 - P_1)a^2}{2\varepsilon_0 \mathbf{r}}\right] \cos \phi & \mathbf{r} > a \end{cases}$$

13. (a)
$$\mathbf{E} = \left[E_0 \left(1 + \frac{a^2}{r^2} \right) \cos \phi + \frac{\lambda(t)}{2\pi\varepsilon r} \right] \mathbf{i}_r - E_0 \left(1 - \frac{a^2}{r^2} \right) \sin \phi \mathbf{i}_{\phi}$$

(b) $\cos \phi < -\frac{\lambda(t)}{4\pi\varepsilon a E_0}$, (c) $\lambda_{\max} = 4\pi\varepsilon a E_0$

703

15. (a)
$$V(\mathbf{r}, z) = \begin{cases} \frac{V_0 z}{l \ln \frac{b}{a}} \ln \frac{\mathbf{r}}{a} & a \le r \le b \\ \frac{V_0 z}{l} & b \le r \le c \end{cases}$$

17. (b) $E_0 \ge \sqrt{\frac{8\rho_m g R}{27\epsilon}}$
22. $V(2, 2) = V(3, 2) = V(2, 3) = V(3, 3) = -4.$
23. (a) $V(2, 2) = -1.0000, V(3, 2) = -.5000, V(2, 3) = -.5000, V(3, 3) = .0000$
(b) $V(2, 2) = 1.2500, V(3, 2) = -.2500, V(2, 3) = .2500, V(3, 3) = -1.2500$

.

Chapter 5

2. (b)
$$B_0^2 > \frac{2mV_0}{es^2}$$
, (e) $B_0^2 > \frac{8b^2mV_0}{e(b^2 - a^2)^2}$
3. $B_0 = \frac{-mg}{qv_0}$
4. (d) $\frac{e}{m} = \frac{E_y}{RB_0^2}$
8. (c) $\mathbf{J} = \sigma(\mathbf{E} + \mathbf{v} \times \mathbf{B})$
10. (a) $B_z = \frac{2\mu_0 I(a^2 + b^2)^{1/2}}{\pi ab}$, (c) $B_z = \frac{n\mu_0 I}{2\pi a} \tan \frac{\pi}{n}$
12. (a) $B_z = \frac{\mu_0 K_0 \pi}{4}$
13. (a) $B_{\phi} = \frac{\mu_0 IL}{2\pi r \sqrt{L^2 + r^2}}$
15. (b) $B_y = \frac{\mu_0 J o d}{2}$
17. (b) $B_x = \begin{cases} -\frac{\mu_0 J o}{2a} (y^2 - a^2) & |y| < a \\ 0 & |y| > a \end{cases}$
18. (d) $y = \frac{y_0}{2}$ at $x = -\infty$
21. (a) $m_z = \frac{1}{2}q\omega a^2$

23.
$$\omega_0 = \sqrt{\gamma B_0}$$

27. (a) $I' = \frac{(\mu_2 - \mu_1)}{(\mu_1 + \mu_2)} I$, $I'' = \frac{2\mu_1 I}{\mu_1 + \mu_2}$
34. (a) $\mathbf{H} = \begin{cases} \frac{-M_0}{2} \mathbf{i}_x \\ \frac{M_0 a^2}{2r^2} [\cos \phi \mathbf{i}_r + \sin \phi \mathbf{i}_{\phi}] \end{cases}$
35. (a) $H_z(\mathbf{x}) = -\frac{I}{Dd} (\mathbf{x} - d)$, (b) $f_x = \frac{1}{2} \mu_0 \frac{I^2 s}{D}$

36. (a)
$$f_x = \frac{1}{2}(\mu - \mu_0)H_0^2 Ds$$
, (b) $f_x = \mu_0 M_0 Ds[H_0 + M_0]$

Chapter 6

1. (a)
$$M = \mu_0 [D - \sqrt{D^2 - a^2}]$$
, (e) $f_r = \mu_0 Ii \left[\frac{D}{\sqrt{D^2 - a^2}} - 1\right]$
3. (d) $v(t) = v_0 \left[\frac{\alpha}{2\beta} \sin \beta t + \cos \beta t\right] e^{-\alpha t/2}$; $\beta = \sqrt{\omega_0^2 - \left(\frac{\alpha}{2}\right)^2}$
 $i(t) = \frac{m v_0 \omega_0^2}{B_0 b \beta} \sin \beta t e^{-\alpha t/2}$
(e) $v_0 > \frac{B_0 b s}{\sqrt{mL}}$
4. (a) $M = \frac{\mu_0 N s}{2\pi} \ln \frac{a}{b}, M = \mu_0 N [R - \sqrt{R^2 - a^2}]$
7. (c) $f_z = \frac{3\mu_0 (IdS)^2}{32\pi d^4}$
8. (a) $H_z = K(t)$, (b) $K(t) = K_0 \left(\frac{x_0}{x_0 - Vt}\right)^{(1 - 1/R_m)}$
9. (a) $i = \frac{r\sigma d}{2} \frac{dB}{dt} dr$, (c) $P = \frac{\pi \sigma da^4}{8} \left(\frac{dB}{dt}\right)^2$
10. $L = \mu_0 N^2 [b - \sqrt{b^2 - a^2}]$
14. (a) $\frac{v_2}{v_1} = \frac{N_2}{2N_1}, \frac{i_2}{i_1} = \frac{2N_1}{N_2}$
16. (a) $V_{oc} = J_x B_z d \frac{(\mu_z^2 n_z + \mu_z^2 n_z)}{q(\mu_z n_z + \mu_z n_z)^2}$

705

$$\begin{aligned} 17. (b), (c) \ EMF &= -\frac{\mu_0 V_0 I}{2\pi} \ln \frac{R_2}{R_1}, \\ (d) \ EMF &= -\frac{(\mu - \mu_0)IV_0}{2\pi} \ln \frac{R_2}{R_1} \\ 18. (a) \ \mathbf{H} &= 0, \mathbf{B} &= \mu_0 M_0 \mathbf{i}_z, \quad (b) \ v_{oc} &= \frac{\omega B_z}{2} (b^2 - a^2) \\ 20. (b) \ V &> \frac{1}{\mu_0 \sigma ND} \\ 21. (a) \ \omega &> \frac{(R_r + R_f)}{G} \\ (b) \ C_{crit} &= \frac{4L_f}{[R_r + R_f - G\omega]^2}; \quad C > C_{crit} (dc), \quad C < C_{crit} (ac) \\ (c) \ \omega_0 \left[\frac{1}{L_f C} - \left[\frac{R_r + R_f - G\omega}{2L_f} \right]^2 \right]^{1/2} \\ 22. (b) \ H_z(x, t) &= \sum_{\substack{n=1\\n \text{ odd}} \frac{2H_0}{n\pi D} \sin \frac{n\pi x}{d} e^{-a_n t} \\ 23. (c) \ H_y(x, t) &= H_0 - \sum_{\substack{n=1\\n \text{ odd}} \frac{4H_0}{n\pi d} \sin \frac{n\pi x}{d} e^{-a_n t} \\ 25. (b) \ H_z(y, t) &= -K_0 + \sum_{\substack{n=0\\n \text{ odd}} \frac{(-1)^n 4K_0}{\pi(2n+1)} \cos \left[\frac{(2n+1)\pi y}{2D} \right] - e^{-a_n t} \\ (d) \ \hat{H}_z(y) &= K_0 \left[\frac{[e^{(1+i)y/\delta} + e^{-(1+i)y/\delta}]}{[e^{(1+i)D/\delta} + e^{-(1+i)D/\delta}]} \right] \\ 26. (a) \ H_z(x) &= \frac{K_0}{1 - e^{R_n}} [2e^{R_n x/t} - (1 + e^{R_n})] \\ 27. (a) \ \hat{H}_z(x) &= K_0 \ e^{-\beta x} \ e^{R_n x/2t}; \beta &= \frac{R_m}{2t} \sqrt{1 + \frac{2jt^2}{R_m^2 \delta^2}} \\ 28. (a) \\ \hat{\mathbf{H}}(x) &= \left\{ \frac{K_0 \left\{ \left(1 - \frac{\mu}{\mu_0} \frac{k}{\gamma}\right) e^{k(x-s)} (i_z + ji_x) + \left(1 + \frac{\mu}{\mu_0} \frac{k}{\gamma}\right) e^{-k(x-s)} (i_z - ji_x) \right\} \\ \left[1 - \frac{\mu}{\mu_0} \frac{k}{\gamma} \right] e^{-kx} + \left[1 + \frac{\mu}{\mu_0} \frac{k}{\gamma} \right] e^{ks} \\ 0 < x < s \\ \end{array} \right. \end{aligned}$$

29. (a)
$$H_y = H_0 \frac{\cosh k(x - d/2)}{\cosh kd/2}$$

32. (b) $\hat{H}_{\phi}(r) = \frac{I_0}{2\pi a} \frac{J_1[(r/\delta)(1-j)]}{J_1[(a/\delta)(1-j)]}$
33. (a) $T = -L_1 I_0^2 \cos^2 \omega_0 t \sin 2\theta$
34. (c) $T = M_0 I_1 I_2 \cos \theta$,
(f) $\theta(t) = \theta_0 \left[\cos \beta t + \frac{\alpha}{2\beta} \sin \beta t \right] e^{-\alpha t/2}$
35. (a) $L(x) = \frac{\mu_0 x}{2\pi} \ln \frac{b}{a}$, (b) $f_x = \frac{\mu_0 i^2}{4\pi} \ln \frac{b}{a}$
37. $h = \frac{I^2(\mu - \mu_0) \ln \frac{b}{a}}{4\pi^2 \rho_m g(b^2 - a^2)}$

Chapter 7

4. (b)
$$W = 4[P_s E_c + \mu_0 M_s H_c]$$

9. (b) $\hat{E}_x(z) = \begin{cases} \frac{j\eta_0 J_0 \sin kd \ e^{\mp jk_0(z \neq d)}}{\omega \varepsilon [\eta_0 \sin kd - j\eta \cos kd]} & z > d \\ -\frac{J_0 \eta \cos kz}{\omega \varepsilon [\eta_0 \sin kd - j\eta \cos kd]} & |z| < d \end{cases}$
10. (b) $E_x = E_0 \ e^{j(\omega t \neq \beta z)} \ e^{\mp (\alpha z/2)} & z > 0 \\ z < 0; \ \beta = \sqrt{\omega^2 \varepsilon \mu - \frac{\alpha^2}{4}} \end{cases}$

11. (a)
$$t'_{1} - t'_{2} = \frac{\gamma v}{c_{0}^{2}}(z_{2} - z_{1}),$$

(b) $t'_{1} - t'_{2} = \gamma(t_{1} - t_{2}),$ (c) $z'_{2} - z'_{1} = \gamma L$
12. (a) $u'_{z} = \frac{u_{z} - v}{1 - v u_{z}/c_{0}^{2}}, u'_{x,y} = \frac{u_{x,y}\sqrt{1 - (v/c_{0})^{2}}}{1 - v u_{z}/c_{0}^{2}}$
15. (b) $\varepsilon(\omega) = \varepsilon_{0} \left[1 + \frac{\omega_{p}^{2}}{\omega_{0}^{2} - \omega^{2}} \right]$
16. (c) $k^{2} = \frac{\omega^{2}}{c^{2}} \left[1 - \frac{\omega_{p}^{2}}{\omega(\omega \mp \omega_{0})} \right]$
20. (a) $\mathbf{E} = E_{0} \left[\cos \omega \left(t - \frac{z}{c} \right) - \cos \omega \left[\left(1 - \frac{2v}{c} \right) \left(t - \frac{z}{c} \right) \right] \right] \mathbf{i},$
22. $\alpha^{2} - k^{2} = -\omega^{2} \varepsilon \mu, \ \mathbf{a} \cdot \mathbf{k} = \frac{1}{\delta^{2}}$

26. (a)
$$L_1 + L_2 = s_i \sin \theta_i + s_r \sin \theta_r = h_1 \tan \theta_i + h_2 \tan \theta_r$$

31. $\theta_i \approx 41.7^\circ$
33. (a) $\left(\frac{x}{R}\right)^2 > 1 - \frac{(n^2 - 2)^2}{4}; \sqrt{2} \le n \le 2$
(b) $R' = \frac{\alpha R}{[\sqrt{n^2(1 - \alpha^2)}\sqrt{n^2 - \alpha^2} + \alpha^2]}$
Chapter 8

2. (c)
$$\hat{v}(z) = -\frac{V_0 \sin \beta(z-l) e^{\alpha z/2}}{\sin \beta l}$$
 (Short circuited end)
4. (c) $\omega^2 = \omega_p^2 + k^2 c^2$, (d) $v(z, t) = -\frac{V_0 \sin kz \cos \omega t}{\sin kl}$
5. (b) $k = \frac{1}{\omega \sqrt{LC}}$
14. (a) $V_+ = -V_- = \frac{V_0 Z_0}{2R_*}$
16. (b) $\tan kl = -XY_0$
21. (c) $VSWR = \frac{1+\sqrt{2}}{\sqrt{2}-1} \approx 5.83$
22. (b) $VSWR = 2$
23. $Z_L = 170.08 - 133.29j$
24. (a) $l_1 = .137\lambda + \frac{n\lambda}{2}, l_2 = .089\lambda + \frac{m\lambda}{2}$
 $l_1 = .279\lambda + \frac{n\lambda}{2}, l_2 = .411\lambda + \frac{m\lambda}{2}$
25. (a) $l_1 = .166\lambda + \frac{n\lambda}{2}, l_2 = .043\lambda + \frac{m\lambda}{2}$
 $l_1 = .077\lambda + \frac{n\lambda}{2}, l_2 = .043\lambda + \frac{m\lambda}{2}$
27. (e) $\alpha = \frac{2(\pi/a)^2[b + (a/2)(\omega^2 a^2/\pi^2 c^2)]}{\omega \mu abk_x \sigma_w \delta}$
28. (b) $= \frac{2\omega\varepsilon (bk_x^2 + ak_y^2)}{\sigma_w \delta k_z ab(k_x^2 + k_y^2)}$

29. (a) TE mode: electric field: $\cos k_x \cos k_y = \text{const}$

magnetic field: $\frac{\sin (k_x x)^{(k_y/k_x)^2}}{\sin k_y y} = \text{const}$

31. (b)
$$\frac{\omega^2}{c^2} = \left(\frac{m\pi}{a}\right)^2 + \left(\frac{n\pi}{b}\right)^2 + \left(\frac{p\pi}{l}\right)^2$$
,

32. (a)
$$\omega^2 = \frac{\pi_2}{\epsilon \mu - \epsilon_0 \mu_0}$$

Chapter 9

1. (c)
$$\hat{V} = \frac{\hat{Q}}{4\pi\varepsilon r} e^{-jr\sqrt{\omega^2/c^2 - j\omega\mu\sigma}}$$

4. (a)
$$dl_{\text{eff}} = \frac{2 \sin (\alpha dl/2)}{\alpha}$$
, $\hat{\lambda}(z) = \frac{I_0 \alpha}{j \omega} \sin \alpha z$

6. (a)
$$\hat{p}_z = 4\pi\varepsilon_0 R^3 \hat{E}_0$$

(c) $\langle P \rangle = \frac{\omega^4 |\hat{p}_z|^2 \eta}{12\pi c^2}$

7. (a)
$$m_{ind} = 2\pi H_0 R^3$$

8. (b) $\sin^2 \theta \left[\frac{\cos(\omega t - kr)}{kr} - \sin(\omega t - kr) \right] = \text{const}$
9. (a) $\hat{E}_{\theta} \approx \frac{2\hat{E}_0}{jkr} \sin \theta e^{-j(kr - \chi/2)} \left[\cos\left(ka \cos \theta - \frac{\chi}{2}\right) \right]$

11.
$$\hat{E}_{\theta} = \frac{2jK_0 dl\eta \ e^{-jkr}}{4\pi r \cos \phi} \sin \left(\frac{kL}{2} \sin \theta \cos \phi\right)$$

12. (a)
$$\hat{E}_{\theta} = \frac{\eta I_0 \sin \theta e^{-jkr}}{j\pi krL \cos^2 \theta} \cos \left[\left(\frac{kL}{2} \cos \theta \right) - 1 \right]$$

INDEX

Addition, vector, 9-10 Admittance, characteristic, 579 A field, 336. See also Vector potential Amber, 50 Ampere, unit, 55 Ampere's circuital law, 334 displacement current correction to, 488 Ampere's experiments, 322 Amperian currents, 348 Analyzer, 518 Angular momentum, 350 Anisotropic media, 516-520 Antennas: long dipole, 687-695 N element array, 685-687 point electric dipole, 667-677 point magnetic dipole, 679-681 two element array, 681-685 Array: broadside, 683 endfire, 685 factor, 683, 685, 687 N element, 685-687 two element, 681-685 Atmosphere, as leaky spherical capacitor, 195-197 Atom, binding energy of, 211-212 Attenuation constant: dielectric waveguide, 646-648 lossy transmission line, 602-606 lossy rectangular waveguide, 644 non-uniform plane waves, 531-532 Autotransformer, 474 Avogadro's number, 136 Axisymmetric solutions to Laplace's equation, 286-288 Backward wave distributed system, 651 Barium titanate, 150 Base units, 55 Batteries due to lightning, 197 Bessel's equation, 280, 482 functions, 281 Betatron, 402-404 oscillations, 404 Bewley, L. V., 433, 475 B field, see Magnetic field Binding energy, of atom, 211-212 of crystal, 205-206 Biot-Savart law, 322-323 Birefringence, 518-520 Bohr atomic model, 111-112

Bohr magneton, 350 Bohr radius, 63 Boltzmann constant, 155 Boltzmann distribution, 156 Boundary conditions: normal component of: current density J, 168-169 displacement field D, 163-164 magnetic field **B**, 366 polarization P, 165-166 $\epsilon_0 E, 165-166$ tangential component of: electric field E, 162-163 magnetic field H, 359-360 magnetization M, 360 Breakdown, electric strength, 93, 223 electromechanical, 252 Brewster's angle, 540-543 and polarization by reflection, 547 Broadside array, 683 Capacitance: as approximation to short transmission line, 589-592, 601 coaxial cylindrical electrodes, 176-177 concentric spherical electrodes, 176-177 energy stored in, 212-213 force on, 219-223 any geometry, 172 isolated sphere, 178, 213 parallel plate electrodes, 173-177 per unit length on transmission line, 570, 572 power flow in, 491-493 reflections from at end of transmission line, 593-594 and resistance, 177 in series or parallel, 242-243 slanted conducting planes, 273 two contacting spheres, 178-181 two wire line, 101-103 Cartesian coordinates, 29-30 Cauchy's equation, 563 Cauchy-Riemann equations, 305 Chalmers, J. A., 293 Characteristic admittance, 579 Characteristic impedance, 579 Charge: by contact, 50 differential elements, 60 distributions, 59-63

and electric field, 56-57 force between two electrons, 56 forces on, 51-52 and Gauss's law, 74-76 polarization, 140-142, 149 Charge relaxation, series lossy capacitor, 184-189 time, 182-184 transient, 182 uniformly charged sphere, 183-184 Child-Langmuir law, 200 Circuit theory as quasi-static approximation, 490 Circular polarization, 515-516 Circulation, 29 differential sized contour, 30 and Stokes' theorem, 35 Coaxial cable, capacitance, 176-177 inductance, 456-458 resistance, 172 Coefficient of coupling, 415 Coercive electric field, 151 Coercive magnetic field, 356-357 Cole-Cole plot, 234 Collision frequency, 154 Commutator, 429 Complex permittivity, 509, 524 Complex Poynting's theorem, 494-496 Complex propagation constant, 530-532 Conductance per unit length, 190 Conduction, 51 drift-diffusion, 156-159 Ohmic, 159-160 superconductors, 160-161 Conductivity, 159-160 of earth's atmosphere, 195 and resistance, 170 Conjugate functions, 305 Conservation of charge, 152-154 boundary condition, 168-169 inconsistency with Ampere's law, 488-489 on perfect conductor with time varying surface charge, 537 Conservation of energy, 199 Constitutive laws: linear dielectrics, 143-146 linear magnetic materials, 352, 356 Ohm's law, 159-160 superconductors, 160-161 Convection currents, 182, 194-195 Coordinate systems, 2-7 Cartesian (rectangular), 2-4 circular cylindrical, 4-7 inertial, 417

spherical, 4-7 Coulomb's force law, 54-55 Critical angle, 541-544 Cross (Vector) product, 13-16 and curl operation, 30 Crystal binding energy, 205-206 Curl: Cartesian (rectangular) coordinates, 29-30 circulation, 29-31 curvilinear coordinates, 31 cylindrical coordinates, 31-33 of electric field, 86 of gradient, 38-39 of magnetic field, 333 spherical coordinates, 33-35 and Stokes' theorem, 35-38 Current, 152-154 boundary condition, 168-169 density, 153-154 over earth, 196 between electrodes, 169-170 through lossless capacitor, 178 through series lossy capacitor, 187-189 sheet, as source of non-uniform plane waves, 532-534 as source of uniform plane waves, 500-503 Curvilinear coordinates, general, 46 Cut-off in rectangular waveguides, 638-641 Cyclotron, 319-321 frequency, 316 Cylinder: magnetically permeable, 357-359 and method of images, 97-103 permanently polarized, 166-168 surface charged, 80-82 with surface current, 335-336 in uniform electric field, 273-277 perfectly conducting, 278 perfectly insulating, 279 volume charged, 72, 82 with volume current, 336 Cylindrical coordinates, curl, 31 divergence, 24-26 gradient, 17 Debye length, 157-159 Debye unit, 139 Dees, 319 Del operator, 16 and complex propagation vector, 531 and curl, 30 and divergence, 24

and gradient, 16 Delta function, 187 Diamagnetism, 349-352 Dichroism, 517 Dielectric, 143 coating, 525-528 constant, 146-147 linear, 146-147 modeled as dilute suspension of conducting spheres, 293 and point charge, 164-165 waveguide, 644-648 Difference equations: capacitance of two contacting spheres, 179-181 distributed circuits, 47-48 self-excited electrostatic induction machines, 227-230 transient transmission line waves, 586-587 Differential: charge elements, 60 current elements, 323 cylindrical charge element, 81-82 lengths and del operator, 16-17 line, surface, and volume elements, 4 planar charge element, 68 spherical charge element, 79-80 Diffusion, coefficient, 156 equation, 191 Diode, vacuum tube, 198-201 Dipole electric field: far from permanently polarized cylinder, 168 far from two oppositely charged electrodes, 169, 172 along symmetry axis, 58-59 two dimensional, 231, 274 Dipole moment, electric, 137 magnetic, 345 Directional cosines, 41 Dispersion, complex waves, 531 light, 563 Displacement current, 154, 178 as correction to Ampere's law, 488-489 Displacement field, 143 boundary condition, 163-164 parallel plate capacitor, 175 permanently polarized cylinder, 166-168 in series capacitor, 185 Distortionless transmission line, 603 Distributed circuits: backward wave, 650 inductive-capacitive, 47-48

resistive-capacitive, 189-194 transmission line model, 575-576 Divergence: Cartesian (rectangular) coordinates, 23-24 of curl, 39 curvilinear coordinates, 24 cylindrical coordinates, 24-26 of electric field, 83 of magnetic field, 333 spherical coordinates, 26 theorem, 26-28 and Gauss's law, 82-83 relating curl over volume to surface integral, 44 relating gradient over volume to surface integral, 43 Domains, ferroelectric, 50 ferromagnetic, 356-357 Dominant waveguide mode, 640 Doppler frequency shifts, 507-508 Dot (scalar) product, 11-13 and divergence operation, 24 and gradient operation, 16 Double refraction, 518-520 Double stub matching, 625-629 Drift-diffusion conduction, 156-159 Earth, fair weather electric field, 195 magnetic field, 424-425 Eddy currents, 401 Effective length of radiating electric dipole, 676-677 Einstein's relation, 156 Einstein's theory of relativity, 207 Electrets, 151 force on, 218 measurement of polarization, 239-240 Electric breakdown, 93, 223-224 mechanical, 252 Electric dipole, 136 electric field, 139 moment, 137-140, 231 potential, 136-137 radiating, 667-671 units, 139 Electric field, 56-57 boundary conditions, normal component, 83, 165-166 tangential component, 162-163 of charge distribution, 63-64 of charged particle precipitation onto sphere, 293 of cylinder with, surface charge, 71, 80-82

714 Index

volume charge, 72, 82 in conducting box, 269 discontinuity across surface charge, 83 of disk with surface charge, 69-71 due to lossy charged sphere, 183 due to spatially periodic potential sheet, 966 due to superposition of point charges, 57-58 energy density, 208-209 and Faraday's law, 395 of finite length line charge, 89 and gradient of potential, 86 around high voltage insulator bushing, 284 of hoop with line charge, 69 between hyperbolic electrodes, 262 of infinitely long line charge, 64-65 of infinite sheets of surface charge, 65-69 line integral, 85-86 local field around electric dipole, 145-146 around lossy cylinder, 276 around lossy sphere, 289 numerical method, 298 around permanently polarized cylinder, 166-168 of permanently polarized cylinder, 166-168 of point charge above dielectric boundary, 165 of point charge near grounded plane, 107 of point charge near grounded sphere, 106 of radiating electric dipole, 671 in resistive box, 263 in resistor, coaxial cylinder, 172 concentric sphere, 173 parallel plate, 171 of sphere with, surface charge, 76-79 volume charge, 79-80 transformation, 417 between two cones, 286 of two infinitely long opposite polarity line charges, 94 of two point charges, 58-59 of uniformly charged volume, 68-69 **Electric field lines:** around charged sphere in uniform field, 297 around cylinder in uniform field, 276-277 due to spatially periodic potential

sheet, 267 of electric dipole, 139 around high voltage insulator bushing, 284 between hyperbolic electrodes, 262 of radiating electric dipole, 671-673 within rectangular waveguide, 636, 639 around two infinitely long opposite polarity line charges, 95-96 around uncharged sphere in uniform field, 290-291 Electric potential, 86-87 of charge distribution, 87 within closed conducting box, 268, 300 due to spatially periodic potential sheet, 266 and electric field, 86-87 of finite length line charge, 88-89 around high voltage insulator bushing, 282-284 between hyperbolic electrodes, 262 of infinitely long line charge, 94 inside square conducting box, 299-301 of isolated sphere with charge, 109 around lossy cylinder in uniform electric field, 274 around lossy sphere in uniform electric field, 288 within open resistive box, 263 of point charge, 87 of point charge above dielectric boundary, 165 of point charge and grounded plane, 107 of point charge and grounded sphere, 103 of sphere with, surface charge, 90-91 volume charge, 90-91 between two cones, 286 of two infinitely long line charges, 94 between upper atmosphere and earth's surface, 196-197 and zero potential reference, ground, 87 Electric susceptibility, 146 Electromechanical breakdown, 252 Electromotive force (EMF), 395 due to switching, 433 due to time varying number of coil turns, 433-435 in magnetic circuits, 406 Electron, beam injection into dielectrics, 201 charge and mass of, 56

radius of, 207

Electronic polarization, 136 Electron volts, 206 Electroscope, 53-54 Electrostatic generators, and Faraday's ice pail experiment, 53-54 induction machines, 224-230 Van de Graaff, 223-224 Electrostatic induction, 51-53 Faraday's ice pail experiment, 53-54 machines, 224-230 Electrostatic precipitation, 293, 307 Electrostatic radiating field, 671 Electrostriction, 151 Elliptical polarization, 515 Element factor, 683 Endfire array, 685 Energy: binding, of atom, 211-212 of crystal, 205-206 and capacitance, 212-213, 220 and charge distributions, 204-208 conservation theorem, 199 and current distributions, 454 density, electric field, 208-209 magnetic field, 441-455 and inductance, 454 stored in charged spheres, 210 Equipotential, 84-85 Euerle, W. C., 227 Exponential transmission line, 649 External inductance, 456-457 Fair weather electric field, 195 Farad, 175 Faraday, M., 394 cage, 78 disk, 420-422 ice pail experiment, 53-54 Faraday's law of induction, 394-397, 489 and betatron, 403 for moving media, 417 and paradoxes, 430-435 and resistive loop, 412 and Stokes' theorem, 404 Far field radiation, 671 Fermat's principle, 562 Ferroelectrics, 149-151 Ferromagnetism, 357 Fiber optics, 550-552 Field emission, 109 Field lines, see Electric field lines; Magnetic field lines Flux, 22 and divergence, 21-26

and divergence theorem, 26-28 and Gauss's law, 74-75 and magnetic field, 338 magnetic through square loop, 342-343 and sources, 21-22 and vector potential, 338 Force: on capacitor, 219-223 Coulomb's law, 54-56 on current carrying slab, 441, 444 between current sheets, 329 due to pressure gradient, 155 on electric dipole, 216 gravitational, 56 on inductor, 461 interfacial, 264 on linear induction machine, 449-450 between line charge and cylinder, 99 between line charge and plane, 97 between line current and perfect conductor or infinitely permeable medium, 363 between line currents, 314-315 on magnetically permeable medium, 363 on magnetic block, 465 on magnetic dipole, 352, 368-370 on magnetizable current loop, \$70-375 on MHD machine, 430 on moving charge, 314-315 on one turn loop, 464 between point charge and dielectric boundary, 165 between point charge and grounded plane, 108 between point charge and grounded sphere, 105 between point charges, 51-56 between point charge and sphere of constant charge, 109 between point charge and sphere of constant potential, 110 on polarizable medium, 215-219 on relay, 463 on surface charge, 213-215 between two contacting spheres, 181 between two cylinders, 100 Fourier series, 267 Frequency, 505-506 Fringing fields, 173-175 Fundamental waveguide mode, 640

Galilean coordinate transformation, 505 Galilean electric field transformation, 417 Garton, C. G., 252 Gas conduction model, 154-155 Gauge, setting, 665 Gauss's law, 75, 489 and boundary conditions: normal component of current density, 168 normal component of displacement field. 163-164 normal component of polarization. 165-166 normal component of $\epsilon_0 E$, 83, 165-166 and charge distributions, 75 and charge injection into dielectrics, 201-202 and conservation of charge, 154 and cylinders of charge, 80-82 and displacement field, 143 and divergence theorem, 82-83 and lossy charged spheres, 183-184 for magnetic field, 333 and point charge inside or outside volume, 74-75 and polarization field, 142 and resistors, coaxial cylinder, 172 parallel plate, 171 spherical, 173 and spheres of charge, 76-80 Generalized reflection coefficient, 607-608 Generators, 427-429 Geometric relations between coordinate systems, 7 Gibbs phenomenon, 269 Gradient: in Cartesian (rectangular) coordinates, 16-17 in cylindrical coordinates, 17 and del operator, 16 and electric potential, 86 and line integral, 18-21 of reciprocal distance, 73 in spherical coordinates, 17-18 theorem, 43-44, 334, 370 Gravitational force, 56 Green's reciprocity theorem, 124 Green's theorem, 44 Ground, 87 Group velocity, 513 on distortionless transmission line, 603 in waveguide, 641 Guard ring, 173-174 Gyromagnetic ratio, 385 Half wave plate, 519

Hall effect, 321-322 Hall voltage, 322 Harmonics, 267-269 Helix, 317 Helmholtz coil, 331 Helmholtz equation, 631 Helmholtz theorem, 337-338, 665 H field, see Magnetic field High voltage bushing, 282-284 Holes, 154, 321 Homopolar generator, 420-422 periodic speed reversals, 426-427 self-excited, 422-424 self-excited ac operation, 424-425 Horenstein, M. N., 282 Hyperbolic electrodes, 261-262 Hyperbolic functions, 264-265 Hysteresis, ferroelectric, 150-151 magnetic, 356-357 and Poynting's theorem, 553 Identities, vector, 38-39, 46-47 Images, see Method of Images Impedance, characteristic, 579 of free space, 498 wave, 498 Impulse current, 187 Index of refraction, 540 Inductance: of coaxial cable, 456-458, 575 external, 456-457 and ideal transformer, 414-415 internal, 457-458 and magnetic circuits, 407-411 mutual, 398 as quasi-static approximations to transmission lines, 589-592, 601 reflections from at end of transmission line, 594-595 and resistance and capacitance, 458-459 self, 407 of solenoid, 408 of square loop, 343 of toroid, 409 per unit length on transmission line, 570, 572 Induction, electromagnetic, 394-395 electrostatic, 51-54, 224-230 machine, 446-450 Inertial coordinate system, 417 Internal inductance, 457-458 International system of units, 55 Ionic crystal energy, 205-206 Ionic polarization, 136-137

Ionosphere plane wave propagation, 511-512, 557 Isotopes, 318-319 Kelvin's dynamo, 227 Kerr effect, 520, 558 Kinetic energy, 199 Kirchoff's current law, 154, 490 Kirchoff's laws on transmission lines, 569-570 Kirchoff's voltage law, 86, 490 Laminations, 401-402, 470-471 Lange's Handbook of Chemistry, 147 Langevin equation, 251 for magnetic dipoles, 355 Langmuir- Child law, 200 Laplace's equation, 93, 258 Cartesian (rectangular) coordinates, 260 cylindrical coordinates, 271 and magnetic scalar potential, 365 spherical coordinates, 284 Laplacian of reciprocal distance, 73-74 Larmor angular velocity, 316 Laser, 517 Law of sines and cosines, 41 Leakage flux, 415 Left circular polarization, 516 Legendre's equation, 287 Legendre's polynomials, 287-288 Lenz's law, 395-397 and betatron, 403 Leyden jar, 227 L'Hôpital's rule, 589 Lightning producing atmospheric charge, 197 Light pipe, 550-552, 565 Light velocity, 56, 497 Linear dielectrics, 143-147 Linear induction machine, 446-450 Linear magnetic material, 352, 356 Linear polarization, 515 Line charge: distributions, 60 finite length, 88-89 hoop, 69 infinitely long, 64-65 method of images, 96-103 near conducting plane, 96-97 near cylinder, 97-99 two parallel, 93-96 two wire line, 99-103 Line current, 324 Line integral, 18-21

of electric field, 85 of gradient, 19-20 and Stokes' theorem, 36 and work, 18-19 Local electric field, 145-146 Lord Kelvin's dynamo, 227 Lorentz field, 238 Lorentz force law, 314-316 Lorentz gauge, 665 Lorentz transformation, 417, 505 Lossy capacitor, 184-189 Madelung, electrostatic energy, 205 Magnesium isotopes, 319 Magnetic charge, 489 Magnetic circuits, 405-407 Magnetic diffusion, 435 with convection, 444-446 equation, 437 Reynold's number, 446 skin depth, 442-443 transient, 438-441 Magnetic dipole, 344 field of, 346 radiation from, 679-681 vector potential, 345, 680 Magnetic energy: density, 455 and electrical work, 452 and forces, 460-461 and inductance, 454 and mechanical work, 453, 460-461 stored in current distribution, 454 Magnetic field, 314, 322-323 and Ampere's circuital law, 333-334 boundary conditions, 359-360 due to cylinder of volume current, 336 due to finite length line current, 341 due to finite width surface current, 342 due to hollow cylinder of surface current, 332, 336 due to hoop of line current, 330 due to infinitely long line current, 324-325 due to magnetization, 348-349 due to single current sheet, 327 due to slab of volume current, 327 due to two hoops of line current (Helmholtz coil), 331 due to two parallel current sheets, 328 in Helmholtz coil, 331 and Gauss's law, 332-333 of line current above perfect conductor or infinitely permeable medium, 363

of line current in permeable cylinder, 358 in magnetic circuits, 405-407, 411 of magnetic dipole, 346 in magnetic slab within uniform field, 361 of radiating electric dipole, 670 of radiating magnetic dipole, 681 in solenoid, 408 of sphere in uniform field, 364-367 in toroid, 409 and vector potential, 336-338 Magnetic field lines, 342, 366-367 Magnetic flux, 333, 343 in magnetic circuits, 406-411 Magnetic flux density, 349 Magnetic scalar potential, 365 Magnetic susceptibility, 350, 352 Magnetite, 343 Magnetization, 343 currents, 346-348 Magnetohydrodynamics (MHD), 430 Magnetomotive force (mmf), 409 Magnetron, 375-376 Mahajan, S., 206 Malus, law of, 518 Mass spectrograph, 318-319 Matched transmission line, 582, 584 Maxwell's equations, 489, 664 Meissner effect, 451 Melcher, J. R., 227, 264, 420, 435 Method of images, 96 line charge near conducting plane, 96-97 line charge near cylinder, 97-99 line charge near dielectric cylinder, 238-239 line current above perfect conductor or infinitely permeable material, 361-363 point charge near grounded plane, 106-107 point charge near grounded sphere, 103-106 point charge near sphere of constant charge, 109 point charge near sphere of constant potential, 110 two contacting spheres, 178-181 two parallel line charges, 93-96 two wire line, 99-103 M field, 343 MHD, 430 Michelson-Morley experiment, 503 Millikan oil drop experiment, 110-111

Mirror, 547 MKSA System of units, 55 Mobility, 156, 201, 293 Modulus of elasticity, 252 Momentum, angular, 350 Motors, 427-429 Mutual inductance, 398 Near radiation field, 671 Newton's force law, 155 Nondispersive waves, 503 Nonuniform plane waves, 529, 532-533 and critical angle, 542 Normal component boundary conditions: current density, 168 displacement field, 163-164 magnetic field, 360 polarization and $\epsilon_0 E$, 165-166 Normal vector: and boundary condition on displacement field, 163-164 and contour (line) integral, 29 and divergence theorem, 27 and flux, 22 integrated over closed surface, 44 and surface integral, 22 Numerical method of solution to Poisson's equation, 297-301 Oblique incidence of plane waves, onto dielectric, 538-543 onto perfect conductor, 534-537 Oersted, 314 Ohmic losses, of plane waves, 508-511 in transmission lines, 602-606 in waveguides, 643-644 Ohm's law, 159-160 with convection currents, 182 in moving conductors, 418 Open circuited transmission lines, 585, 589-590, 599-600 Optical fibers, 550-552 Orientational polarization, 136-137 Orthogonal vectors and cross product, 14 Orthogonal vectors and dot product, 11-12 Paddle wheel model for circulation, 30-31 Parallelogram, and cross(vector) product, 13 rule for vector addition and subtraction, 9-10 Parallelpiped volume and scalar triple product, 42 Paramagnetism, 352-356

Perfect conductor, 159-160 Period, 506 Permeability, of free space, 322 magnetic, 352, 356 Permeance, 411 Permittivity: complex, 509, 524 dielectric, 146-147 of free space, 56 frequency dependent, 511 P field, 140, 165-166. See also Polarization Phase velocity, 513 on distortionless transmission line, 603 in waveguide, 641 Photoelastic stress, 520 Piezoelectricity, 151 Planck's constant, 350 Plane waves, 496-497 losses, 508-511 non-uniform, 530-533 normal incidence onto lossless dielectric, 522-523 normal incidence onto lossy dielectric, 524-525 normal incidence onto perfect conductor, 520-522 oblique incidence onto dielectrics, 538-544 oblique incidence onto perfect conductors, 534-537 power flow, 498, 532 uniform, 529-530 Plasma, conduction model, 154-155 frequency, 161, 511 wave propagation, 511-512 Pleines, J., 206 Point charge: above dielectric boundary, 164-165 within dielectric sphere, 147-149 force on, 55-58 near plane, 106-108 in plasma, 158-159 radiation from, 666-667 near sphere, 103-110 Poisson equation, 93, 258 and Helmholtz theorem, 338 and radiating waves, 665-666 within vacuum tube diode, 199 Poisson-Boltzmann equation, 157 Polariscope, 518-520 Polarizability, 143-144 and dielectric constant, 147 Polarization: boundary conditions, 165-166

charge, 140-142, 149 cylinder, 166-168 and displacement field, 146-147 electronic, 136 force density, 215-219 ionic, 136 orientational, 136 in parallel plate capacitor, 176-177 by reflection, 546-547 spontaneous, 149-151 of waves, 514-516 Polarizers, 517-520 Polarizing angle, 547 Polar molecule, 136-137 Polar solutions to Laplace's equation, 271-272 Potential: energy, 199 retarded, 664-667 scalar electric, 86-93, 664-667 scalar magnetic, 365-367 vector, 336, 664-667 see also Electric potential; Vector potential Power: in capacitor, 220 on distributed transmission line, 576-578 in electric circuits, 493-494 electromagnetic, 491 flow into dielectric by plane waves, 524 in ideal transformer, 415 in inductor, 461 from long dipole antenna, 692 in lossy capacitor, 492 from radiating electric dipole, 675-676 time average, 495 in waveguide, 641 Poynting's theorem, 490-491 complex, 494-496 for high frequency wave propagation, 512 and hysteresis, 553 Poynting's vector, 491 complex, 495 and complex propagation constant, 532 through dielectric coating, 528 due to current sheet, 503 of long dipole antenna, 691 for oblique incidence onto perfect conductor, 536-537 through polarizer, 518 and radiation resistance, 674 in rectangular waveguide, 641-642

720 Index

reflected and transmitted through lossless dielectric, 524 time average, 495 of two element array, 683 and vector wavenumber, 530 Precipitator, electrostatic, 293-297, 307 Pressure, 154 force due to, 155 radiation, 522 Primary transformer winding, 415 Prisms, 549-550 Product, cross, 13-16 dot, 11-13 vector, 13-16 **Product solutions:** to Helmholtz equation, 632 to Laplace's equation: Cartesian (rectangular) coordinates, 260 cylindrical coordinates, 271-272 spherical coordinates, 284-288 Pyroelectricity, 151 Q of resonator, 660 Quadrapole, 233 Quarter wave long dielectric coating, 528 Quarter wave long transmission line, 608-610 Quarter wave plate, 520 Quasi-static circuit theory approximation, 490 Quasi-static inductors and capacitors as approximation to transmission lines, 589-592 Quasi-static power, 493-494 Radiation: from electric dipole, 667-677 field, 671 from magnetic dipole, 679-681 pressure, 522 resistance, 674-677, 691-694 Radius of electron, 207 Rationalized units, 55 Rayleigh scattering, 677-679 Reactive circuit elements as short transmission line approximation, 601-602 Reciprocal distance, 72 and Gauss's law, 74-75 gradient of, 73 laplacian of, 73-74 Reciprocity theorem, 124 Rectangular (Cartesian) coordinate system, 2-4

curl, 29-30 divergence, 23-24 gradient, 16-17 Rectangular waveguide, 629-644. See also Waveguide Reference potential, 86-87 Reflected wave, plane waves, 520, 522, 535-536, 538, 542 transmission line, 581-582, 586-587, 592-595 Reflection, from mirror, 545 polarization by, 546-548 **Reflection coefficient:** arbitrary terminations, 592-593 generalized, 607-608 of plane waves, 523 of resistive transmission line terminations, 581-582 Refractive index, 540 Relative dielectric constant, 146 Relative magnetic permeability, 356 Relativity, 503-505 Relaxation, numerical method, 297-301 Relaxation time, 182 of lossy cylinder in uniform electric field, 275 of two series lossy dielectrics, 186-187 Reluctance, 409 motor, 482-483 in parallel, 411 in series. 410 **Resistance:** between electrodes, 169-170 between coaxial cylindrical electrodes, 172 in open box, 262-264 between parallel plate electrodes, 170-171 in series and parallel, 186-187 between spherical electrodes, 173 Resistivity, 159 Remanent magnetization, 356-357 Remanent polarization, 151 Resonator, 660 Retarded potentials, 664-667 Reynold's number, magnetic, 446 Right circular polarization, 516 Right handed coordinates, 3-5 **Right hand rule:** and circulation, 29-30 and cross products, 13-14 and Faraday's law, 395 and induced current on perfectly conducting sphere, 367 and line integral, 29

and magnetic dipole moment, 344-345 and magnetic field, 324 Saturation, magnetic, 356-357 polarization, 150-151 Saturation charge, 295 Scalar electric potential, 86-87 Scalar magnetic potential, 365 Scalar potential and radiating waves, 664-667,669-670 Scalar (dot) product, 11-13 Scalars, 7-8 Scalar triple product, 42 Schneider, J. M., 201 Seawater skin depth, 443 Secondary transformer winding, 415 Self-excited machines, electrostatic, 224-230 homopolar generator, 422-427 Self-inductance, see Inductance Separation constants, to Helmholtz equation, 632 to Laplace's equation, 260-261, 271, 278-280, 286-287 Separation of variables: in Helmholtz equation, 632 in Laplace's equation: Cartesian, 260-261, 264-265, 270 cylindrical, 271, 277-282 spherical, 284-288 Short circuited transmission line, 585, 590.596-599 Sidelobes, 688 Sine integral, 691, 694 SI units, 55-56, 322 capacitance, 175 resistance, 171 Skin depth, 442-443 with plane waves, 511, 525 and surface resistivity, 604-606, 643 Slip, 448 Single stub tuning, 623-625 Sinusoidal steady state: and complex Poynting's theorem, 494-495and linear induction machine, 446-450 and magnetic diffusion, 442-444 and Maxwell's equations, 530-532 and radiating waves, 667-671 and series lossy capacitor, 188-189 and TEM waves, 505-507 Slot in waveguide, 635 Smith chart, 611-615 admittance calculations, 620-621 stub tuning, 623-629

Snell's law, 540 Sohon, H., 431 Solenoid self-inductance, 407-408 Space charge limited conduction, in dielectrics, 201-203 in vacuum tube diode, 198-201 Speed coefficient, 421 Sphere: capacitance of isolated, 178 of charge, 61-63, 76-80, 91 charge relaxation in, 183-184 earth as leaky capacitor, 195-197 as electrostatic precipitator, 293-297 lossy in uniform electric field, 288-293 method of images with point charge, 103-110 point charge within dielectric, 147-149 two charged, 92 two contacting, 178-181 in uniform magnetic field, 363-368 Spherical coordinates, 4-6 curl, 33-37 divergence, 26 gradient, 17 Spherical waves, 671 Spin, electron and nucleus, 344 Standing wave, 521-522 Standing wave parameters, 616-620 Stark, K. H., 252 Stewart, T. D., 237 Stokes' theorem, 35-38 and Ampere's law, 349 and electric field, 85-86 and identity of curl of gradient, 38-39 and magnetic flux, 338 Stream function: of charged particle precipitation onto sphere, 297 cylindrical coordinates, 276-277 of radiating electric dipole, 672 spherical coordinates, 290-291 Stub tuning, 620-629 Successive relaxation numerical method, 297-301 Superconductors, 160-161 and magnetic fields, 450-451 Surface charge distribution, 60 and boundary condition on current density, 168 and boundary condition on displacement field, 163-164 and boundary condition on $\epsilon_0 E$, 83, 166on cylinder in uniform electric field, 273-275

of differential sheets, 68-69 disk, 69-71 electric field due to, 65-67 force on, 213-215 hollow cylinder, 71 induced by line charge near plane, 97 induced by point charge near plane, 107-108 induced by point charge near sphere, 106 and parallel plate capacitor, 175 on slanted conducting planes, 273 on spatially periodic potential sheet, 266 on sphere in uniform electric field, 289 between two lossy dielectrics, 186-187 two parallel opposite polarity sheets, 67-68 Surface conductivity, 435, 601 Susceptibility, electric, 146 magnetic, 350, 352 Tangential component boundary conditions, electric field, 162-163 magnetic field, 359-360 Taylor, G. I., 264 Taylor series expansion, 298 of logarithm, 205 Temperature, ideal gas law, 154-155 TEM waves, see Transverse electromagnetic waves TE waves, see Transverse electric waves Tesla, 314 Test charge, 57 Thermal voltage, 156, 158 Thermionic emission, 108-109 in vacuum tube diode, 198 Thomson, J. J., 377 Till, H. R., 201 Time constant: charged particle precipitation onto sphere, 296 charging of lossy cylinder, 273 discharge of earth's atmosphere, 197 distributed lossy cable, 192-194 magnetic diffusion, 440 ohmic charge relaxation, 182-184 resistor-inductor, 436 for self-excited electrostatic induction machine, 226 series lossy capacitor, 186-188 Time dilation, 505 TM waves, see Transverse magnetic waves Tolman, R. C., 237 Torque, on electric dipole, 215

on homopolar machine, 422 on magnetic dipole, 353 Toroid, 408-409 Tourmaline, 517 Transformer: action. 411 autotransformer, 474 ideal, 413-416 impedance, 415-416 real, 416-417 twisted, 473-474 Transient charge relaxation, see Charge relaxation Transmission coefficient, 523 Transmission line: approach to dc steady state, 585-589 equations, 568-576 losses, 602-603 sinusoidal steady state, 595-596 transient waves, 579-595 Transverse electric (TE) waves, in dielectric waveguide, 647-648 in rectangular waveguide, 635-638 power flow, 642-643 Transverse electromagnetic (TEM) waves, 496-497 power flow, 532 transmission lines, 569-574 Transverse magnetic (TM) waves: in dielectric waveguide, 644-647 power flow, 641-642 in rectangular waveguide, 631-635 Traveling waves, 497-500 Triple product, scalar, 42 vector, 42 Two wire line, 99-103 Uman, M. A., 195 Uniform plane waves, 529-530 Uniqueness, theorem, 258-259 of vector potential, 336-338 Unit: capacitance, 175 rationalized MKSA, 55-56 resistance, 171 SI. 55-56 Unit vectors, 3-5 divergence and curl of, 45 Unpolarized waves, 546-547 Vacuum tube diode, 198-201 Van de Graaff generator, 223-224 Vector, 8-16 addition and subtraction, 9-11 cross(vector) product, 13-16

distance between two points, 72 dot(scalar) product, 11-13 identities, 46-47 curl of gradient, 38-39 divergence of curl, 39 triple product, 42 magnitude, 8 multiplication by scalar, 8-9 product, 11-16 scalar (dot) product, 11-13 Vector potential, 336 of current distribution, 338 of finite length line current, 339 of finite width surface current, 341 of line current above perfect conductor or infinitely permeable medium, 363 of magnetic dipole, 345 and magnetic field lines, 342 and magnetic flux, 338 of radiating electric dipole, 668-669 of radiating waves, 667 uniqueness, 336-338 Velocity: conduction charge, 156 electromagnetic waves, 500 group, 513 light, 56, 500 phase, 513 Virtual work, 460-461 VSWR, 616-620 Voltage, 86 nonuniqueness, 412 standing wave ratio, 616-620 Volume charge distributions, 60 cylinder, 72-82 slab, 68-69 sphere, 79-80 Von Hippel, A. R., 147

Water, light propagation in, 548-549 Watson, P. K., 201

Wave: backward, 651 dispersive, 512-514 equation, 496-497 high frequency, 511-512 nondispersive, 503 plane, 496-497 properties, 499-500 radiating, 666-667 solutions, 497-499 sources, 500-503 standing, 521-522 transmission line, 578-579 traveling, 499-500 Waveguide: dielectric, 644-648 equations, 630 power flow, 641-644 rectangular, 629-644 TE modes, 635-638 TM modes, 631-635 wall losses, 643-644 Wave impedance, 498 Wavelength, 506 Wavenumber, 505-506 on lossy transmission line, 604 as vector, 530 Wheelon, A. D., 181 Whipple, F. J. W., 293 White, H. J., 293 White light, 563 Wimshurst machine, 227 Woodson, H. H., 420, 435 Work: to assemble charge distribution, 204-208 and dot product, 11 mechanical, 453 to move point charge, 84-85 to overcome electromagnetic forces, 452 Zeeman effect, 378 Zero potential reference, 87

VECTOR IDENTITIES

$$(\mathbf{A} \times \mathbf{B}) \cdot \mathbf{C} = \mathbf{A} \cdot (\mathbf{B} \times \mathbf{C}) = (\mathbf{C} \times \mathbf{A}) \cdot \mathbf{B}$$

$$\mathbf{A} \times (\mathbf{B} \times \mathbf{C}) = \mathbf{B}(\mathbf{A} \cdot \mathbf{C}) - \mathbf{C}(\mathbf{A} \cdot \mathbf{B})$$

$$\nabla \cdot (\nabla \times \mathbf{A}) = 0$$

$$\nabla \times (\nabla f) = 0$$

$$\nabla (fg) = f \nabla g + g \nabla f$$

$$\nabla (\mathbf{A} \cdot \mathbf{B}) = (\mathbf{A} \cdot \nabla) \mathbf{B} + (\mathbf{B} \cdot \nabla) \mathbf{A}$$

$$+ \mathbf{A} \times (\nabla \times \mathbf{B}) + \mathbf{B} \times (\nabla \times \mathbf{A})$$

$$\nabla \cdot (f\mathbf{A}) = f \nabla \cdot \mathbf{A} + (\mathbf{A} \cdot \nabla) f$$

$$\nabla \cdot (\mathbf{A} \times \mathbf{B}) = \mathbf{B} \cdot (\nabla \times \mathbf{A}) - \mathbf{A} \cdot (\nabla \times \mathbf{B})$$

$$\nabla \times (\mathbf{A} \times \mathbf{B}) = \mathbf{A} (\nabla \cdot \mathbf{B}) - \mathbf{B} (\nabla \cdot \mathbf{A})$$

$$+ (\mathbf{B} \cdot \nabla) \mathbf{A} - (\mathbf{A} \cdot \nabla) \mathbf{B}$$

$$\nabla \times (f\mathbf{A}) = \nabla f \times \mathbf{A} + f \nabla \times \mathbf{A}$$

$$(\nabla \times \mathbf{A}) \times \mathbf{A} = (\mathbf{A} \cdot \nabla) \mathbf{A} - \frac{1}{2} \nabla (\mathbf{A} \cdot \mathbf{A})$$

$$\nabla \times (\nabla \times \mathbf{A}) = \nabla (\nabla \cdot \mathbf{A}) - \nabla^{2} \mathbf{A}$$

INTEGRAL THEOREMS

Line Integral of a Gradient

$$\int_{a}^{b} \nabla f \cdot \mathbf{dl} = f(b) - f(a)$$

Divergence Theorem:

$$\int_{\mathbf{V}} \nabla \cdot \mathbf{A} d\mathbf{V} = \oint_{S} \mathbf{A} \cdot \mathbf{dS}$$

Corollaries

$$\int_{\mathbf{V}} \nabla f \, d\mathbf{V} = \oint_{S} f \, \mathbf{dS}$$
$$\int_{\mathbf{V}} \nabla \times \mathbf{A} \, d\mathbf{V} = -\oint_{S} \mathbf{A} \times \mathbf{dS}$$

Stokes' Theorem:

$$\oint_L \mathbf{A} \cdot \mathbf{dl} = \int_S (\nabla \times \mathbf{A}) \cdot \mathbf{dS}$$

Corollary

$$\oint_L f \mathbf{dl} = -\int_S \nabla f \times \mathbf{dS}$$

Resource: Ò|^&d[{ æ*}^ca3k/4Ø8t\|åÁ/@^[¦^k/40E4Ú|[à|^{ ÁÛ[|çā]*Á0E]] |[æ&@ Tæ\ੱ•Azæ@

The following may not correspond to a particular course on MIT OpenCourseWare, but has been provided by the author as an individual learning resource.

For information about citing these materials or our Terms of Use, visit: http://ocw.mit.edu/terms.